

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Vivitar](#) /

› [Vivitar VPULSE Multi LED Bluetooth Speaker User Manual](#)

Vivitar VPULSE

Vivitar VPULSE Multi LED Bluetooth Speaker User Manual

Model: VPULSE

INTRODUCTION

Thank you for purchasing the Vivitar VPULSE Multi LED Bluetooth Speaker. This portable speaker is designed to provide wireless audio playback with integrated LED lighting effects. Please read this manual carefully to ensure proper use and to maximize your listening experience.



Image: Front view of the Vivitar VPULSE Multi LED Bluetooth Speaker.

PACKAGE CONTENTS

Please check the package for the following items:

- Vivitar VPULSE Multi LED Bluetooth Speaker
- USB Charging Cable

- User Manual



Image: The Vivitar VPULSE Multi LED Bluetooth Speaker in its retail packaging.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the supplied USB charging cable to the speaker's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will illuminate during charging and turn off when fully charged.

2. Powering On/Off

To power on the speaker, press and hold the Power button located on the top panel until the LED lights activate. To power off, press and hold the Power button again until the LED lights turn off.



Image: Top view of the speaker, highlighting the control buttons and ports.

OPERATING INSTRUCTIONS

1. Bluetooth Pairing

1. Ensure the speaker is powered on and within 1 meter (3 feet) of your Bluetooth-enabled device.
2. The speaker will automatically enter pairing mode, indicated by a flashing LED light.
3. On your device, navigate to the Bluetooth settings and search for available devices.
4. Select "Vivitar VPULSE" from the list.
5. Once paired, the speaker will emit an audible confirmation, and the LED light will stop flashing.

The speaker is compatible with most Bluetooth-enabled devices, including smartphones, tablets, and MP3 players.

2. Audio Playback

- **Play/Pause:** Press the Play/Pause button once to play or pause audio.
- **Volume Control:** Use the Volume Up (+) and Volume Down (-) buttons on the speaker to adjust the volume. You can also adjust the volume from your connected device.
- **Next/Previous Track:** Press and hold the Volume Up (+) button for the next track, or press and hold the Volume Down (-) button for the previous track.

3. LED Light Control

The Vivitar VPULSE speaker features multi-color LED lights. To cycle through different light modes or turn the lights off, press the LED button located on the top panel. Each press will change the light pattern or state.



Image: The Vivitar VPULSE speaker displaying its active multi-color LED lights.

MAINTENANCE

Cleaning

To clean the speaker, use a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the surface or internal components. Avoid exposing the speaker to excessive moisture.

Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to fully charge the battery before storing and to recharge it every few months to maintain

battery health.

Battery Care

The speaker contains a rechargeable Lithium-Ion battery. To prolong battery life:

- Avoid fully discharging the battery frequently.
- Do not expose the battery to high temperatures.
- If the speaker will not be used for a long time, charge it periodically.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is discharged.	Charge the speaker using the provided USB cable.
Cannot pair with Bluetooth device.	Speaker is not in pairing mode or too far from device.	Ensure speaker is powered on and flashing. Move device closer to speaker. Turn off and on Bluetooth on your device.
No sound during playback.	Volume is too low or device is not connected.	Increase speaker and device volume. Ensure Bluetooth is connected and audio is playing on the device.
LED lights are not working.	LED function is turned off or battery is low.	Press the LED button to cycle through modes. Charge the speaker.

SPECIFICATIONS

- **Model Name:** VPULSE
- **Brand:** Vivitar
- **Connectivity Technology:** Bluetooth
- **Wireless Communication Technology:** Bluetooth
- **Audio Output Mode:** Stereo
- **Power Source:** Battery Powered (2 Lithium Ion batteries included)
- **Control Method:** Touch
- **Special Feature:** Portable, Multi LED Lighting
- **Recommended Uses:** Music, Portable Listening (Outdoor)
- **Compatible Devices:** MP3 Player, Smartphone, Tablet
- **Product Dimensions:** 5 x 5 x 9.5 inches
- **Item Weight:** 8.8 ounces (0.55 Pounds)
- **Waterproof:** No

WARRANTY INFORMATION

This Vivitar VPULSE Multi LED Bluetooth Speaker comes with a limited warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included in your product packaging or contact Vivitar customer support.

SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please visit the official Vivitar website or contact their customer support department. Contact information can typically be found on the product packaging or the Vivitar official website.

© 2024 Vivitar. All rights reserved.