

Zippo 2004742

Zippo Pocket Watch Chrome Polished Lighter Instruction Manual

Model: 2004742

INTRODUCTION

This manual provides essential instructions for the safe and proper use, maintenance, and care of your Zippo Pocket Watch Chrome Polished Lighter, Model 2004742. This lighter features a distinctive pocket watch and number wheels emblem design. It is a windproof lighter designed for reliable performance.

Key Features:

- Authentic Zippo "click" sound upon opening.
- Windproof design for consistent flame in various conditions.
- Durable metal construction.
- Packaged in a gift box.

SETUP

1. Fueling Your Zippo Lighter

Your Zippo lighter is shipped without fuel for safety. Use only genuine Zippo lighter fluid for optimal performance.

1. Open the lighter and remove the inner unit (insert) from the case.
2. Lift the felt pad on the bottom of the insert to expose the packing material.
3. Slowly saturate the packing material with Zippo lighter fluid until the cotton is wet. Do not overfill.
4. Replace the felt pad and insert the unit back into the case.
5. Wipe any excess fluid from the lighter and your hands before igniting.

2. Flint Check

Ensure the flint is properly seated and provides a strong spark. If not, refer to the Maintenance section for flint replacement.

OPERATING INSTRUCTIONS

1. **Open the Lid:** Flip open the lid of the lighter. You will hear the distinctive Zippo "click."
2. **Ignite the Flame:** Hold the lighter firmly and spin the flint wheel downwards with your thumb to create a spark. The spark will ignite the fuel-soaked wick.
3. **Maintain Flame:** Keep the lid open to maintain the flame.
4. **Extinguish Flame:** Close the lid to extinguish the flame. Do not blow out the flame.



Image: The Zippo lighter open, showing the internal mechanism and the detailed pocket watch design on the case.

MAINTENANCE

1. Refueling

Refuel your Zippo lighter as described in the "Setup" section when the flame becomes weak or fails to

ignite. Frequency depends on usage.

2. Replacing the Flint

If the flint wheel spins but no spark is produced, the flint needs replacement.

1. Remove the inner unit from the case.
2. Unscrew the flint spring at the bottom of the insert. Be careful, as the spring is under tension.
3. Remove the old flint and insert a new Zippo flint into the tube.
4. Replace the flint spring and tighten it securely. Do not overtighten.
5. Insert the unit back into the case.

3. Trimming the Wick

If the flame becomes inconsistent or difficult to light, the wick may need trimming.

1. Using tweezers or pliers, gently pull the wick up until a clean, unburned section is exposed.
2. Trim the wick even with the top of the chimney using scissors.
3. Reshape the wick to ensure it is centered and straight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lighter won't light.	No fuel.	Refuel the lighter with Zippo lighter fluid.
Lighter won't light.	Worn flint.	Replace the flint.
Weak or inconsistent flame.	Wick needs trimming or adjusting.	Trim or adjust the wick as described in the Maintenance section.
Lighter leaks fuel.	Overfilled with fuel or damaged felt pad.	Do not overfill. Ensure felt pad is properly seated. If damage persists, contact Zippo support.

SPECIFICATIONS

- Brand:** Zippo
- Model Number:** 2004742
- Color:** Chrome
- Material:** Brass
- Style:** Square
- Item Weight:** 50 Grams (1.76 ounces)
- Fuel Type:** Gasoline (Zippo Lighter Fluid recommended)
- Product Dimensions:** 2.28"L x 1.5"W x 0.79"Th
- Specific instructions for use:** Ideal in wind and weather




Image: The Zippo lighter shown in hand, illustrating its compact size (approximately 2.3 inches / 5 cm in height).

WARRANTY AND SUPPORT

All Zippo lighters are backed by Zippo's famous lifetime guarantee: "It works or we fix it free.™" For service or repair, please visit the official Zippo website or contact Zippo customer service directly. Do not attempt to repair the lighter yourself beyond basic maintenance as this may void the warranty.

For more information, visit the [Zippo Store on Amazon](#).

© 2024 Zippo Manufacturing Company. All rights reserved.

Please use Zippo products responsibly.