

[Manuals.plus](#) /

› [Handy Laundry](#) /

› Handy Laundry Folding Step Stool Instruction Manual

Handy Laundry 5111

Handy Laundry Folding Step Stool Instruction Manual

Model: 5111

1. PRODUCT OVERVIEW

The Handy Laundry Folding Step Stool is designed for versatile use around the home, providing a sturdy and reliable boost for various tasks. Its compact, foldable design ensures easy storage and portability, making it ideal for small spaces and on-the-go needs. Equipped with enhanced safety features, this step stool offers stability and confidence for users of all ages.



Figure 1: The Handy Laundry Folding Step Stool (Black, 9-Inch).

2. SETUP INSTRUCTIONS

The Handy Laundry Folding Step Stool requires no assembly and is designed for quick and easy setup. Follow these steps to prepare your stool for use:

1. **Unfolding the Stool:** Hold the stool by its integrated carrying handle. Allow the two side panels to swing outwards until they are fully extended and locked into place. You will hear a click as the locking mechanism engages.
2. **Verify Stability:** Before stepping on the stool, ensure all four legs are firmly on a flat, stable surface. Gently press down on the top surface to confirm it is securely locked in the open position.

Easy to Use

Quickly Opens and Folds
with just One Hand



Figure 2: Unfolding the step stool for immediate use.

3. OPERATING INSTRUCTIONS

This folding step stool is designed for safe and convenient use in various household environments. Always adhere to the following guidelines:

- **Standing Surface:** Always step onto the center of the stool's top surface. The surface features a gripped finish with white polka dots to minimize slips.
- **Weight Capacity:** The stool is designed to support up to 300 pounds (136 kg). Do not exceed this weight limit.
- **Stability:** Ensure the stool is placed on a dry, level, and stable surface before use. Avoid placing it on uneven ground or slippery floors.
- **Folding the Stool:** To fold, lift the carrying handle located in the center of the top surface. The side panels will automatically collapse inward. Once folded, the stool becomes slim and compact for easy storage.

The Perfect Leg-Up

NO-SLIP
GRIP DOT
SURFACE

ANTI-SKID
FOOT PADS

ANSI III SAFETY CERTIFIED

Figure 3: Detail of the non-slip surface and anti-skid foot pads.



Strong and Durable

Can Support Weights
of Up to 300lbs!

Figure 4: The stool's robust construction supports significant weight.

4. MAINTENANCE

To ensure the longevity and optimal performance of your folding step stool, follow these simple maintenance tips:

- **Cleaning:** Wipe the stool clean with a damp cloth and mild soap. Avoid using abrasive cleaners or harsh chemicals, as these may damage the plastic.
- **Drying:** Ensure the stool is completely dry before folding and storing to prevent moisture buildup.
- **Storage:** Store the folded stool in a cool, dry place away from direct sunlight or extreme temperatures. Its slim profile allows it to fit in narrow spaces, such as between appliances or under furniture.



Figure 5: The stool's design allows for easy carrying and space-saving storage.

5. TROUBLESHOOTING

If you encounter any issues with your folding step stool, please refer to the following common solutions:

Problem	Possible Cause	Solution
Stool does not lock open securely.	Side panels not fully extended.	Ensure both side panels are pushed outwards until they click into place.
Stool feels wobbly.	Uneven surface or debris under legs.	Place the stool on a flat, level surface. Check for and remove any debris under the feet.
Difficulty folding the stool.	Handle not lifted completely.	Lift the central carrying handle firmly and completely to disengage the locking mechanism.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions (Open)	9.75"D x 12.5"W x 9"H
Material	Plastic
Color	Black
Weight Limit	300 Pounds (136 kg)
Item Weight	2.2 pounds (1 kg)
Foldable	Yes
Assembly Required	No
Model Number	5111
UPC	021455051119

The Perfect Fit




Figure 6: Product dimensions for the 9-inch stool.

7. SAFETY INFORMATION

Your safety is paramount. Please read and understand all safety warnings before using this product:

- **WARNING:** Always ensure the stool is fully open and locked into position before use.
- **WARNING:** Do not stand on the stool with only one foot. Always maintain balance with two feet on the step stool.
- **CAUTION:** Do not use the stool as a seat unless it is fully opened and on a stable surface.
- **CAUTION:** Keep hands and fingers clear of folding parts when opening or closing the stool to prevent pinching.
- **CAUTION:** Do not place the stool on boxes, unstable surfaces, or in the path of nearby doors.
- **PROPER CARE & STORAGE:** To extend the life of your stool, store it in a dry place. Do not store heavy materials on the stool.

8. WARRANTY AND SUPPORT

Handy Laundry products are manufactured with quality and durability in mind. For any questions, concerns, or warranty claims regarding your Folding Step Stool, please contact Handy Laundry customer support.

Visit the official Handy Laundry Store for more information and product support:[Handy Laundry Store](#)

© 2025 Handy Laundry. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question