



[Manuals.plus](#) /

› [Octane Seating](#) /

› Octane Seating Blaze XL900 Home Theater Chairs Instruction Manual

## Octane Seating XL900

# Octane Seating Blaze XL900 Home Theater Chairs Instruction Manual

Model: XL900

## INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Octane Seating Blaze XL900 Home Theater Chairs. Please read this manual thoroughly before use to ensure proper function and longevity of your product.

## SAFETY INFORMATION

- Keep the chairs away from direct heat sources to prevent damage to the upholstery and internal components.
- Do not use the chairs if any part is damaged or appears to be malfunctioning. Contact customer support immediately.
- Ensure all power cords are properly routed to avoid tripping hazards and are not pinched by moving parts.
- Keep children and pets away from the moving parts of the recline mechanism.
- Do not stand on the footrest or armrests.

## PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Octane Seating Blaze XL900 Chair Sections (Quantity will vary based on configuration, e.g., 4 sections for a straight row of 4)
- Backrests for each chair section
- Power Adapter and Cables
- User Manual (This document)
- Pillows (3 included)

## SETUP AND ASSEMBLY

---

Assembly of the Octane Seating Blaze XL900 chairs is designed to be straightforward. It is recommended to have two people for easier handling.

1. **Unpack Components:** Carefully remove all chair sections, backrests, and accessories from their packaging. Inspect for any shipping damage.
2. **Position Chair Bases:** Place the main chair bases in their desired location. Ensure there is sufficient space behind the chairs for the wall-away recline mechanism to operate without obstruction.
3. **Attach Backrests:** Align the metal brackets on the backrest with the corresponding slots on the chair base. Slide the backrest down firmly until it locks into place. Repeat for all chair sections.
4. **Connect Power:** Locate the power cable connections under each chair. Connect the individual chair power cables to the main power adapter, then plug the adapter into a standard electrical outlet. Ensure all connections are secure.
5. **Test Functionality:** Once assembled and powered, test the power recline and LED functions of each chair.



Image: A straight row of four Octane Seating Blaze XL900 home theater chairs in brown top-grain leather. One chair is fully reclined, showcasing the power recline mechanism and the blue LED lighting beneath the base and within the cup holders. This illustrates the assembled product.

## OPERATING INSTRUCTIONS

---

### Power Recline Function

Each chair is equipped with a power recline mechanism. To recline, locate the control buttons on the inner side of the armrest. Press and hold the appropriate button to extend the footrest and recline the backrest to your desired position. Release the button to stop. To return to the upright position, press and hold the other button until the chair is fully upright.

Your browser does not support the video tag.

Video: This video demonstrates the power recline function of the Octane Seating Blaze XL900 chairs, showing how to operate the recline mechanism and highlighting the smooth movement and comfortable positions. It also showcases the LED lighting and accessory dock features.

### LED Ambient Lighting

The chairs feature blue LED lighting in the cup holders and along the baserail. These lights can be turned on or off using

a dedicated button located near the recline controls on the armrest. The ambient lighting enhances the home theater experience and provides subtle illumination.

## USB Charging Port

A built-in USB port is located on the armrest control panel, allowing you to charge your electronic devices while seated. Simply connect your device's USB cable to the port.



Image: A detailed view of the armrest control panel on an Octane Seating Blaze XL900 chair. It clearly shows the power recline buttons, the LED light control, and the integrated USB charging port with a smartphone plugged in, demonstrating its functionality.

## Accessory Dock

Each armrest includes a stainless steel accessory dock. This dock is designed to hold various Octane Seating accessories (sold separately), such as tray tables, wine glass holders, LED flex lights, and tablet holders. To use, simply insert the accessory into the dock until it is securely seated.



Image: Two Octane Seating Blaze XL900 chairs are shown with optional accessories. One chair features a wine glass holder securely placed in its accessory dock, holding a glass of red wine. The neighboring chair has a tray table accessory, displaying a bowl of popcorn, illustrating the versatility of the accessory dock system.

## MAINTENANCE

- **Leather Care:** For top-grain leather, regularly dust with a soft, dry cloth. For spills, blot immediately with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners. Use a specialized leather cleaner and conditioner periodically as recommended by leather care professionals.
- **Mechanism Lubrication:** The power recline mechanism is factory-lubricated. If any squeaking or stiffness occurs over time, a silicone-based lubricant can be applied to moving joints. Avoid oil-based lubricants.
- **Electrical Components:** Ensure all power cables and connections are free from damage. Do not attempt to repair electrical components yourself. Contact qualified service personnel.
- **General Cleaning:** Vacuum crevices and under cushions regularly to remove dust and debris.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not recline.	Power cable disconnected; power outlet not working; motor malfunction.	Check all power connections. Ensure the outlet has power. If problem persists, contact customer support.

Problem	Possible Cause	Solution
LED lights are not working.	LED power button off; loose connection; LED strip damage.	Press the LED power button. Check connections. If still not working, contact customer support.
USB port not charging.	Device cable faulty; USB port malfunction; chair not powered.	Try a different USB cable and device. Ensure the chair is powered. Contact support if issue continues.
Squeaking noise during recline.	Mechanism requires lubrication.	Apply a silicone-based lubricant to moving metal joints.

## SPECIFICATIONS

Feature	Detail
Brand	Octane Seating
Model Name	Blaze XL900
Color	Brown
Product Dimensions (Overall)	39"D x 125"W x 44"H (for a row of 4)
Seat Height	21 Inches
Seat Depth	22 inches
Material	Top Grain Leather, Foam Fill
Special Features	Power Recline, Ambient Blue LED Cup Holders & Baserail, Gel Infused Memory Foam, Accessory Dock, Built-in USB Port
Item Weight	179 pounds (per chair section, approximate)

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Octane Seating website. Keep your proof of purchase for warranty claims.

**Important:** If you experience any issues not covered in the troubleshooting section, or require replacement parts, please contact Octane Seating customer service directly.

