



Manuals.plus /

- › Tzumi /
- › Tzumi Retractable Cord Manager User Manual

Tzumi Retractable Cord Manager

Tzumi Retractable Cord Manager User Manual

INTRODUCTION

This manual provides instructions for the proper use and maintenance of your Tzumi Retractable Cord Manager. This device is designed to efficiently organize and store various cables, including headphones, chargers, and lightweight USB cords, preventing tangles and clutter.



TZumi

Retractable Cord Manager
Enrouleur de fils rétractable
Organizador de cordones retráctil

EASY AS 1-2-3 Pull the cord straight down until it winds

SIMPLE COMME BONJOUR
Tirez le fil vers le bas pour qu'il s'enroule.

LISTO EN UN 1-2-3

Jale el cordón, estírelo hacia abajo hasta que se envuelva.

TZumi

- **Automatically winds cables, cords & earbuds**
Enroule automatiquement les câbles, les fils et les écouteurs.
Envuelve automáticamente cables, cordones y audífonos.

Image: The Tzumi Retractable Cord Manager, a pink, oval-shaped device, shown within its retail packaging. The packaging highlights its retractable feature and ease of use for managing cables and earbuds.

SETUP

The Tzumi Retractable Cord Manager requires no complex setup. It is ready for use directly out of its packaging. Ensure the device is free from any packaging materials before first use.

OPERATING INSTRUCTIONS

To use the Tzumi Retractable Cord Manager, follow these simple steps:

1. **Extend the Cord:** Gently pull the cable or cord you wish to manage straight down from the opening of the device. Continue pulling until the desired length is extended or the cord is fully unwound.
2. **Retract the Cord:** To retract the cord, pull it straight down again slightly, then release. The internal mechanism will automatically wind the cord back into the manager.
3. **Secure the Cord:** Ensure the cord is fully retracted and secured within the device to prevent tangles.

The device is designed to automatically wind cables, cords, and earbuds up to 60 inches in length.

MAINTENANCE

To ensure the longevity and proper function of your Tzumi Retractable Cord Manager, observe the following maintenance guidelines:

- **Cleaning:** Wipe the exterior of the device with a soft, dry cloth. Avoid using abrasive cleaners or solvents, as these may damage the finish.
- **Storage:** Store the cord manager in a clean, dry place away from extreme temperatures and direct sunlight.
- **Avoid Over-Stressing:** Do not force cords into or out of the device. Use only lightweight cables and cords as intended.

TROUBLESHOOTING

If you encounter issues with your Tzumi Retractable Cord Manager, consider the following:

- **Cord Not Retracting:**
 - Ensure the cord is pulled straight down before releasing it for retraction.
 - Check if the cord is tangled or obstructed at the opening.
 - Verify that the cord is not too thick or heavy for the device's mechanism. The manager is designed for lightweight cables up to 60 inches.
- **Difficulty Extending Cord:**
 - Ensure there are no knots or kinks in the cord being managed.
 - Pull the cord gently and steadily; avoid sudden jerks.

SPECIFICATIONS

Brand	Tzumi
Model	Retractable Cord Manager
ASIN	B0150GIISY
Maximum Cord Length	Up to 60 inches (152 cm)
Compatible Cords	Headphones, chargers, lightweight USB cables, earbuds
Date First Available	September 6, 2015

WARRANTY AND SUPPORT

Specific warranty details for the Tzumi Retractable Cord Manager are not provided in this manual. For warranty information or product support, please refer to the product packaging or contact Tzumi customer service directly through their official website or the retailer where the product was purchased. Keep your purchase receipt as proof of purchase for any warranty claims.