

[Manuals.plus](#) /

> [CGOLDENWALL](#) /

> CGOLDENWALL Corn Dog Waffle Maker Machine Instruction Manual

CGOLDENWALL FF203

CGOLDENWALL Corn Dog Waffle Maker Machine Instruction Manual

Model: FF203

1. PRODUCT OVERVIEW

The CGOLDENWALL Commercial/Home Corn Dog Waffle Maker Machine is a versatile appliance designed for making corn dogs, waffles, and other stick-shaped treats. It features a non-stick coating for easy food release and cleaning, adjustable temperature control (0-300°C / 0-482°F), and a 0-5 minute timer. Constructed from durable stainless steel, this 1550W machine ensures quick and even heating for consistent results.



Image: The CGOLDENWALL Corn Dog Waffle Maker Machine, showcasing its stainless steel body and waffle molds.

2. SAFETY PRECAUTIONS

- Always ensure the machine is placed on a stable, heat-resistant surface.
- Do not immerse the machine in water or any other liquid.
- Keep hands and utensils away from the hot plates during operation.
- Unplug the machine when not in use and before cleaning.
- Ensure proper ventilation around the machine during use.

3. SETUP AND FIRST USE

1. **Unpacking:** Carefully remove the waffle maker from its packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wipe down the non-stick plates with a damp cloth and mild

detergent. Rinse with a clean damp cloth and dry thoroughly.

3. **Placement:** Place the machine on a flat, stable, and heat-resistant countertop. Ensure there is adequate space around the unit for ventilation.
4. **Power Connection:** Plug the power cord into a grounded 110V AC electrical outlet.



Image: Demonstrates the easy cleaning process of the non-stick plates and detachable tray.

4. OPERATING INSTRUCTIONS

Follow these steps for optimal performance and delicious results:

1. **Preheating:** Turn the temperature knob to your desired setting (e.g., 300°C for corn dogs, 225-250°C for waffles). Set the timer to 5 minutes for preheating. The green 'POWER' light will illuminate, and the orange 'HEAT' light will turn on during heating and off when the set temperature is reached.
2. **Prepare Molds:** Once preheated, open the lid. Lightly brush the non-stick upper and lower plates with cooking oil or glaze.
3. **Pour Batter:** Pour your prepared batter into the waffle molds. For corn dogs, you may insert the hot dog or sausage into the batter.
4. **Close and Cook:** Carefully close the lid. Set the timer according to your recipe. For corn dogs,

approximately 5 minutes at 300°C is recommended. For waffles, 7 minutes or longer at 225-250°C may be needed for thorough cooking.

5. **Remove Product:** Once the timer sounds and the cooking is complete, carefully open the lid. Use a non-metallic utensil to remove the cooked corn dogs or waffles.

EASY TO CLEAN

Teflon Non-stick coating
& Detachable Tray



Image: Step-by-step guide on how to use the waffle maker, from preparing batter to pouring and cooking.

Your browser does not support the video tag.

Video: Demonstrates the operational steps of the CGOLDENWALL Corn Dog Machine, including preheating, oiling, pouring batter, and cooking. This video shows the machine in action, producing corn dog waffles.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will prolong the life of your waffle maker.

- **Cool Down:** Always allow the machine to cool completely before cleaning.
- **Non-Stick Plates:** Wipe the non-stick plates with a soft, damp cloth or sponge. For stubborn residue, use a small amount of mild dish soap. Avoid abrasive cleaners or metal scouring pads, as they can damage the non-stick coating.
- **Detachable Drip Tray:** The detachable drip tray can be removed and washed with warm, soapy

water. Ensure it is completely dry before reinserting.

- **Exterior:** Wipe the stainless steel exterior with a clean, damp cloth. Dry thoroughly to prevent water spots.
- **Storage:** Store the machine in a dry, clean place when not in use.



Image: Highlights the machine's features, including the stainless steel body and the convenient detachable drip tray for easy cleaning.

6. TROUBLESHOOTING

If you encounter any issues, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in, power switch off, power outage.	Check power connection, ensure switch is on, check circuit breaker.
Waffles/Corn Dogs stick to plates.	Insufficient oiling, damaged non-stick coating.	Ensure plates are properly oiled before each use. Avoid using metal utensils.
Uneven cooking.	Incorrect temperature setting, uneven batter distribution.	Adjust temperature, ensure batter is evenly spread across molds.

If the problem persists, please contact customer support.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	CGOLDENWALL
Model Number	FF203
Wattage	1550 watts
Voltage	110 Volts (AC)
Temperature Control	0-300°C (0-482°F)
Timer	0-5 minutes
Material	Stainless Steel (body), Non-stick coating (plates)
Product Dimensions	15.35"D x 13.9"W x 9.65"H
Item Weight	21 Pounds
Included Components	Bamboo stick, Corn Dog Waffle Maker Machine, Instruction Manual

8. WARRANTY AND SUPPORT

The CGOLDENWALL Corn Dog Waffle Maker Machine comes with **one-year warranty**. For any operational questions, technical support, or warranty claims, please contact our service team online. We are dedicated to elevating your overall kitchen experience and quality of life.

You can also visit the official CGOLDENWALL store for more information and products: [CGOLDENWALL Store](#)