

[Manuals.plus](#) /

› [Dabmar](#) /

› Dabmar GM630-LED30-B LED Wall Fixture Instruction Manual

Dabmar GM630-LED30-B

Dabmar GM630-LED30-B LED Wall Fixture Instruction Manual

Model: GM630-LED30-B

1. INTRODUCTION

Thank you for choosing the Dabmar GM630-LED30-B LED Wall Fixture. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting product. Please read these instructions thoroughly before installation and retain them for future reference.

2. SAFETY INFORMATION

- **WARNING:** Risk of electric shock. Disconnect power at the fuse or circuit breaker before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC).
- Consult a qualified electrician if you are unsure about the installation process.
- Ensure the fixture is securely mounted to a structurally sound surface.
- Do not operate the fixture with a damaged cord or if it has been dropped or damaged in any way.
- This fixture is designed for outdoor use.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Wall Fixture (GM630-LED30-B)

4. SETUP AND INSTALLATION

Tools Required (Not Included): Screwdriver, wire strippers, electrical tape, drill (if needed for mounting).

4.1 Pre-Installation

1. Turn off power at the circuit breaker or fuse box before starting installation.
2. Carefully unpack the fixture and inspect for any damage.
3. Ensure you have all necessary mounting hardware and tools.

4.2 Mounting the Fixture

1. Position the mounting bracket against the desired wall surface.
2. Mark the locations for drilling pilot holes.
3. Drill pilot holes and secure the mounting bracket to the wall using appropriate screws and anchors (if necessary).
4. Ensure the bracket is firmly attached and level.

4.3 Wiring Connections

1. Connect the fixture's black wire to the household's black (hot) wire.
2. Connect the fixture's white wire to the household's white (neutral) wire.
3. Connect the fixture's green or bare copper wire to the household's green or bare copper (ground) wire.
4. Secure all wire connections with approved wire connectors and wrap with electrical tape for added protection.
5. Carefully tuck all wires into the junction box.

4.4 Final Assembly

1. Attach the fixture body to the mounted bracket, ensuring a snug fit.
2. Secure the fixture with any provided screws or fasteners.
3. Ensure all seals and gaskets are properly seated to maintain weather resistance.



This image displays the Dabmar GM630-LED30-B LED Wall Fixture. It features a black cast aluminum body with a modern design. The light source is enclosed within a clear, ribbed diffuser, providing ambient illumination. The fixture is mounted on a black wall bracket.

5. OPERATING INSTRUCTIONS

Once the fixture is securely installed and wired, restore power at the circuit breaker. The LED wall fixture will illuminate when power is supplied. Operation is typically controlled by an external wall switch or an integrated photocell/timer (if applicable and installed separately).

6. MAINTENANCE

- **Cleaning:** Ensure power is off before cleaning. Wipe the fixture with a soft, damp cloth. Do not use abrasive cleaners or solvents, as

they may damage the finish or electrical components.

- **Inspection:** Periodically inspect the fixture for any signs of wear, damage, or loose connections. Address any issues promptly.
- **LEDs:** The LED light source is integrated and not user-replaceable.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fixture does not light up.	No power supply.	Check circuit breaker or fuse. Ensure wall switch is ON.
	Loose wiring connection.	Turn off power and check all wire connections. Re-secure if loose.
	Faulty fixture.	If all other steps fail, contact customer support.
Light flickers.	Loose wiring.	Turn off power and check all wire connections.
Water inside fixture.	Improper sealing during installation.	Turn off power. Disassemble, dry thoroughly, and reassemble ensuring all gaskets and seals are correctly seated.

8. SPECIFICATIONS

Specification	Detail
Item Model Number	GM630-LED30-B
Brand	Dabmar
Manufacturer	DABMAR LIGHTING INC
Material	Aluminum
Style	Modern
Light Fixture Form	Wall
Power Source	Corded Electric
ASIN	B01577SAZM
Date First Available	September 10, 2015

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact Dabmar Lighting Inc. directly through their official website or customer service channels. Please have your model number (GM630-LED30-B) and proof of purchase available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01577SAZM>

More documents and user manuals: **<https://manuals.plus/>**