

[Manuals.plus](#) /

> [Beko](#) /

> Beko CN228220 Ice Cube Tray User Manual

Beko CN228220

Beko CN228220 Ice Cube Tray User Manual

Model: CN228220

INTRODUCTION

This manual provides essential information for the proper use and maintenance of your Beko CN228220 Ice Cube Tray. Please read these instructions carefully before first use to ensure optimal performance and longevity of the product. This ice cube tray is designed specifically for use with Beko CN228220 refrigerator models.



Image: The Beko CN228220 Ice Cube Tray, a white rectangular tray with a textured bottom surface and a raised front edge for easy handling.

SETUP

The Beko CN228220 Ice Cube Tray is a replacement or supplementary part for compatible Beko refrigerators. No complex setup is required.

1. **Unpacking:** Carefully remove the ice cube tray from its packaging. Inspect for any signs of damage during transit.
2. **Initial Cleaning:** Before first use, wash the ice cube tray thoroughly with warm water and a mild dish soap. Rinse completely and dry.
3. **Placement:** Place the clean ice cube tray into the designated slot or shelf within your Beko CN228220 refrigerator's freezer compartment. Ensure it sits level.

OPERATING INSTRUCTIONS

Using the ice cube tray is straightforward:

- Filling:** Fill the tray with potable water. Do not overfill; leave a small gap at the top to allow for water expansion during freezing.
- Freezing:** Carefully place the filled tray back into the freezer compartment. Allow several hours for the water to freeze completely into ice cubes. Freezing time may vary depending on your freezer's temperature setting.
- Removing Ice Cubes:** Once frozen, remove the tray from the freezer. To release the ice cubes, gently twist the tray or press on the bottom of individual compartments. For stubborn cubes, you may run a small amount of warm water over the back of the tray for a few seconds (avoiding the ice itself).
- Storage:** Store released ice cubes in a clean, sealed container in the freezer to prevent odor absorption and maintain freshness.

MAINTENANCE AND CARE

Regular cleaning will help maintain the hygiene and longevity of your ice cube tray.

- Cleaning:** Wash the ice cube tray regularly with warm water and mild dish soap. Avoid abrasive cleaners or scouring pads, which can scratch the surface.
- Drying:** Ensure the tray is completely dry before refilling and placing back into the freezer to prevent ice buildup on the tray itself.
- Odor Prevention:** If the tray develops odors, a solution of baking soda and water can be used for cleaning. Rinse thoroughly afterwards.
- Storage (when not in use):** If storing the tray for an extended period, ensure it is clean and dry, and store it in a clean, dry place.

TROUBLESHOOTING

Common issues and their solutions:

Problem	Possible Cause	Solution
Ice cubes are difficult to remove.	Overfilling the tray; insufficient twisting; tray stuck to freezer shelf.	Do not overfill. Twist the tray more firmly. If stuck, gently pry it loose or run warm water over the back of the tray briefly.
Ice cubes have an unusual taste or odor.	Water quality; odors from other foods in the freezer; tray not cleaned properly.	Use filtered water. Store ice cubes in an airtight container. Clean the tray thoroughly with baking soda solution. Ensure freezer is clean and food is covered.
Tray appears brittle or cracked.	Physical damage; extreme temperature fluctuations; age.	Handle with care. Avoid dropping or bending excessively. If cracked, replace the tray.

SPECIFICATIONS

- Product Name:** Beko Ice Cube Tray
- Model Number:** CN228220 (Part Number: 46845-CN228220)

- **Brand:** Beko
- **Compatibility:** Designed for Beko CN228220 refrigerator models.
- **Material:** Durable plastic (specific type not provided, assume food-grade plastic).
- **Shape:** Rectangular
- **ASIN:** B0158VCE72
- **Date First Available:** 1 June 2015

WARRANTY AND SUPPORT

As an accessory part, the Beko CN228220 Ice Cube Tray typically falls under the warranty terms of the appliance it is designed for, or a limited warranty for replacement parts. Please refer to the original documentation provided with your Beko CN228220 refrigerator for specific warranty details.

For further assistance or to inquire about replacement parts, please contact Beko customer support or visit the official Beko website. You may need to provide your refrigerator's model number and serial number when seeking support.

- **Beko Official Website:** www.beko.com
- **Customer Support:** Refer to your regional Beko website for local contact numbers and service information.

© 2024 Beko. All rights reserved.

This manual is for informational purposes only. Beko reserves the right to make changes to products without prior notice.