

Manuals.plus /

› Google /

› Google NC2-6A5 Chromecast HDMI Streaming Media Player Instruction Manual

Google NC2-6A5

Google NC2-6A5 Chromecast HDMI Streaming Media Player

Model: NC2-6A5 | Brand: Google

INTRODUCTION

The Google NC2-6A5 Chromecast is an HDMI streaming media player designed to bring online content to your television. This compact device allows you to cast videos, music, and other media from your smartphone, tablet, or laptop directly to any HDTV with an HDMI port. It offers a simple and convenient way to transform your existing television into a smart TV, providing access to a wide range of streaming services and applications.

SETUP

What's Included

- Google Chromecast device
- Power adapter
- USB power cable

Connection Steps

1. **Plug Chromecast into your HDTV:** Locate an available HDMI port on your television and firmly insert the Chromecast device.
2. **Connect to power:** Use the provided USB power cable and power adapter to connect the Chromecast to a power outlet. Ensure the device powers on, indicated by a small LED light.
3. **Select HDMI input:** On your TV, use your remote control to select the HDMI input corresponding to the port where your Chromecast is connected.



Image: The Google Chromecast HDMI Streaming Media Player device.



Image: A Google Chromecast device being plugged into an HDMI port on the back of a television.

Initial Configuration

1. **Download Google Home app:** On your smartphone or tablet, download and open the Google Home app.

2. **Connect to Wi-Fi:** Follow the on-screen instructions in the Google Home app to connect your Chromecast to your home Wi-Fi network.
3. **Link Google Account:** Sign in with your Google account to personalize your Chromecast experience.

OPERATING INSTRUCTIONS

Casting Content

Once setup is complete, you can cast content from compatible apps on your smartphone, tablet, or computer. Look for the Cast icon (a rectangle with a Wi-Fi symbol in the corner) within your favorite streaming apps (e.g., YouTube, Netflix, Hulu) and tap it to select your Chromecast device.

Using the Remote Control

The included remote control allows for easy navigation and control of your Chromecast. It features directional buttons, volume control, and dedicated buttons for popular streaming services like YouTube and Netflix.



Image: The Google Chromecast remote control with various buttons for navigation and app access.

Voice Control

The Chromecast supports voice control through Google Assistant. Press the microphone button on your remote and speak commands to search for content, control playback, or get information.

MAINTENANCE

General Care

- Keep the device in a well-ventilated area to prevent overheating.
- Clean the device with a soft, dry cloth. Avoid liquid cleaners.
- Do not expose the device to extreme temperatures or humidity.

Software Updates

The Chromecast will automatically download and install system software updates to ensure optimal performance and access to the latest features. Ensure the device remains connected to power and the internet during update periods.

TROUBLESHOOTING

No Signal on TV

- Ensure the Chromecast is firmly plugged into the HDMI port.
- Verify that your TV is set to the correct HDMI input source.
- Check that the Chromecast is receiving power and its LED indicator is on.

Casting Issues

- Ensure your casting device (smartphone, tablet, laptop) is connected to the same Wi-Fi network as

your Chromecast.

- Restart your Chromecast by unplugging it from the power source for 30 seconds and then plugging it back in.
- Restart your Wi-Fi router.

SPECIFICATIONS

Feature	Detail
Brand	Google
Model Name	H2G2-42
Connectivity Technology	HDMI
Connector Type	HDMI
Resolution	720p (Video Output Resolution: 1280x720)
Supported Internet Services	Chromecast
Controller Type	Button Control
Form Factor	TV Stick
Color	Black
Compatible Devices	Television, Smartphone, Personal Computer, Laptop, Tablet
Video Codec	H.264, H.265/HEVC
Item Weight	0.35 Pounds

WARRANTY

For detailed warranty information, please refer to the official Google product documentation included with your Chromecast or visit the Google support website. Standard warranty terms typically cover manufacturing defects for a limited period from the date of purchase.

SUPPORT

For further assistance, troubleshooting tips, or to access the full user manual, please visit the official Google Chromecast support website. You can also find community forums and FAQs to help resolve common issues.

RELATED VIDEOS

No relevant official seller videos for this specific product were found in the provided data.