

[Manuals.plus](#) /

› [Life-Tech](#) /

› Life-Tech Premium Hands-Free Stereo Earphones User Manual

Life-Tech B015AJMSPK

Life-Tech Premium Hands-Free Stereo Earphones User Manual

Model: B015AJMSPK

1. INTRODUCTION

Thank you for choosing Life-Tech Premium Hands-Free Stereo Earphones. This manual provides essential information for the proper setup, operation, and maintenance of your new earphones. Please read it carefully before use to ensure optimal performance and longevity of the product.

Product Features

- In-ear design for high-fidelity stereo sound.
- Standard 3.5mm plug compatible with most devices.
- Integrated microphone for hands-free communication.
- On/Off switch for call management.
- Tangle-free cord design.

2. SETUP

Package Contents

- Life-Tech Premium Hands-Free Stereo Earphones
- User Manual

Connecting Your Earphones

1. Locate the 3.5mm audio jack on your device (e.g., smartphone, tablet, MP3 player).
2. Insert the 3.5mm plug of the earphones firmly into the device's audio jack.
3. Ensure the connection is secure for proper audio transmission.



Image 1: The Life-Tech Premium Hands-Free Stereo Earphones, showing the 3.5mm audio jack, in-line microphone, and earbuds. This image illustrates the complete product for connection reference.

3. OPERATING YOUR EARPHONES

Audio Playback

Once connected, your earphones will automatically function as the audio output device for your connected device. Play music, videos, or other audio content as you normally would on your device.

Using the Microphone and Control Button

The earphones feature an in-line microphone and a control button for hands-free communication.

- **Answering a Call:** When a call comes in, press the control button once to answer.
- **Ending a Call:** During a call, press the control button once to end the conversation.
- **Rejecting a Call:** Press and hold the control button for approximately 2 seconds to reject an incoming call.
- **Playing/Pausing Music:** While listening to music, press the control button once to play or pause the track.



Image 2: A close-up view of the Life-Tech earbud design, highlighting the speaker grille and ergonomic shape for comfortable wear.

4. MAINTENANCE AND CARE

- **Cleaning:** Gently wipe the earbuds and cable with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earphones in a clean, dry place. Avoid extreme temperatures.
- **Tangle-Free Cord:** The cord is designed to resist tangling. To maintain this feature, coil the cable loosely when storing.
- **Avoid Moisture:** Keep the earphones away from water and excessive moisture to prevent damage.

5. TROUBLESHOOTING

If you encounter any issues with your earphones, please refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
No sound from earphones	• Earphones not fully plugged in. • Device volume is too low or muted. • Incorrect audio output selected on device. • Damaged cable or plug.	• Ensure the 3.5mm plug is fully inserted into the device's jack. • Increase the volume on your device. • Check your device's audio settings to ensure earphones are selected as output. • Test with another device or another pair of earphones to identify if the issue is with the earphones or the device.
Microphone not working	• Microphone port blocked. • Device microphone settings. • Damaged microphone.	• Ensure the microphone is not covered. • Check your device's privacy or sound settings to ensure microphone access is granted. • Test with another device.

Problem	Possible Cause	Solution
Poor sound quality (static, distorted)	- Loose connection. - Source audio quality is low. - Interference.	- Re-insert the 3.5mm plug firmly. - Try playing a different audio file or source. - Move away from potential sources of electromagnetic interference.

6. SPECIFICATIONS

Feature	Specification
Speaker Size	F10MM
Frequency Range	20Hz - 20KHz
Impedance	34Ω±3Ω
Sensitivity	107dB±3dB
Max Power Input	10mW
Microphone Sensitivity	-58±5Db
Connectivity Technology	Wired
Headphones Jack	3.5 mm Jack
Cable Feature	Tangle Free
Control Type	Media Control
UPC	714270674914

7. WARRANTY AND SUPPORT

Warranty Information

Life-Tech products are manufactured to high-quality standards. This product is covered by a standard limited warranty against defects in materials and workmanship. Please retain your proof of purchase for warranty claims. Specific warranty terms and duration may vary by region and retailer.

Customer Support

For further assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact Life-Tech customer support through the retailer where the product was purchased or visit the official Life-Tech website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B015AJMSPK>

More documents and user manuals: <https://manuals.plus/>