Leggett & Platt COMIN16JU043475

Leggett & Platt 7-Inch Adjustable Bed Leg Kit (M8 Threading) Instruction Manual

1. Introduction

This manual provides instructions for the proper installation, use, and care of your Leggett & Platt 7-inch Adjustable Bed Leg Kit. These legs are designed to replace existing legs on compatible adjustable bed frames, allowing you to adjust the bed's height. This kit includes four durable alloy steel legs with an M8 threaded bolt for secure attachment.

2. Safety Information

- Ensure the bed frame is stable before and after installation.
- Do not exceed the weight capacity of your bed frame.
- Keep small parts away from children.
- Always lift, do not drag, the bed frame when moving to prevent damage to legs or floor.
- Verify leg compatibility with your bed frame's threading before installation.

3. Package Contents

- 4 x Leggett & Platt 7-inch Adjustable Bed Legs (M8 Threading)



Image 1: The Leggett & Platt 7-inch adjustable bed leg kit, showing four individual black legs.

4. Compatibility

These legs feature M8 threading and are compatible with most Leggett & Platt adjustable bed frames. The M8 threaded bolt extends approximately 1/2 inch from the top of the leg.

Important: These legs are **NOT** compatible with Leggett & Platt 50 Series Adjustable Beds from Mattress Firm. Additionally, these legs are **NOT** compatible with Sealy or Serta brand frames. Always verify the threading type of your bed frame before installation to ensure proper fit and stability.



Image 2: Detail of the M8 threaded bolt and a clear warning about incompatible bed frame brands and models.

5. Setup & Installation

1. **Prepare the Bed:** Carefully lift or tilt your adjustable bed frame to access the existing legs. It is recommended to have assistance for this step to prevent injury or damage.
2. **Remove Existing Legs:** Unscrew and remove the current legs from your bed frame. Keep them in a safe place if you plan to reuse them later.
3. **Install New Legs:** Align the M8 threaded bolt of the new Leggett & Platt 7-inch leg with the corresponding threaded insert on your bed frame. Screw each leg clockwise until it is securely tightened. Do not overtighten, as this may damage the threading.
4. **Verify Stability:** Once all four legs are installed, carefully lower the bed frame to its upright position. Gently test the bed's stability by applying pressure to different areas. Ensure there is no wobbling or instability before use.

6. Operating Instructions (Usage)

The Leggett & Platt 7-inch adjustable bed legs provide a fixed height of 7 inches. Once installed, the bed's height will be raised by approximately 7 inches from the base of the frame, offering a consistent and stable elevation.

Caster Attachment

These legs are designed with a provision for attaching casters (wheels) to the bottom. If you wish to add casters, ensure they have a 7/16-inch diameter and a 1 1/2-inch high stem. Insert the caster stem into the hole at the bottom of the leg until it is securely seated. Grip ring stem casters are commonly used with these types of legs.



Image 3: Illustration of the bed legs, highlighting their design for use with 7/16-inch grip ring stem casters.

7. Maintenance

- **Cleaning:** Wipe the legs with a dry cloth to remove dust and debris. Avoid using harsh chemicals or abrasive cleaners, which may damage the finish.
- **Periodic Inspection:** Periodically check that all legs remain securely tightened to the bed frame. Retighten if necessary to maintain stability.

8. Troubleshooting

- **Bed is Unstable or Wobbly:**
  - Ensure all four legs are fully and securely tightened to the bed frame.

- Verify that the bed frame is placed on a flat, even surface.
- Confirm that the legs are compatible with your specific bed frame model (refer to the Compatibility section). Incorrect threading or incompatible frames can lead to instability.

- **Legs Do Not Fit:**
  - Double-check the threading type of your bed frame. These legs use M8 threading.
  - Confirm your bed frame is a compatible Leggett & Platt model and not one of the excluded series (e.g., 50 Series from Mattress Firm, Sealy, or Serta).

9. Specifications

Brand	Leggett & Platt
Model Number	COMIN16JU043475
Height	7 inches (approximate)
Leg Diameter	1.5 inches (approximate)
Threading	M8
Bolt Extension	Approximately 0.5 inches (1/2 inch) above the top of the leg
Glide Height	0.1875 inches (3/16 inch)
Material	Alloy Steel
Finish	Black
Number of Pieces	4
Installation Type	Screw-In
Caster Compatibility	7/16 inch diameter x 1 1/2 inch H Stem casters

10. Warranty & Support

For warranty information or technical support regarding your Leggett & Platt Adjustable Bed Leg Kit, please contact Leggett & Platt customer service directly. Refer to your product packaging or the official Leggett & Platt website for the most current contact details and warranty terms.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question