

Duronic SI2

Duronic SI2 Travel Steam Iron User Manual

Model: SI2

INTRODUCTION

Thank you for choosing the Duronic SI2 Travel Steam Iron. This compact and lightweight iron is designed for convenience, making it an ideal companion for travelers or for quick touch-ups at home. With its 375W power and 50ml water tank, it provides efficient steam ironing for various fabric types. Please read this manual carefully before use to ensure safe and optimal performance.

IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the voltage indicated on the iron matches your local mains voltage (220-240V).
- Do not immerse the iron, cord, or plug in water or other liquids.
- Unplug the iron from the power outlet when filling with water, emptying, or when not in use.
- Do not leave a hot iron unattended.
- Keep the iron and its cord out of reach of children.
- Use the iron only for its intended purpose as described in this manual.
- Do not operate the iron if it has a damaged cord or plug, or if it has been dropped or damaged.
- Always place the iron on a stable, heat-resistant surface.
- Exercise caution when handling hot surfaces and steam.

SETUP

1. **Unpacking:** Carefully remove the iron and all accessories (measuring cup, brush attachment, travel pouch) from the packaging. Inspect for any damage.
2. **First Use Preparation:** Before first use, wipe the soleplate with a damp cloth to remove any manufacturing residue.
3. **Filling the Water Tank:**

Ensure the iron is unplugged. Open the water tank cover located on the top of the iron. Use the provided measuring cup to fill the 50ml water tank with distilled or demineralized water. Do not overfill. Close the water tank cover securely.



Figure 1: Filling the 50ml water tank and location of the steam button.

4. **Connecting to Power:** Plug the iron into a suitable 220-240V power outlet. The indicator light will illuminate, signaling that the iron is heating up.

OPERATING INSTRUCTIONS

1. Temperature Selection:

Rotate the temperature dial on the top of the iron to select the desired heat setting for your fabric. The iron heats up quickly due to its 375W power. Refer to the fabric care labels on your garments for recommended ironing temperatures.



Figure 2: Temperature control dial and rapid heating capability.

- **Low Temperature (approx. 65-110°C):** Suitable for delicate fabrics like silk, synthetics.
- **Medium Temperature (approx. 110-150°C):** Ideal for wool, cotton blends.
- **High Temperature (approx. 150-230°C):** For linen, denim, and other robust fabrics.

2. Steam Function:

Once the iron has reached the selected temperature, press the steam button located on the top of the handle to release a burst of steam. This helps to remove stubborn wrinkles. For continuous steam, ensure the water tank is filled and the iron is at a high enough temperature setting.

3. Using the Brush Attachment:

The included brush attachment can be used for vertical steaming or to remove lint and dust from garments. Attach the brush securely to the soleplate before heating the iron. Use gentle strokes while steaming vertically.



Figure 3: Utilizing the brush attachment for steaming and lint removal.

4. Versatile Applications:

Beyond travel, the Duronic SI2 iron is also perfect for various crafting activities such as quilting, appliqué, and working with fusible beads, offering precision and ease of use for small details.



Figure 4: The compact iron is ideal for travel and various craft projects.

5. Ironing Tips:

- Always iron fabrics from lowest to highest temperature setting to prevent damage.
- For delicate fabrics, iron on the reverse side or use a pressing cloth.
- The non-stick soleplate ensures smooth gliding over various materials.

MAINTENANCE

• Cleaning the Soleplate:

After the iron has cooled down completely, wipe the soleplate with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as these can damage the non-stick coating.

• Draining the Water Tank:

After each use, or before storing, ensure the water tank is emptied. Unplug the iron, allow it to cool, then open the water tank cover and carefully drain any remaining water.

• Storage:

Once the iron is completely cool and dry, wrap the cord around the base. Store the iron in its provided travel pouch in a dry, safe place, away from direct sunlight and moisture.



Figure 5: Storing the iron in its travel pouch for convenience and protection.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet issue; iron malfunction.	Check power connection; try a different outlet; contact customer support if problem persists.
No steam or insufficient steam.	Water tank empty; temperature too low; steam vents clogged.	Fill water tank; increase temperature setting; clean steam vents (refer to maintenance).
Water leaking from soleplate.	Water tank overfilled; temperature too low for steam; iron not hot enough.	Do not overfill; ensure iron is at proper temperature before using steam; allow iron to heat fully.

Problem	Possible Cause	Solution
Soleplate sticking to fabric.	Temperature too high for fabric; soleplate dirty.	Adjust temperature setting; clean soleplate (refer to maintenance).

SPECIFICATIONS

- Brand:** Duronic
- Model Number:** SI2
- Color:** White, Anthracite
- Power:** 375W
- Voltage:** 220-240V
- Water Tank Capacity:** 50 ml
- Product Dimensions (L x W x H):** 13.5 x 7.5 x 0.1 cm
- Item Weight:** 600 g
- Soleplate Material:** Non-stick (Steel)
- Special Features:** Compact and lightweight, includes travel pouch and measuring cup, powerful steam.
- Recommended Uses:** Travel and leisure, sewing, quilting, crafts.



Figure 6: Product dimensions and included accessories.

WARRANTY AND SUPPORT

Duronic products are designed for quality and reliability. For any questions, technical support, or warranty claims, please contact Duronic customer service. Refer to your purchase documentation or the official Duronic website for specific warranty terms and contact information.

Online Support: Visit the official Duronic website for FAQs, product registration, and support resources.

Note: No official product videos were available from the seller for embedding in this manual.

© 2025 Duronic. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question