

Sharpie 35539

SHARPIE Permanent Paint Marker Fine Point Yellow (35539) User Manual

Model: 35539

INTRODUCTION

This manual provides essential instructions for the proper use, maintenance, and care of your Sharpie Permanent Paint Marker Fine Point Yellow (Model 35539). Please read this manual thoroughly before initial use to ensure optimal performance and safety.

SAFETY INFORMATION

- **Flammability:** This product contains flammable components. Keep away from heat, sparks, open flames, and other ignition sources.
- **Ventilation:** Use in a well-ventilated area to avoid inhalation of fumes.
- **Skin and Eye Contact:** Avoid direct contact with skin and eyes. In case of contact, wash thoroughly with soap and water. If irritation persists, seek medical attention.
- **Children:** Keep out of reach of children. This product is not intended for use by children.
- **Disposal:** Dispose of used markers according to local regulations for hazardous waste.

SETUP

Before first use, or if the marker has not been used for an extended period, follow these steps to prepare the marker:

1. **Shake Well:** With the cap on, shake the marker vigorously for approximately 30 seconds to mix the paint thoroughly. You should hear the mixing ball inside.
2. **Prime the Tip:** On a scrap piece of paper or disposable surface, press the marker tip down several times until the paint begins to flow. This may take a few presses.
3. **Test:** Once the paint flows consistently, test the marker on a scrap surface to ensure desired color and flow before applying to your project.



Image: Sharpie Permanent Paint Marker Fine Point Yellow. This image displays the yellow marker with its cap on, showing the brand name and product details printed on the barrel.

OPERATING INSTRUCTIONS

Once primed, the Sharpie Permanent Paint Marker is ready for use on various surfaces.

- **Application:** Apply the marker to the desired surface with steady, even strokes.
- **Drying Time:** Allow adequate drying time for the paint to set, which may vary depending on the surface and environmental conditions.
- **Layering:** For opaque coverage, multiple layers can be applied once the previous layer is dry.
- **Surface Compatibility:** This marker is designed for use on a wide range of surfaces including metal, wood, glass, plastic, and stone.

MAINTENANCE

- **Recap After Use:** Always replace the cap firmly after each use to prevent the paint from drying out.
- **Storage:** Store the marker horizontally at room temperature, away from direct sunlight and extreme temperatures.

- **Cleaning the Tip:** If the tip becomes clogged or dirty, gently wipe it with a clean, damp cloth. Do not use harsh solvents.

TROUBLESHOOTING

- **No Paint Flow:** If paint does not flow, ensure the marker has been shaken well and the tip has been adequately primed by pressing it down multiple times on a scrap surface.
- **Inconsistent Flow:** If the paint flow is inconsistent, re-shake the marker and re-prime the tip. Ensure the surface is clean and dry.
- **Dry Tip:** If the tip appears dry, it may be due to the cap not being replaced properly. Try re-priming the tip. If it remains dry, the marker may be depleted.

SPECIFICATIONS

Feature	Detail
Brand	Sharpie
Model Number	35539 (Sharp.M.35539)
Color	Yellow
Point Type	Fine
Ink Color	Yellow
Material Type	Plastic (Body), Metal (Tip)
Item Weight	8.5 ounces
ASIN	B015G7XWAQ

WARRANTY AND SUPPORT

For specific warranty information or product support, please refer to the official Sharpie website or contact their customer service directly. Retain your purchase receipt as proof of purchase.