

Manuals.plus /

› Verbatim /

› Verbatim 49041 Wireless Blue LED Mouse Instruction Manual

Verbatim 49041

Verbatim 49041 Wireless Blue LED Mouse Instruction Manual

Model: 49041 | Brand: Verbatim

INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your Verbatim 49041 Wireless Blue LED Mouse. Please read these instructions carefully before using the product to ensure optimal performance and longevity.

The Verbatim 49041 Deluxe 8-Button Wireless Mouse features advanced Blue LED technology, enabling precise tracking on a wide variety of surfaces, including glass and granite. Its 2.4 GHz wireless technology ensures a stable and responsive cursor movement without lag. The mouse connects to your computer via a compact nano receiver, designed for convenience and portability. The ergonomic design and easy-grip surface are crafted to provide comfort during extended periods of use.

SETUP INSTRUCTIONS

1. **Insert Batteries:** Open the battery compartment located on the underside of the mouse. Insert the two included AA batteries, ensuring correct polarity. Close the battery compartment securely.

Image: Underside of the Verbatim 49041 mouse with the battery compartment open, showing two AA batteries being inserted. The nano receiver storage slot is also visible.



2. **Connect Nano Receiver:** Locate the nano receiver, typically stored within the mouse's battery compartment or packaged separately. Plug the nano receiver into an available USB port on your computer.

Image: The Verbatim 49041 wireless mouse positioned next to its compact USB nano receiver, ready for connection to a computer.



3. **Power On:** Slide the power switch, usually found on the underside of the mouse, to the "ON" position. Your computer should automatically detect and install the necessary drivers.
4. **Test Functionality:** Move the mouse to confirm cursor movement. If the mouse does not respond, refer to the Troubleshooting section.

OPERATING INSTRUCTIONS

The Verbatim 49041 mouse is designed for intuitive use with its 8-button configuration and advanced tracking technology.

- **Basic Functions:** Use the left and right click buttons for standard selections and context menus. The scroll wheel allows for vertical scrolling through documents and web pages.
- **Blue LED Tracking:** The Blue LED sensor enables the mouse to track accurately on almost any surface, including reflective materials like glass or polished granite, without requiring a mouse pad.
- **8-Button Functionality:** In addition to standard buttons, this mouse features dedicated buttons for enhanced navigation. These buttons can facilitate web browser navigation (forward/back), zoom functions, and quick access to Windows features. Specific button assignments may vary or be customizable via your operating system's mouse settings.
- **DPI Adjustment:** The mouse operates at a sensitivity of 1600 DPI, providing precise control for various

tasks.

Image: Top view of the Verbatim 49041 mouse, highlighting the ergonomic shape, scroll wheel, and multiple buttons for enhanced control.



MAINTENANCE

- **Cleaning:** To clean the mouse, gently wipe its surface with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials. Ensure the optical sensor on the underside is free from dust and debris for optimal tracking.
- **Battery Replacement:** When the mouse performance degrades or stops responding, replace the AA batteries. Always replace both batteries at the same time with new ones.
- **Nano Receiver Storage:** For travel or when the mouse is not in use, store the nano receiver in its dedicated slot within the battery compartment to prevent loss.

TROUBLESHOOTING

Problem	Solution
Mouse not responding	<ul style="list-style-type: none">• Ensure the mouse power switch is in the "ON" position.• Check if the batteries are correctly inserted and have sufficient charge. Replace if necessary.• Verify the nano receiver is securely plugged into a working USB port. Try a different USB port.• Restart your computer.
Erratic cursor movement	<ul style="list-style-type: none">• Clean the optical sensor on the underside of the mouse.• Try using the mouse on a different surface.• Ensure there are no obstructions between the mouse and the nano receiver.
Connectivity issues	<ul style="list-style-type: none">• Move the mouse closer to the nano receiver.• Avoid using the mouse near other wireless devices that may cause interference.• If possible, try the mouse with another computer to determine if the issue is with the mouse or the computer.

SPECIFICATIONS

Model Number	49041
Brand	Verbatim
Connectivity Technology	2.4 GHz Radio-frequency (RF) Wireless
Movement Detection Technology	Blue LED
Max Mouse Sensitivity	1600 DPI (Dots Per Inch)
Number of Buttons	8
Hand Orientation	Ambidextrous
Power Source	Battery Powered
Batteries Required	Yes (2 AA)
Batteries Included	Yes
Compatible Devices	Office computers
Operating System	Windows
Item Weight	82 Grams
Item Dimensions (L x W)	23L x 14W centimeters
Box Contents	Wireless Mouse
Country of Origin	China
UPC / GTIN	023942490418

WARRANTY INFORMATION

Warranty terms and conditions for the Verbatim 49041 Wireless Blue LED Mouse are typically provided at the point of purchase or can be found on the official Verbatim website. Please retain your proof of purchase for any warranty claims. Information regarding spare parts availability and guaranteed software updates is not available in the provided product details.

CUSTOMER SUPPORT

For further assistance, technical support, or to access updated drivers and software, please visit the official Verbatim website. You may also find FAQs and additional resources there to help resolve any issues you encounter.