

[manuals.plus](#) /

› [DBPOWER](#) /

› [DBPOWER 11.5" Portable DVD Player User Manual](#)

DBPOWER CHY-09

DBPOWER 11.5" Portable DVD Player User Manual

MODEL: CHY-09



1. INTRODUCTION

Thank you for purchasing the DBPOWER 11.5" Portable DVD Player. This manual provides essential information for setting up, operating, and maintaining your device. Please read it thoroughly before use to ensure optimal performance and longevity of your player. Keep this manual for future reference.

2. PACKAGE CONTENTS

Please check the package carefully to ensure all items are present and in good condition:

- DBPOWER 11.5" Portable DVD Player
- Remote Control (with batteries)
- AC Power Adapter
- Car Charger (1.8M)
- AV Cable
- Car Headrest Mount



Image: Included accessories with the DBPOWER Portable DVD Player.

3. PRODUCT OVERVIEW

3.1 Main Unit

The DBPOWER Portable DVD Player features an 11.5-inch overall size with a 9-inch swivel screen. The screen can rotate 270 degrees and flip 180 degrees, allowing for versatile viewing angles and tablet-like usage.



Image: Front view of the DBPOWER Portable DVD Player with remote and carrying case.

Three Power Systems



Car Charger



AC Adapter(12V)



Built-in Battery
(2500mAh 5 hours)



Image: The swivel screen functionality of the portable DVD player.

3.2 Controls and Ports

Familiarize yourself with the buttons and ports on the device for easy operation. These typically include power, volume, playback controls, disc tray, USB port, SD card slot, AV output, and headphone jack.

4. SETUP

4.1 Initial Charging

Before first use, fully charge the built-in 2500 mAh lithium battery using the provided AC power adapter. Connect the adapter to the DC IN port on the player and plug it into a wall outlet. The charging indicator light will typically change color or turn off when fully charged.

4.2 Powering On/Off

Press and hold the Power button to turn the player on or off.

4.3 Inserting a Disc

Gently open the disc cover. Place the DVD or CD onto the spindle with the label side facing up. Press down lightly on the center of the disc until it clicks into place. Close the disc cover firmly.

4.4 Connecting to a TV

To view content on a larger screen, connect the player to a TV using the supplied AV cable. Connect the yellow, white, and red plugs from the AV cable to the corresponding input jacks on your TV. Select the correct AV input source on your TV.



Sync Screen to TV

Share Happiness on a Bigger Screen

Image: Connecting the portable DVD player to a television.

5. OPERATING INSTRUCTIONS

5.1 Basic Playback

Once a compatible disc is inserted, the player will typically begin playback automatically. Use the Play/Pause, Stop, Next, and Previous buttons on the player or remote control to manage playback.

5.2 Using the Remote Control

The included remote control provides full functionality for navigating menus, adjusting settings, and controlling playback from a distance. Ensure batteries are correctly inserted.

5.3 Last Memory Function

The player features a break-point memory function, which allows it to resume playback from where you left off, even after the device has been powered off. This feature is enabled by default.



6. MULTIMEDIA SUPPORT

Your DBPOWER Portable DVD Player supports a wide range of media formats:

- **Disc Formats:** CD, DVD, CD-R/RW, DVD-R/+R, DVD+RW/-RW, VCD, SVCD (Note: Does not support Blu-ray DVDs).
- **USB & SD Card:** Supports up to 32GB USB drives and SD cards.
- **Audio Formats:** MP3, WMA, WAV.
- **Image Formats:** JPEG.
- **Video Formats:** MPEG2, AVI, DIVX.



Image File Format: JPG



Audio File Formats: MP3/ MP4/ WMA



Video File Formats:
VOB/ AVI/ MPEG 1/ MPEG 2/ MPEG 4/ DIVX
(Resolution should be under 720*576)



Disc Formats:
CD/DVD/CD-R/CD-RW/DVD-R/DVD+
R/DVD+RW/DVD-RW/VCD/SVCD(Not blu-ray DVD)



Multiple Media Support

Image: Supported multimedia formats for the portable DVD player.

7. POWER OPTIONS

The DBPOWER Portable DVD Player offers flexible power options for various scenarios:

- **Built-in Rechargeable Battery:** A 2500 mAh lithium battery provides approximately 5 hours of continuous playback.

- **AC Power Adapter:** Use the included AC adapter for home use and charging.
- **Car Charger:** The 1.8M car charger allows you to power the device and charge it while on the go, perfect for road trips.



Image: The three power options available for the portable DVD player.

8. MAINTENANCE

Proper care will extend the life of your DVD player:

- **Cleaning:** Use a soft, dry cloth to clean the screen and exterior. For stubborn smudges, a slightly damp cloth can be used, followed by a dry one. Do not use abrasive cleaners or solvents.
- **Disc Care:** Handle discs by their edges. Clean discs with a soft, lint-free cloth wiping from the center outwards.
- **Storage:** Store the player in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, ensure the battery is partially charged (around 50%) to preserve its lifespan.
- **Avoid Liquids:** Keep the device away from water and other liquids.

9. TROUBLESHOOTING

If you encounter issues with your DBPOWER Portable DVD Player, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|----------------------------------|--|--|
| Player does not power on. | Low battery; Power adapter not connected or faulty. | Charge the battery; Ensure power adapter is securely connected and working. |
| No disc playback. | Disc is dirty, scratched, or incompatible format; Disc inserted incorrectly. | Clean the disc; Check for scratches; Ensure disc is compatible (not Blu-ray); Reinsert disc correctly. |
| No sound. | Volume too low or muted; Headphones not fully plugged in; Speaker issue. | Increase volume; Check mute setting; Ensure headphones are fully inserted; Test with different headphones or speakers. |
| Remote control not working. | Batteries are dead or inserted incorrectly; Obstruction between remote and player. | Replace batteries; Ensure correct polarity; Remove any obstructions. |
| Picture distorted or no picture. | Disc issue; AV cable loose or faulty (when connected to TV). | Clean or replace disc; Check AV cable connections. |

10. SPECIFICATIONS

| Feature | Specification |
|--------------------|--|
| Product Dimensions | 9.45 x 7.09 x 1.57 inches |
| Item Weight | 2.54 pounds |
| Model Number | CHY-09 |
| Screen Size | 9.5 Inches (diagonal) |
| Display Type | LCD |
| Battery | 1 Lithium Metal battery (2500 mAh, approx. 5 hours playback) |

| Feature | Specification |
|----------------------|--------------------------------|
| Media Type Supported | DVD-R, SVCD, DVD-RW, VCD, CD-R |
| Color | Blue |

11. WARRANTY AND SUPPORT




DBPOWER is committed to providing high-quality products and customer satisfaction. Your portable DVD player comes with:

- **12 Months Exchange & Return:** For any manufacturing defects or performance issues within 12 months of purchase.
- **12 Months Technical Support:** Assistance with setup, operation, and troubleshooting for one year.
- **24 Hours Customer Service:** Dedicated support available to answer your queries.

For support, please refer to the contact information provided on the DBPOWER official website or your purchase platform. Please have your model number (CHY-09) and purchase details ready when contacting support.

© 2025 DBPOWER. All rights reserved.


Related Documents - CHY-09

| | |
|---|--|
|  | <p><u>DBPOWER Portable Video Player User Manual</u></p> <p>User manual for the DBPOWER Portable Video Player, covering features, safety instructions, panel keys, remote control functions, general setup, playback, specifications, troubleshooting, and warranty exclusions.</p> |
|  | <p><u>DBPOWER CHY-09 Portable Video Player User Manual</u></p> <p>User manual for the DBPOWER CHY-09 portable video player, covering features, safety instructions, panel keys, remote control functions, setup, playback, specifications, troubleshooting, and warranty exclusions.</p> |
|  | <p><u>DBPOWER ZC-01 Multimedia Player User Manual</u></p> <p>User manual for the DBPOWER ZC-01 Multimedia Player. Covers safety, setup, operation, features, settings, technical specs, and troubleshooting.</p> |



[DBPOWER Portable DVD Player Inventory and Features](#)

An overview of the DBPOWER Portable DVD Player, detailing its included accessories and specifications. This document lists the items that come with the portable DVD player, such as the player itself, manual, car charger, AV cable, power adapter, remote, headrest mount, and batteries. It also notes that the device is not Blu-ray compatible.



[DBPOWER Portable Video Player Quick User Guide](#)


A quick user guide for the DBPOWER Portable Video Player, covering setup, controls, disc formats, and maintenance.



[DBPOWER PD-928 Portable Video Player User Manual](#)

This user manual provides comprehensive instructions for operating the DBPOWER PD-928 portable video player, covering features, setup, safety precautions, troubleshooting, and warranty information.

Documents - DBPOWER – CHY-09



[DBPOWER CHY-09 Portable Video Player User Manual](#)

User manual for the DBPOWER CHY-09 portable video player, covering features, safety instructions, panel keys, remote control functions, setup, playback, specifications, troubleshooting, and warranty exclusions.

lang: score:32 filesize: 1.88 M page_count: 36 document date: 2022-09-01