i-rocks IRK32W

I-Rocks IRK32W Washable Keyboard Instruction Manual

Model: IRK32W | Brand: i-rocks

1. SAFETY INFORMATION

Please read all safety instructions carefully before using this product. Failure to follow these instructions may result in damage to the product or personal injury.

- Ensure the keyboard is completely dry before connecting it to a computer or any power source.
- Do not immerse the USB connector in water or any other liquid.
- Avoid using harsh chemicals or abrasive materials for cleaning, as this may damage the keyboard's surface or key legends.
- Keep the keyboard away from extreme temperatures and direct sunlight.
- This product is designed for general office and home use. Do not use it for purposes other than its intended use.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- I-Rocks IRK32W Washable Keyboard
- Cleaning Brush

3. SETUP

The I-Rocks IRK32W Washable Keyboard is designed for simple plug-and-play functionality, requiring no additional drivers for most Windows-based PCs.

1. Unpack the keyboard from its packaging.
2. Locate an available USB port on your computer.
3. Plug the keyboard's USB connector into the USB port.
4. Your operating system should automatically detect and install the necessary drivers. The keyboard will be ready for use shortly.

Figure 3.1: Top-down view of the I-Rocks IRK32W Washable Keyboard, showing its full layout and wired USB connection.

4. OPERATING INSTRUCTIONS

The I-Rocks IRK32W functions as a standard full-size keyboard. Its durable keys with laser printing ensure longevity and clear visibility.

- **Typing:** Use the keys as you would on any standard keyboard. The layout includes a full alphanumeric section, function keys (F1-F12), navigation keys, and a numeric keypad.
- **Adjustable Foot-Stand:** For comfortable typing, the keyboard features adjustable foot-stands on the underside. Flip them out to raise the rear of the keyboard to your preferred angle.

5. MAINTENANCE AND CLEANING

A key feature of the I-Rocks IRK32W is its hand-washable design, making it easy to keep clean and hygienic. The keyboard is designed with drainage holes to facilitate drying.

1. **Disconnect:** Always disconnect the keyboard from your computer before cleaning.
2. **Washing:** The keyboard can be hand-washed under running water. You may use mild soap if necessary.
3. **Brushing:** Use the provided cleaning brush to remove debris and dirt from between the keys and other hard-to-reach areas.
4. **Rinsing:** Rinse thoroughly with clean water to remove any soap residue.

5. **Drying:** Shake off excess water. Allow the keyboard to air dry completely before reconnecting it to your computer. Ensure all internal components are dry to prevent electrical damage.

Figure 5.1: The keyboard's washable design allows for direct rinsing under water to remove spills and dirt.

Figure 5.2: The keyboard can be thoroughly cleaned in a sink, demonstrating its waterproof capabilities.

Figure 5.3: A cleaning brush, included with the keyboard, is used to effectively remove debris from between the keys.

6. TROUBLESHOOTING

If you encounter issues with your I-Rocks IRK32W keyboard, try the following steps:

- **No Response:** Ensure the USB connector is securely plugged into a functioning USB port on your computer. Try plugging it into a different USB port.
- **Keys Not Working:** If individual keys are unresponsive, ensure the keyboard is clean and dry. Check for any physical obstructions under the keycaps.
- **Computer Not Recognizing:** Restart your computer. This can often resolve driver recognition issues.
- **Intermittent Connection:** Check the USB cable for any visible damage. Ensure the cable is not bent or kinked excessively.

7. Specifications

Feature	Detail
Brand	i-rocks
Model Number	IRK32W-BK
Connectivity Technology	USB
Compatible Devices	PC (Windows)
Special Features	Slim design, Hand-washable, Durable keys with laser printing, Adjustable foot-stand, Cleaning brush
Color	Black
Item Weight	1.65 pounds
Product Dimensions	18.31 x 1.27 x 6.84 inches
Material	Plastic

8. Warranty

For detailed warranty information regarding your I-Rocks IRK32W Washable Keyboard, please refer to the documentation included with your purchase or visit the official i-rocks website. Warranty terms and conditions may vary by region and retailer.

9. Support

If you require further assistance or have questions not covered in this manual, please contact i-rocks customer support. Contact information can typically be found on the manufacturer's official website or on the product packaging.