## Manuals+

Q & A | Deep Search | Upload

## manuals.plus /

- iTouchless /
- > iTouchless 50 Liter / 13 Gallon Open Top Kitchen Trash Can with Double AbsorbX Odor Filters, Model OL13STV User Manual

# iTouchless OL13STV

# iTouchless 50 Liter / 13 Gallon Open Top Kitchen Trash Can User Manual

Model: OL13STV

## Introduction

Thank you for choosing the iTouchless 50 Liter / 13 Gallon Open Top Kitchen Trash Can. This manual provides essential information for the proper setup, operation, and maintenance of your new trash can. Please read these instructions carefully to ensure optimal performance and longevity of the product.






Image: The iTouchless 50 Liter / 13 Gallon Open Top Kitchen Trash Can, showcasing its sleek stainless steel design and oval shape.

# **S**ETUP

# 1. Unpacking and Component Check

Carefully remove all components from the packaging. Verify that all parts are present:

- 1 x Trash Can Body (Stainless Steel)
- 1 x Open Top Lid
- 2 x AbsorbX Odor Filters

# 2. AbsorbX Odor Filter Installation

The trash can includes two AbsorbX Odor Filters designed to absorb and neutralize garbage odors. Install them as follows:

- 1. Locate the filter compartments on the underside of the lid.
- 2. Insert one AbsorbX Odor Filter into each compartment. Ensure they are securely seated.



Image: Diagram illustrating the placement of AbsorbX Odor Filters within the lid of the trash can to control odors.

## 3. Trash Bag Installation

This trash can is designed to fit standard tall kitchen trash bags (13-gallon or 50-liter capacity).

- 1. Lift the open top lid from the trash can body.
- 2. Place a trash bag into the can, ensuring the top edge of the bag is folded over the rim of the can body.
- 3. Carefully place the lid back onto the can, securing the trash bag in place. The lid's design helps conceal the bag for a neat appearance.



Image: A close-up view demonstrating how to effortlessly remove a full trash bag from the can, highlighting the air vents that prevent vacuum sealing.

#### 4. Placement

Position the trash can in your desired location. Its space-saving oval design allows it to fit snugly against walls or cabinets. The can also features a handle on one side for easy relocation.



Image: The iTouchless trash can positioned in a kitchen, demonstrating its space-saving design and how it fits neatly into various spaces.

## **OPERATING INSTRUCTIONS**

# 1. Waste Disposal

The open-top design provides quick and easy access for waste disposal. Simply drop items into the wide opening. The generous opening accommodates bulky waste, reducing the need to touch the can.



Image: An illustration highlighting the extra-wide opening of the trash can, designed for easy disposal of larger items.

# 2. Bag Removal

When the trash bag is full, lift the lid and remove the bag. The integrated air vents prevent a vacuum seal, making full bag removal effortless.

#### MAINTENANCE

## 1. Cleaning the Trash Can

The stainless steel exterior is fingerprint-proof, smudge-resistant, and rust-resistant. To clean:

- Wipe the exterior with a damp cloth and a mild, non-abrasive cleaner.
- Dry thoroughly with a soft cloth to prevent water spots.
- For the interior, if soiled, wipe with a damp cloth and disinfectant, then dry completely.



Image: A close-up of the trash can's premium grade stainless steel finish, highlighting its easy-to-clean and durable properties.

## 2. AbsorbX Odor Filter Replacement

AbsorbX Odor Filters are effective for approximately 3 months. Replace them regularly to maintain optimal odor control.

- 1. Remove the old filters from their compartments on the underside of the lid.
- 2. Insert new AbsorbX Odor Filters into the compartments.

You can sign up for a free text message reminder service to be notified when it's time to replace your filters.



Image: A visual representation of the dual AbsorbX Odor Filters, showing how they are inserted and their activated carbon composition.

# **T**ROUBLESHOOTING

If you encounter any issues with your iTouchless trash can, please refer to the following common solutions:

- Odor Persistence: Ensure AbsorbX Odor Filters are correctly installed and not expired. Replace filters every 3 months for optimal performance.
- **Trash Bag Slippage:** Verify that the trash bag is properly secured under the lid's rim. The lid should sit flush on the can body, holding the bag in place.
- Lid Not Fitting Securely: Check for any obstructions around the rim of the can or the underside of the lid. Ensure the lid is aligned correctly before placing it on the body.

For further assistance, please contact iTouchless customer support.

## **S**PECIFICATIONS

Feature	Detail
Brand	iTouchless
Model Number	OL13STV
Capacity	50 Liters / 13 Gallons
Dimensions (L x W x H)	11.5" x 16.2" x 24.4" (29.2 cm x 41.1 cm x 62 cm)
Opening Mechanism	Open-Top
Material	Stainless Steel
Color	Silver
Special Features	Dual AbsorbX Odor Filters, Fingerprint-Proof, Smudge-Resistant, Rust-Resistant, Easy to Clean, ADA & OSHA Compliant Design
Item Weight	7.7 pounds (3.5 kg)
UPC	897112000604



Image: A visual representation of the iTouchless trash can with its key dimensions labeled for reference.

# WARRANTY AND SUPPORT

iTouchless products are designed for durability and performance. For specific warranty details, please refer to the warranty card included with your product or visit the official iTouchless website.

If you require technical support, have questions about your product, or need to order replacement parts (such as AbsorbX Odor Filters), please contact iTouchless customer service:

- Website: www.itouchless.com
- Email: Refer to the website for contact email.
- Phone: Refer to the website for customer service phone number.



## iTouchless 13 Gallon AutoStep Stainless Steel Trash Can User Manual

Comprehensive user manual for the iTouchless 13 Gallon AutoStep Stainless Steel Trash Can (models ITA13SB, ITA13SR, ITA13SW). Learn about its features including the automatic sensor lid, odor control system, battery and AC power options, proper operation, care and maintenance, troubleshooting, and warranty information.



#### iTouchless Sensor Trash Can User Manual MT02SS MT02SW MT04SS MT04SW

User manual for iTouchless MT02SS, MT02SW, MT04SS, MT04SW sensor trash cans. Covers features, setup, operation, maintenance, troubleshooting, and warranty information.



## iTouchless 13 Gallon Stainless Steel Sensor Trash Can User Manual

User manual for the iTouchless 13 Gallon Stainless Steel Sensor Trash Can (Model DZT13P). Learn about its features, operation, troubleshooting, and warranty.



## iTouchless 18 & 23 Gallon Stainless Steel Sensor Trash Can User Manual

User manual for the iTouchless 18 and 23 Gallon Round Stainless Steel Sensor Trash Can with Dual Deodorizers. Provides information on features, contents, operation, filter replacement, troubleshooting, and warranty.



## iTouchless WS13RSL/WS18RSL Sensor Trash Can User Manual

Comprehensive user manual for the iTouchless WS13RSL and WS18RSL sensor trash cans, detailing features, setup, operation, maintenance, troubleshooting, and warranty information.



## iTouchless 4 Gallon Slim Sensor Trash Can User Manual (SG04SSL/SG04SSR)

User manual for the iTouchless 4 Gallon Slim Sensor Trash Can (models SG04SSL and SG04SSR). Learn about its features, operation, maintenance, troubleshooting, and warranty.



# [pdf] User Manual

iTouchless OL1316STV User Manual 04 2021 C1XwFT6GPjL m media amazon images I ||| Touch less, do more TM User Manual 13 / 16 Gallon Stainless Steel Elliptical Open Top Trash Can **OL13STV** / OL16STV itouchless.com 844.660.7978 **OL13STV** OL16STV We re here to help If you have any questions or concerns about this product, please contact iTouchless Customer Support for immediate... lang:en score:47 filesize: 5.66 M page\_count: 6 document date: 2021-04-13