

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Moretti](#) /
- › [Moretti Sliced Cured Tongs Instruction Manual](#)

## Moretti 1

# Moretti Sliced Cured Tongs Instruction Manual

Model: 1 | Brand: Moretti

## INTRODUCTION

The Moretti Sliced Cured Tongs are a specialized tool designed for hygienic and easy handling of sliced cured meats. Crafted entirely from high-quality stainless steel, these tongs provide a convenient way to pick up delicate slices from a slicer, tray, or serving platter without direct hand contact. Their ergonomic design ensures a secure grip and precise control, making them an essential accessory for both professional delicatessens and home users.



Image: The Moretti Sliced Cured Tongs, showcasing their stainless steel construction and ergonomic design. A small paper bag with the Moretti logo is visible in the background, indicating product packaging.

## SAFETY INFORMATION

---

Please read all safety instructions before using the Moretti Sliced Cured Tongs. Failure to follow these instructions may result in injury or damage to the product.

- **Sharp Edges:** If the product is broken or damaged, sharp edges and pointed parts may cause injuries. Inspect the tongs before each use.
- **Not a Toy:** This product is not a toy. Keep out of reach of children.
- **Choking Hazard:** The product and its packaging may contain small detachable parts or plastic bags that, if swallowed or improperly used by children, can pose a choking hazard. Remove all packaging components before use and dispose of them properly.
- **Intended Use:** This product is intended for permitted use only, specifically for handling sliced cured meats. The manufacturer and distributor are not responsible for any improper use of the product.
- **Food Contact:** The product is suitable for direct contact with food.



Image: A technical data sheet for the Moretti Sliced Cured Tongs, displaying product information, warnings, and contact details in Italian and English. This sheet emphasizes safety and proper use.

## SETUP

---

Before first use, and after each subsequent use, thoroughly wash the Moretti Sliced Cured Tongs. Refer to the 'Maintenance' section for detailed cleaning instructions.

## OPERATING INSTRUCTIONS

---

The Moretti Sliced Cured Tongs are designed for simple and effective use:

1. **Grip:** Hold the tongs comfortably in your hand. The spring mechanism allows for easy opening and closing.



2. **Approach:** Position the tongs over the desired slice of cured meat.
3. **Grasp:** Gently press the handles together to close the tongs around the slice. The ergonomic design ensures a secure grip without damaging the delicate meat.
4. **Transfer:** Carefully lift the slice and transfer it to a serving plate, tray, or directly onto a sandwich.
5. **Release:** Release the pressure on the handles to open the tongs and release the slice.



Image: The Moretti Sliced Cured Tongs positioned on a wooden board next to various types of cured meats, including sliced salami and prosciutto. This illustrates the product's intended use in a kitchen or deli setting.

## MAINTENANCE

Proper cleaning and maintenance will ensure the longevity and hygienic performance of your Moretti Sliced Cured Tongs.

- **Cleaning:** Wash the tongs thoroughly by hand using warm water and a mild dish soap. Rinse completely to remove all soap residue.
- **Drying:** Dry the tongs immediately after washing with a soft cloth to prevent water spots and maintain the polished finish.
- **Dishwasher Safety:** This product is **not** dishwasher-safe. Hand washing is recommended to preserve the material and finish.
- **Storage:** Store the tongs in a clean, dry place when not in use.

## TROUBLESHOOTING

If you encounter any issues with your Moretti Sliced Cured Tongs, consider the following:

- **Difficulty Gripping:** Ensure the tongs are clean and free of any food residue that might impede the grip.
- **Stiffness:** If the spring mechanism feels stiff, ensure no debris is lodged in the hinge area. A thorough cleaning may resolve this.

- **Damage:** If the tongs appear bent, broken, or have sharp edges, discontinue use immediately to prevent injury.

## SPECIFICATIONS

Brand	Moretti
Model Number	1
Material	Stainless Steel (AISI 304 / 1.4301)
Color	Steel
Product Dimensions	11 x 6 x 1 cm
Item Weight	60 g
Dishwasher Safe	No
Manufacturer	Salumificio Moretti

## WARRANTY AND SUPPORT

For information regarding warranty coverage, product support, or to report any issues not covered in this manual, please contact the retailer where the product was purchased or refer to the official Moretti website for manufacturer contact details.