

DUNLOP 871125222756

DUNLOP Volleyball Set with Ball and Pump, Model 871125222756 Instruction Manual

1. INTRODUCTION

Thank you for choosing the DUNLOP Volleyball Set. This set is designed for recreational outdoor volleyball, suitable for gardens, beaches, or campsites. This manual provides essential information for the safe and correct assembly, operation, and maintenance of your volleyball set. Please read these instructions carefully before use and retain them for future reference.

2. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Volleyball Net (609 cm long, 220 cm high)
- Net Poles (2 pieces)
- Tension Ropes (4 pieces)
- Ground Stakes (4 pieces)
- Volleyball (1 piece)
- Ball Pump with Needle (1 piece)
- Carrying Bag (1 piece)

3. SETUP INSTRUCTIONS

3.1 Inflating the Volleyball

1. Locate the inflation needle, usually stored within the handle of the pump.
2. Carefully screw the needle into the pump nozzle.
3. Moisten the needle with a drop of water or saliva before inserting it into the ball's valve. This prevents damage to the valve.

4. Insert the needle straight into the valve.
5. Pump air into the ball until it is firm but not overinflated. Avoid over-pumping to prevent damage.
6. Remove the needle carefully.



Image 1: The DUNLOP volleyball and pump. The pump is green with a black handle, and the ball is white with the DUNLOP logo.

3.2 Assembling the Net

1. Choose a flat, open area for setup, ensuring sufficient space around the net for play.
2. Assemble the two net poles by connecting the sections. Ensure they are securely locked.
3. Slide the net onto the assembled poles. The net has sleeves on the sides for the poles.
4. Insert the bottom of each pole firmly into the ground. For softer ground, consider digging a small hole for stability.
5. Attach the tension ropes to the top corners of the net/poles.
6. Extend the tension ropes outwards at an angle (approximately 45 degrees) and secure them to the ground using the ground stakes. Ensure the stakes are driven deep enough to provide firm anchorage.
7. Adjust the tension of the ropes to make the net taut and upright. The net should be approximately 220 cm high at the center.



Image 2: The DUNLOP volleyball net fully extended and ready for setup. The net features a green top border with the DUNLOP logo.

4. OPERATING INSTRUCTIONS

Once the net is securely set up and the ball is inflated, the DUNLOP Volleyball Set is ready for play. Ensure all players understand basic volleyball rules and safety guidelines. Always supervise children during play.

- **Playing Area:** Ensure the playing area is clear of obstacles and hazards.
- **Net Tension:** Periodically check the net tension during play and re-tighten ropes if necessary to maintain proper height and stability.
- **Ball Pressure:** Maintain optimal ball pressure for best performance. Re-inflate if the ball feels soft.

5. MAINTENANCE

5.1 Cleaning

- **Net and Poles:** Wipe down with a damp cloth to remove dirt and debris. For stubborn stains, use mild soap and water. Rinse thoroughly and allow to air dry completely before storage.
- **Volleyball:** Clean the ball with a damp cloth. Avoid harsh chemicals that may damage the ball's surface.

5.2 Storage

To prolong the life of your volleyball set, proper storage is essential:

- Disassemble the net and poles after each use or when not in use for extended periods.
- Deflate the volleyball slightly before storing to reduce stress on the seams.

- Store all components in the provided carrying bag.
- Keep the set in a cool, dry place, away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Net sags or is unstable.	Loose tension ropes; ground stakes not secure; poles not firmly planted.	Re-tighten tension ropes; ensure ground stakes are fully driven into firm ground; check pole connections and stability.
Volleyball does not inflate.	Needle not properly inserted; valve obstruction; damaged valve or ball.	Ensure needle is fully and straightly inserted; check for debris in valve; if damaged, replacement may be necessary.
Poles do not connect securely.	Debris in connection points; bent pole section.	Clean connection points; inspect for damage and straighten if possible.

7. SPECIFICATIONS

Feature	Detail
Brand	DUNLOP
Model Number	871125222756
Net Dimensions (L x H)	609 cm x 220 cm (approx. 20 ft x 7.2 ft)
Material	Polyester (Net)
Color	Green (Net trim)
Item Weight	1.6 Kilograms
Sport Type	Volleyball
Included Components	Volleyball net, poles, tension ropes, ground stakes, volleyball, pump, carrying bag

8. SAFETY INFORMATION

- Always set up the net on a level surface, clear of any obstacles or hazards.
- Ensure all poles and stakes are securely anchored to prevent collapse during play.
- Do not hang or climb on the net or poles.
- Keep small children and pets away from the setup area during assembly and disassembly.
- Inspect all components for wear or damage before each use. Do not use if any part is broken or compromised.
- This product is intended for recreational use only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question