

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [JETBeam](#) /

› [JETBeam MS-R28 Military Flashlight User Manual](#)

JETBeam MS-R28

JETBeam MS-R28 Military Flashlight User Manual

Model: MS-R28

1. PRODUCT OVERVIEW

The JETBeam MS-R28 is a robust military-grade flashlight designed for reliability and performance. It features advanced LED technology, durable construction, and user-friendly functionalities suitable for various demanding environments.



Figure 1: JETBeam MS-R28 Military Flashlight. This image displays the flashlight's full body, highlighting its black finish and textured grip. The JETBeam brand logo and MS-R28 model number are clearly visible on the side of the head.

2. SAFETY INFORMATION

- Do not look directly into the light beam. The high intensity light can cause temporary vision impairment or permanent eye damage.

- Keep out of reach of children.
- Do not disassemble the sealed head of the flashlight. Doing so may cause damage to the flashlight and will void the warranty.
- Use only recommended batteries. Incorrect battery types may cause damage or explosion.
- Ensure proper battery polarity during installation.
- Avoid dropping the flashlight or subjecting it to severe impacts.
- Do not expose the flashlight to extreme temperatures or open flames.

3. PACKAGE CONTENTS

Please check the package contents upon opening to ensure all items are present and in good condition.

- JETBeam MS-R28 Military Flashlight (1 unit)
- User Manual (This document)
- Lanyard (if included in specific package variant)
- Spare O-rings (if included)
- USB Charging Cable (if included)

4. SETUP

4.1 Battery Installation

The JETBeam MS-R28 requires a compatible rechargeable battery (not included). Ensure the battery is fully charged before first use.

1. Unscrew the tail cap of the flashlight by turning it counter-clockwise.
2. Insert the battery with the positive (+) terminal facing towards the head of the flashlight.
3. Screw the tail cap back on clockwise until it is securely tightened. Ensure the O-ring is properly seated to maintain waterproofing.

4.2 Initial Charge

If your MS-R28 model supports USB charging, it is recommended to fully charge the battery before initial use to ensure optimal performance and battery longevity.

- Locate the USB charging port, typically covered by a rubber seal near the head of the flashlight.
- Open the rubber seal and connect the provided USB charging cable to the port.
- Connect the other end of the USB cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
- The indicator light will show charging status (refer to Section 6 for details).
- Once charging is complete, disconnect the cable and securely close the rubber seal to maintain waterproofing.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- To turn the flashlight **ON**: Press the power button located on the side or tail cap (depending on model variant) until the light illuminates.
- To turn the flashlight **OFF**: Press the power button again.

5.2 Mode Selection

The MS-R28 typically features multiple brightness levels and special modes. The method for cycling through modes may vary slightly by specific production batch, but generally involves the following:

- With the flashlight **ON**, press and hold the power button to cycle through brightness levels (e.g., Low, Medium, High, Turbo). Release the button to select the desired brightness.
- For special modes (e.g., Strobe, SOS): Double-press the power button rapidly to activate Strobe mode. Double-press again for SOS mode. Press once to return to the last used brightness level.

5.3 Battery Life Indicator

The power button on the MS-R28 features a built-in flash indicator to denote battery life. The specific color or flash pattern will indicate the remaining power level:

- Solid Green/Blue:** Sufficient power remaining.
- Flashing Yellow/Orange:** Medium power, consider recharging soon.
- Flashing Red:** Low power, immediate recharge required.

Note: Specific indicator colors may vary slightly. Refer to the quick start guide included with your specific product for exact details if different.

6. CHARGING

The JETBeam MS-R28 features USB-charger capabilities for convenient recharging of its internal battery.

- Ensure the flashlight is turned OFF before charging.
- Locate the USB charging port, typically protected by a rubber cover to maintain waterproofing.
- Carefully lift the rubber cover to expose the USB port.
- Insert the micro-USB end of the charging cable into the flashlight's port.
- Connect the standard USB-A end of the cable to a 5V USB power adapter or a computer's USB port.
- The power button indicator light will typically illuminate red or orange during charging and turn green or blue when charging is complete.
- Once fully charged, disconnect the USB cable and firmly press the rubber cover back into place to ensure the waterproofing seal is intact.

7. MAINTENANCE

7.1 Cleaning

- Wipe the flashlight body with a clean, damp cloth. Do not use abrasive cleaners or solvents.
- Clean the threads of the tail cap and head regularly. Apply a thin layer of silicone grease to the O-rings to maintain waterproofing and smooth operation.
- Keep the lens clean. Use a lens cleaning cloth or cotton swab with a small amount of rubbing alcohol if necessary.

7.2 Storage

- Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, remove the battery to prevent leakage and damage to the flashlight.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	Battery is depleted. Battery inserted incorrectly. Loose tail cap. Dirty contacts.	Recharge or replace battery. Ensure positive (+) terminal faces the head. Tighten tail cap securely. Clean battery contacts and flashlight contacts with a clean cloth.
Light flickers or is dim.	Low battery. Loose components. Dirty contacts.	Recharge battery. Ensure tail cap and head are tightened. Clean battery contacts and flashlight contacts.
Water ingress after exposure.	Rubber seals (O-rings) are damaged or improperly seated. USB port cover not fully sealed.	Inspect O-rings for damage; replace if necessary. Apply silicone grease. Ensure USB port cover is firmly pressed into place.

9. SPECIFICATIONS

Model Number	MS-R28
Brand	JETBeam
Product Dimensions	19 x 5 x 5 cm
Item Weight	1 kg (2.2 lbs)
Colour	Black
Bulb Type	LED
Waterproofing	IPX-6 (Resistant to high-pressure, heavy sprays of water)
Charging Capability	USB-charger capabilities
Battery Indicator	Flash indicator on power button denotes battery life
Thermal Management	Optimized thermal heat fins
Included Components	Jetbeam MS-R28 Military Flashlight Black (and potentially USB cable, lanyard, spare O-rings depending on package)

10. WARRANTY AND SUPPORT

JETBeam products are manufactured to high quality standards. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official JETBeam website.

For technical support, service, or inquiries regarding your JETBeam MS-R28 Military Flashlight, please contact your authorized dealer or the manufacturer's customer service department. Contact information can typically be found on the product packaging or the official brand website.

- **Manufacturer:** Sportsman Supply Inc.
- **Brand Website:** www.jetbeam.com (Note: This is a general placeholder for a brand website, actual URL may vary or not exist)

© 2023 JETBeam. All rights reserved.

This manual is for informational purposes only and is subject to change without notice.