

Braun 3210-652

Braun 3210-652 Universal Food Processor Work Bowl

INSTRUCTION MANUAL

Product Overview

This document provides instructions for the Braun 3210-652 Universal Food Processor Work Bowl. This is an Original Equipment Manufacturer (O.E.M.) authorized replacement part designed for specific Braun food processor models. It is manufactured in the United States.

Compatible Models: 3066, 3067, 3093, 3094, 3111, 3112, KF140, KF149.



Image: The Braun 3210-652 Universal Food Processor Work Bowl, a clear plastic bowl with a central mechanism.

Setup and Installation

- Unpacking:** Carefully remove the work bowl from its packaging. Inspect for any damage.
- Initial Cleaning:** Before first use, wash the work bowl with warm, soapy water. Rinse thoroughly and dry.
- Placement:** Position the work bowl onto the motor base of your compatible Braun food processor. Ensure the bowl is seated correctly and securely locked into place according to your food processor's main instruction manual. A click or firm seating usually indicates proper installation.
- Lid Attachment:** Once the bowl is in place, attach the food processor lid. The food processor will not operate unless both the bowl and lid are correctly assembled and locked.

Operating Guidelines

This work bowl functions as the primary container for processing ingredients within your Braun food processor. Refer to your food processor's main instruction manual for specific operating procedures, safety precautions, and recommended processing times for various foods.

- **Capacity:** Do not overfill the work bowl beyond the maximum fill line indicated on your food processor or the bowl itself. Overfilling can lead to inefficient processing and potential damage.
- **Secure Lid:** Always ensure the lid is securely locked onto the work bowl before operating the food processor.
- **Blade/Disc Installation:** Install the appropriate blade or disc into the work bowl's central shaft before adding ingredients and attaching the lid.

Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your work bowl.

- **Immediate Cleaning:** Clean the work bowl immediately after each use to prevent food residue from drying and becoming difficult to remove.
- **Hand Washing:** Wash the work bowl with warm, soapy water using a soft sponge or cloth. Rinse thoroughly under running water.
- **Dishwasher Use:** The work bowl is generally dishwasher-safe. Place it on the top rack to avoid potential damage from heating elements. Avoid using harsh or abrasive detergents.
- **Drying:** Allow the work bowl to air dry completely or dry with a soft cloth before storing.
- **Storage:** Store the work bowl in a clean, dry place, away from direct sunlight or extreme temperatures.

Troubleshooting

- **Bowl Does Not Fit:**

Issue: The work bowl does not seat properly on the motor base or the lid does not close.

Solution: Verify that your food processor model is listed as compatible (3066, 3067, 3093, 3094, 3111, 3112, KF140, KF149). Ensure there are no obstructions on the motor base or the bowl's locking mechanism. Rotate the bowl until it clicks securely into place.

- **Food Processor Not Starting:**

Issue: The food processor does not turn on after installing the bowl.

Solution: Confirm that both the work bowl and the lid are correctly and securely locked into their operating positions. Most food processors have safety interlocks that prevent operation if components are not properly assembled.

- **Central Mechanism Not Engaging:**

Issue: The central shaft or blade does not rotate when the food processor is on.

Solution: Ensure the blade or disc is correctly placed on the central shaft within the bowl. Check the food processor's main manual for specific assembly instructions for the blade/disc and lid.

Specifications

- **Model Number:** 3210-652
- **Product Dimensions:** 1 x 1 x 1 inches (approximate)
- **Item Weight:** 1 pound (approximate)
- **Manufacturer:** BRAUN
- **Material:** Clear plastic

Warranty Information

Specific warranty details for replacement parts like the Braun 3210-652 Work Bowl are typically provided by the retailer at the time of purchase or by the manufacturer. Please refer to your purchase documentation or contact Braun customer support directly for current warranty terms and conditions.

Support

For further assistance, questions regarding compatibility, or service inquiries, please contact Braun customer support. You may also refer to the original instruction manual provided with your Braun food processor for comprehensive operational and safety information.

Braun Official Website: www.braunhousehold.com

© 2024 Braun. All rights reserved.