

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Lepro](#) /

› [Lepro 1000LM LED Camping Lantern Rechargeable Instruction Manual](#)

## Lepro 3300008

# Lepro 1000LM LED Camping Lantern Instruction Manual

Model: 3300008

[Instructions](#) [Maintenance](#) [Overview](#) [Setup](#) [Operating](#)  
[Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

## 1. OVERVIEW

The Lepro 1000LM LED Camping Lantern is a versatile and portable lighting solution designed for various outdoor and indoor uses, including camping, hiking, emergencies, and power outages. It features a high brightness output, multiple light modes, and a built-in power bank for charging mobile devices.



Figure 1.1: The Lepro 1000LM LED Camping Lantern, showcasing its compact design and included USB charging cable.

## Key Features:

- **1000 Lumen Brightness:** Provides powerful 360-degree illumination.
- **4 Light Modes:** Includes Daylight White, Warm White, Combined, and Flashing modes.
- **Stepless Dimming:** Allows for adjustable brightness within each mode.

- **4400mAh Power Bank:** Can be used to charge smartphones and other mobile devices in emergencies.
- **IP44 Water Resistant:** Suitable for outdoor activities and adverse weather conditions.
- **Portable Design:** Features a top handle and a bottom hook for versatile hanging and carrying options.



Figure 1.2: The lantern provides 1000 lumens of 360-degree bright light, illuminating a wide area.

## 2. SETUP

### 2.1 Initial Charging

Before first use, fully charge the lantern. The lantern is equipped with a built-in rechargeable battery.

1. Locate the USB charging port on the side of the lantern.
2. Connect the included USB cable to the lantern's charging port.
3. Plug the other end of the USB cable into a 5V DC charger adapter (not included) or a compatible USB power source.

4. The charging indicator light will illuminate during charging. A full charge typically takes approximately 8 hours.



Figure 2.1: The lantern can be recharged via USB and also functions as a power bank.

**Note:** Do not use charger adapters over 5V voltage. The lantern can be used while charging, but it may extend the charging time. Avoid using the lantern as a power bank while it is simultaneously charging.

## 3. OPERATING INSTRUCTIONS

### 3.1 Power On/Off and Light Modes

The lantern features a single button for controlling power and cycling through light modes.

1. **Short Press:** Press the power button briefly to turn the lantern on and cycle through the four light modes in the following order:

- Daylight White (6000K)

- Warm White (3100K)
- Combined (6000K + 3100K)
- Flashing (Emergency Strobe)

2. **Turn Off:** After cycling through all modes, a short press will turn the lantern off.



Figure 3.1: Control the light modes with a short press and adjust brightness with a long press.

### 3.2 Stepless Dimming

To adjust the brightness of any active light mode:

- **Long Press:** While the lantern is on, press and hold the power button. The brightness will gradually increase or decrease. Release the button when the desired brightness level is reached.

### 3.3 Power Bank Function

The lantern can serve as an emergency power source for your mobile devices.

1. Locate the USB output port on the side of the lantern.
2. Connect your device's charging cable to the USB output port.
3. The lantern will begin charging your device.

**Note:** The power bank function is intended for emergency use. Continuous use may significantly reduce the lantern's illumination time.

### 3.4 Portability and Placement

The lantern offers multiple options for placement and carrying:

- **Top Handle:** Use the integrated handle for easy carrying or hanging the lantern upright.
- **Bottom Hook:** A hook is located at the base of the lantern, allowing it to be hung upside down for broader light distribution, especially useful in tents or overhead.
- **Anti-Skid Base:** The stable base prevents the lantern from easily tipping over when placed on flat surfaces, both indoors and outdoors.



Figure 3.2: The lantern features a versatile top handle and a bottom hook for various hanging options.

## 4. MAINTENANCE

---

### 4.1 Cleaning

Wipe the lantern with a soft, damp cloth. Do not use abrasive cleaners or solvents.

### 4.2 Storage

Store the lantern in a cool, dry place when not in use. For long-term storage, ensure the battery is fully charged every 3-6 months to maintain battery health.

### 4.3 Water Resistance

The lantern has an IP44 water resistance rating, meaning it is protected against splashing water from any direction. It is suitable for use in light rain but should not be submerged in water.




Figure 4.1: The IP44 rating ensures the lantern is water resistant for outdoor use.

## 5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lantern does not turn on.	Battery is depleted.	Charge the lantern fully using the provided USB cable.
Lantern does not charge.	Charging cable or adapter is faulty.	Try a different USB cable or 5V DC charger adapter. Ensure the adapter is not over 5V.
Light is too dim or too bright.	Brightness setting needs adjustment.	Press and hold the power button to activate stepless dimming and adjust to desired brightness.
Battery life is shorter than expected.	Constant use at maximum brightness or frequent use of power bank function.	Reduce brightness using stepless dimming. Limit power bank usage to emergencies. Ensure full charge before use.

## 6. SPECIFICATIONS

Feature	Detail
Brand	Lepro
Model Number	3300008
Brightness	1000 Lumens
Battery Capacity	4400mAh (2 Lithium Ion batteries included)
Battery Life	Up to 12 Hours (depending on mode and brightness)
Water Resistance Level	IP44
Product Dimensions	3.82" L x 3.82" W x 7.8" H
Item Weight	550 Grams
Light Source Type	Light Emitting Diode (LED)
Power Source	Battery Powered
Material	Plastic
Color	Green / Black

## 7. WARRANTY & SUPPORT

### 7.1 Warranty Information

This product comes with a 1-year warranty from the date of purchase. Please retain your proof of purchase for warranty claims.



## 7.2 Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official Lepro Store or contact their customer service.

Visit the Lepro  
Store

© 2025 Lepro. All rights reserved.

### Related Documents - 3300008

	<p><a href="#"><u>Lepro LED Headlamp PR320017 User Manual and Instructions</u></a></p> <p>Detailed user manual for the Lepro LED Headlamp (Model PR320017). Learn about features, operation, charging, safety guidelines, and specifications.</p>
	<p><a href="#"><u>Lepro LED Camping Lantern User Manual and Specifications</u></a></p> <p>Comprehensive user guide for the Lepro LED Camping Lantern, including operating instructions, maintenance, specifications, and safety precautions in multiple languages.</p>
	<p><a href="#"><u>Lepro PR330033 LED Camping Lantern User Guide</u></a></p> <p>User guide for the Lepro PR330033 LED Camping Lantern, providing instructions on usage, battery replacement, features, and safety information. Includes multilingual support and WEEE directive compliance.</p>
	<p><a href="#"><u>Lepro LE2000/LE2050 Extra Bright LED Flashlight User Manual</u></a></p> <p>Official user manual and specifications for the Lepro LE2000 and LE2050 extra bright LED flashlights. Includes safety instructions, product details, and compliance information.</p>
	<p><a href="#"><u>Lepro 320014-2 LED Headlamp User Manual and Specifications</u></a></p> <p>Comprehensive guide for the Lepro 320014-2 LED headlamp, covering lighting modes, usage instructions, safety precautions, technical specifications, and environmental compliance.</p>
	<p><a href="#"><u>Lepro LED Headlamp User Manual and Safety Guide</u></a></p> <p>Comprehensive user manual for the Lepro LED Headlamp (Model 3200008 series), including features, operating instructions, safety precautions, and contact information.</p>

