

[Manuals.plus](#) /

› [BRESSER](#) /

› Bresser BR-LB310 Tripod Lamp with Articulated Arm - Instruction Manual

BRESSER BR-LB310

Bresser BR-LB310 Tripod Lamp with Articulated Arm - Instruction Manual

Model: BR-LB310 / F001965

1. PRODUCT OVERVIEW

The BRESSER BR-LB310 is a professional, strong, and stable aluminum light stand designed for versatile use in photography and videography. It features an easy and quick deployment mechanism and can be adjusted to various positions. A key feature is its ability to convert the top section into a stand with an articulating arm, providing extended reach and flexible positioning for lighting equipment. The stand is coated with a black powder finish to reduce reflections and comes with essential accessories for immediate use.

2. PACKAGE CONTENTS

Please check the package carefully to ensure all components are present and undamaged:

- 1x BRESSER BR-LB310 Tripod Lamp with Articulated Arm
- 1x Giraffe Tang Adapter (1/4" Male, 3/8" Male)
- 1x Counterweight Bag (empty, for user-supplied counterweight)
- 1x Lobster Clasp
- 1x Carry Bag with inner compartments
- 1x Shoulder Bag



Image: The Bresser BR-LB310 Tripod Lamp with its articulated arm extended, showing the counterweight bag attached. A black carry bag is visible at the bottom, indicating portability.

3. SETUP INSTRUCTIONS

1. **Unfold the Tripod Base:** Place the folded stand on a flat, stable surface. Loosen the locking knob(s) on the main column and gently extend the legs outwards until they are fully spread and stable. Tighten the locking knob(s) securely.
2. **Adjust Main Column Height:** Loosen the height adjustment knobs on the main column. Extend the column to the desired height. Ensure each section is fully extended or retracted to a stable position before tightening the knobs firmly.
3. **Attach and Position the Articulated Arm:** The top section of the stand can be converted into an articulated arm. Loosen the appropriate knob to adjust the angle and extension of the arm. The arm length can extend up to 290 cm. Securely tighten all knobs once the desired position is achieved.
4. **Utilize Counterweight Bag:** For stability, especially when extending the articulated arm with heavy equipment, fill the provided counterweight bag with sand or other suitable material. Attach the filled counterweight bag to the designated hook on the articulated arm using the lobster clasp. This helps balance the load and prevent tipping.
5. **Mount Equipment:** Use the Giraffe Tang Adapter (1/4" Male, 3/8" Male) to mount your lighting fixtures or other compatible equipment onto the end of the articulated arm. Ensure the equipment is securely fastened.

Safety Note: Always ensure the stand is on a level surface and that all locking mechanisms are securely tightened

before mounting any equipment. Use the counterweight bag when extending the arm or using heavy loads to prevent the stand from tipping over.

4. OPERATING INSTRUCTIONS

The BRESSER BR-LB310 is designed for straightforward operation:

- **Height Adjustment:** To change the overall height, loosen the section clamps on the main vertical column, adjust to the desired height (maximum 500 cm with vertical arm), and then firmly tighten the clamps.
- **Arm Extension and Angle:** The articulated arm allows for precise positioning. Loosen the pivot and extension clamps on the arm to adjust its length and angle. Once positioned, tighten all clamps to secure the arm.
- **Load Distribution:** Always distribute the weight of your equipment evenly. When using the articulated arm, the counterweight bag is crucial for maintaining stability.
- **Portability:** When finished, collapse the stand by reversing the setup steps. Store all components in the provided carry bag for easy transport and protection.

5. MAINTENANCE

Proper maintenance will ensure the longevity and optimal performance of your BRESSER BR-LB310:

- **Cleaning:** Wipe down the aluminum surfaces with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid abrasive cleaners or solvents.
- **Lubrication:** Periodically check the moving parts and locking mechanisms. If any part feels stiff, apply a small amount of silicone-based lubricant to ensure smooth operation. Avoid over-lubrication.
- **Storage:** Store the stand in its carry bag in a dry, cool place, away from direct sunlight and extreme temperatures. Ensure it is clean and dry before storage to prevent corrosion.
- **Inspection:** Regularly inspect the stand for any signs of wear, damage, or loose components. Do not use the stand if any part is damaged or compromised.

6. TROUBLESHOOTING

If you encounter issues with your BRESSER BR-LB310, refer to the following common problems and solutions:

- **Stand is unstable:**
 - Ensure legs are fully extended and locked.
 - Verify all height adjustment knobs are securely tightened.
 - Use the counterweight bag, especially with extended arm or heavy loads.
 - Ensure the stand is on a flat, level surface.
- **Arm difficult to adjust or extend:**
 - Check if all locking knobs are fully loosened before attempting adjustment.
 - Clean any dirt or debris from the sliding sections.
 - Apply a small amount of silicone lubricant if parts feel stiff.
- **Equipment not fitting adapter:**
 - Confirm your equipment has a 1/4" or 3/8" female thread. The adapter provides both male threads.
 - Ensure the adapter is correctly screwed into the arm.

If the problem persists or you encounter an issue not listed here, please contact BRESSER customer support or your retailer for assistance.

7. SPECIFICATIONS

Feature	Specification
Brand	BRESSER
Model Name	BR-LB310
Item Model Number	F001965
Product Dimensions	7.09 x 13.98 x 5.24 inches (folded/packaged)
Item Weight	0.194 ounces / 0.01 Kilograms
Maximum Height (vertical arm)	500 cm (16.4 feet)
Arm Length	290 cm (9.5 feet)
Height (folded)	129 cm (50.8 inches)
Maximum Tube Diameter	40 mm
Material	Aluminum with black powder coating
Special Feature	Light Foot, Articulated Arm
Color	Black/White

8. WARRANTY AND SUPPORT

For information regarding warranty coverage, terms, and conditions for your BRESSER BR-LB310 Tripod Lamp, please refer to the warranty card included with your purchase or visit the official BRESSER website. You may also contact your retailer for specific warranty details.

For technical support, spare parts, or service inquiries, please contact BRESSER customer service directly. Contact information can typically be found on the manufacturer's website or in the product packaging.

BRESSER Store: [Visit the BRESSER Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0161FL9AM>

More documents and user manuals: <https://manuals.plus/>