

Singtrix SGTXMIC1

Singtrix SGTXMIC1 Professional Karaoke Microphone User Manual

Model: SGTXMIC1 | Brand: Singtrix

INTRODUCTION

This manual provides instructions for the Singtrix SGTXMIC1 Professional Karaoke Microphone, designed to enhance vocal performances with real-time effects and voice enhancements. This microphone is compatible with Singtrix karaoke systems, offering a high-quality audio experience for users.

PACKAGE CONTENTS

- Singtrix SGTXMIC1 Professional Karaoke Microphone

Please ensure all components are present upon unboxing.

SETUP

Follow these steps to set up your Singtrix SGTXMIC1 microphone:

- Connect the Microphone:** Locate the microphone input port on your Singtrix karaoke system. Insert the microphone's 6-foot cord securely into this port. The microphone is designed for quick plug-and-play functionality.
- Power On System:** Ensure your Singtrix karaoke system is powered on and ready for use.
- Positioning:** For optimal sound quality, hold the microphone approximately 2-6 inches from your mouth. The microphone is weighted and balanced for comfortable handling during performances.



Image 1: The Singtrix SGTXMIC1 Professional Karaoke Microphone. This image displays the microphone's design, including the wired connection and the 'Hit' button.

OPERATING INSTRUCTIONS

The Singtrix SGTXMIC1 microphone is designed for intuitive operation with your Singtrix karaoke system.

- **Standard Vocal Performance:** Once connected, the microphone will capture your voice for standard karaoke singing through the Singtrix system.
- **Using the "Hit" Button:** The microphone features a dedicated "Hit" button. Pressing this button activates real-time vocal effects and enhancements provided by your Singtrix system. These effects can include harmonies, pitch correction, and other vocal transformations. Refer to your Singtrix system's manual for specific effect details.



Image 2: Close-up of the Singtrix SGTXMIC1 microphone highlighting the 'Hit' effect control button. This button is used to activate vocal enhancements during performance.

MAINTENANCE

Proper care ensures the longevity and performance of your microphone:

- **Cleaning:** Wipe the microphone body with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the microphone in a dry, cool place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid sharp bends or kinks in the microphone cable. Coil the cable loosely when storing to prevent damage.
- **Handling:** Handle the microphone with care. Avoid dropping it or subjecting it to strong impacts.

TROUBLESHOOTING

If you encounter issues with your Singtrix SGTXMIC1 microphone, refer to the following common solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No sound from microphone	Microphone not properly connected; system volume too low; microphone or cable damage.	Ensure the microphone cable is fully inserted into the input jack. Check the volume settings on your Singtrix system. Inspect the cable for visible damage. Try connecting the microphone to a different compatible input if available.
Intermittent sound or crackling	Loose connection; damaged cable; interference.	Verify all connections are secure. Examine the cable for any signs of wear or internal breaks. Ensure no other electronic devices are causing interference nearby.
"Hit" button effects not activating	System not recognizing button press; system effects disabled.	Confirm your Singtrix system is in a mode that supports vocal effects. Refer to your Singtrix system's manual for troubleshooting effect activation.

SPECIFICATIONS

Feature	Detail
Model Name	SGTXMIC1
Brand	Singtrix
Microphone Form Factor	Handheld
Connectivity Technology	Wired
Connector Type	Plug-in
Cable Length	6 feet (approx. 1.8 meters)
Item Weight	10.6 ounces (approx. 0.3 kg)
Product Dimensions (L x W x H)	13 x 4 x 3 inches (approx. 33 x 10 x 7.6 cm)
Compatible Devices	Singtrix Karaoke Machine systems
Special Feature	Built-in "Hit" button for vocal effects
Color	Black

WARRANTY INFORMATION

For detailed warranty information regarding your Singtrix SGTXMIC1 microphone, please refer to the warranty card included with your original Singtrix karaoke system or visit the official Singtrix website. Warranty terms and conditions may vary by region and purchase date.

SUPPORT



If you require further assistance or have questions not covered in this manual, please contact Singtrix

customer support through their official website or the contact information provided with your product packaging. Always refer to the main Singtrix karaoke system manual for comprehensive operational details.


Official Singtrix Website: www.singtrix.com

© 2023 Singtrix. All rights reserved.

Related Documents - SGTXMIC1

	<p>Singtrix Quick Start Guide: Tips for Singing Like a Rockstar</p> <p>Learn how to set up and use your Singtrix Party Bundle with this quick start guide. Discover tips for optimizing vocal effects, mixing music, and troubleshooting common issues for an amazing singing experience.</p>
	<p>Singtrix Quick Start Guide: Tips for Singing Like a Rockstar</p> <p>Learn how to set up and use your Singtrix Party Bundle with this quick start guide. Discover tips for optimizing vocal effects, mixing music, and troubleshooting common issues for an amazing singing experience.</p>

Documents - Singtrix – SGTXMIC1



[\[pdf\]](#) Instructions Specifications Warranty Accessories

click here Singtrix Professional Karaoke Machine Microphone with Hit Button to Activate Effects and Voice Enhancements SGTXMIC1 Black Musical Instruments 611MaicfrL m media amazon images I |||

90 DAY LIMITED WARRANTY VOXX ELECTRONICS CORP. the Company warrants to the original retail purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 90 days from the date of original purchase, suc...

lang:en score:15 filesize: 124.27 K page_count: 1 document date: 2015-01-21