

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Pioneer](#) /
- › [Pioneer Carrozzeria FH-9200DVD Car Audio System User Manual](#)

Pioneer FH-9200DVD

Pioneer Carrozzeria FH-9200DVD Car Audio System User Manual

Model: FH-9200DVD

INTRODUCTION

This manual provides detailed instructions for the proper installation, operation, and maintenance of your Pioneer Carrozzeria FH-9200DVD 2DIN car audio system. Please read this manual thoroughly before using the product to ensure safe and optimal performance. Keep this manual for future reference.

Key Features:

- High-quality 7-inch touch panel display.
- Advanced audio processing including Time Alignment and a 13-band graphic equalizer.
- Network Mode for enhanced audio configuration.
- Versatile media playback: CD, DVD, USB.
- Integrated Bluetooth for audio streaming and hands-free calling, supporting two devices simultaneously.
- FLAC audio file playback compatibility (via USB, excluding MTP connection).
- MIXTRAX EZ for non-stop mix playback.
- Map Link function for navigation integration.

Included Accessories:

- USB Extension Cable (1.5m x 1)
- Dedicated Remote Control
- Voice Recognition Microphone



Figure 1: Front view of the Pioneer Carrozzeria FH-9200DVD unit.

SETUP

1. Installation

Professional installation is highly recommended for this car audio system. Incorrect installation can lead to damage to the unit or your vehicle's electrical system. Refer to the separate installation manual for detailed wiring diagrams and mounting instructions.

2. Initial Power-On and Basic Settings

1. After installation, turn on your vehicle's ignition. The unit should power on automatically.
2. Follow the on-screen prompts to set the initial language, date, and time.
3. Adjust basic audio settings such as fader and balance to your preference.

3. Connecting Accessories

- **USB Devices:** Connect your USB storage device to the provided USB extension cable.
- **Microphone:** Plug the voice recognition microphone into the designated input for hands-free calling and voice commands. Position the microphone in a location that ensures clear voice pickup, typically near the driver's sun visor.

OPERATING INSTRUCTIONS

1. Basic Controls

The FH-9200DVD features a touch panel display and physical buttons for intuitive control.

- **Power On/Off:** Press and hold the **SRC** button on the unit or remote control.
- **Volume Adjustment:** Use the **VOLUME +/-** buttons on the unit or remote.
- **Source Selection:** Press the **SRC** button repeatedly to cycle through available sources (CD, DVD, USB, Bluetooth Audio, AUX, Radio).



Figure 2: Dedicated remote control for the FH-9200DVD.

2. CD/DVD Playback

1. Insert a CD or DVD into the disc slot. The unit will automatically detect the disc and begin playback.
2. Use the on-screen controls or the remote control for playback functions (Play, Pause, Skip Track/Chapter, Fast Forward/Rewind).

3. USB Playback

1. Connect a USB storage device containing audio or video files to the USB input.
2. Select 'USB' as the source. The unit will display the file structure.
3. Navigate through folders and select files using the touch screen.

4. Bluetooth Functionality

Pairing a Bluetooth Device:

1. Ensure Bluetooth is enabled on your mobile device.
2. On the FH-9200DVD, go to the Bluetooth settings menu.
3. Select 'Pairing' or 'Add Device'. The unit will become discoverable.
4. On your mobile device, search for available Bluetooth devices and select 'FH-9200DVD'.
5. Confirm the pairing code on both devices if prompted.

Hands-Free Calling:

- Once paired, you can make and receive calls directly through the unit.
- Use the voice recognition microphone for clear communication.
- The unit supports simultaneous standby for two Bluetooth-enabled phones.

Bluetooth Audio Streaming:

- Select 'Bluetooth Audio' as the source.
- Play audio from your paired mobile device, and it will stream wirelessly to the FH-9200DVD.

5. Audio Settings

The FH-9200DVD offers advanced audio customization options.

Time Alignment:

This feature allows you to precisely adjust the sound output timing from each speaker to ensure that sound from all speakers reaches the listening position simultaneously, creating a more focused and natural soundstage.



Figure 3: Time Alignment adjustment screen, showing speaker distance settings.

Graphic Equalizer:

Utilize the 13-band graphic equalizer to fine-tune the audio frequency response to match your preferences and vehicle acoustics.



Figure 4: 13-band graphic equalizer interface for audio customization.

Network Mode:

This mode allows for a more advanced speaker setup, enabling direct control over individual speaker channels (e.g., High, Mid, Low) for a more precise sound system configuration.

MAINTENANCE

1. Cleaning the Unit

- Wipe the display panel and exterior surfaces with a soft, dry cloth.
- For stubborn dirt, use a cloth lightly dampened with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, solvents, or abrasive cleaners, as these can damage the finish.

2. Disc Handling

- Always handle discs by their edges to avoid fingerprints and scratches.
- Keep discs clean and free from dust. Use a soft, lint-free cloth to wipe discs from the center outwards.
- Do not use irregularly shaped discs or discs with adhesive labels, as these can cause damage to the disc mechanism.

TROUBLESHOOTING

If you encounter issues with your FH-9200DVD, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No power	Incorrect wiring; Blown fuse; Vehicle ignition off.	Check wiring connections; Replace fuse if necessary; Turn vehicle ignition to ACC or ON.
No sound	Volume too low; Mute function active; Incorrect audio source selected; Speaker wiring issue.	Increase volume; Deactivate mute; Select correct audio source; Check speaker connections.
Bluetooth connection fails	Device not in pairing mode; Incorrect pairing procedure; Interference.	Ensure both devices are in pairing mode; Re-attempt pairing; Move closer to the unit; Restart both devices.
Disc error	Scratched or dirty disc; Unsupported disc format; Disc inserted incorrectly.	Clean or replace disc; Ensure disc format is supported; Re-insert disc correctly.

If the problem persists after trying these solutions, consult a qualified service technician or contact Pioneer customer support.

SPECIFICATIONS

Feature	Specification
Brand	Pioneer
Model Name	FH-9200DVD
Mounting Size	2DIN
Output Power	50 Watts x 4 Channels
Connectivity Technology	AUX, Bluetooth, USB
Special Features	Bluetooth Built-in
Compatible Devices	Speakers
Audio Encoding	Stereo
Color	Black
Item Weight	1.8 Kilograms
Package Dimensions	28.3 x 24.9 x 16.2 cm

WARRANTY AND SUPPORT

Warranty Information

Pioneer products are manufactured to high-quality standards. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Pioneer website for your region. Keep your proof of purchase for warranty claims.

Customer Support

If you require further assistance, technical support, or service, please contact Pioneer customer support through their official website or the contact information provided in your product documentation. Please have your model number (FH-9200DVD) and serial number ready when contacting support.



© 2023 Pioneer Corporation. All rights reserved.