Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HABA 301696

HABA Wooden Motor Skills Board (Model 301696) Instruction Manual

Double-Sided Fine Motor Skills Toy for Color & Shape Recognition

Introduction

This instruction manual provides essential information for the safe and effective use of your HABA Wooden Motor Skills Board, Model 301696. This double-sided toy is designed to engage young children in developing fine motor skills, color recognition, and shape identification through interactive play.

Product Overview


The HABA Wooden Motor Skills Board features two distinct play sides:

- **Farm Theme Side:** Depicts a vibrant farm scene with animals and objects, designed for color matching and imaginative play.
- **Geometric Shapes Side:** Features primary-colored geometric shapes, promoting shape and color recognition.

Both sides incorporate tracks with attached wooden knobs that children can slide and maneuver, enhancing hand-eye coordination and problem-solving abilities.



This image shows the front side of the HABA Wooden Motor Skills Board, featuring a farm scene with a horse, cow, cat, and snail. Colored wooden knobs are visible within the tracks, ready for manipulation.



This image displays the reverse side of the HABA Wooden Motor Skills Board, which features geometric shapes (triangle, circle, square) in primary colors. Colored wooden knobs are positioned within the tracks, designed for shape and color matching.

Setup

1. **Unboxing:** Carefully remove the HABA Wooden Motor Skills Board from its packaging.
2. **Inspection:** Before first use, inspect the board for any signs of damage or loose components. Ensure all wooden knobs are securely attached within their tracks.
3. **Placement:** Place the board on a stable, flat surface such as a table or floor, ensuring adequate space for the child to interact comfortably.

Operating Instructions

The HABA Wooden Motor Skills Board is designed for intuitive play. Encourage children to explore and interact with the board at their own pace.

Playing with the Farm Theme Side

- Identify the various farm animals and objects depicted on the board (e.g., horse, cow, cat, barn, tree).
- Guide the child to slide the colored wooden knobs along the carved tracks.
- Encourage matching the knob colors to corresponding colors on the farm scene, such as moving a red knob to the red barn roof or green knobs to the tree leaves.
- Promote storytelling and naming the animals and colors to enhance vocabulary and imaginative play.

Playing with the Geometric Shapes Side

- Turn the board over to access the geometric shapes side.
- Identify the shapes (triangle, circle, square) and their respective colors (blue, yellow, green, red).
- Instruct the child to slide the colored wooden knobs along the tracks to match them with the corresponding colored shapes. For example, move blue knobs to the blue triangle or yellow knobs to the yellow circle.
- This activity helps develop shape and color recognition, as well as logical thinking.



A child's hands are shown interacting with the geometric shapes side of the HABA Wooden Motor Skills Board, demonstrating how the

knobs are moved along the tracks.

Your browser does not support the video tag.

This video illustrates the interactive features of the HABA Wooden Motor Skills Board, showcasing how children can slide the colored wooden knobs along the tracks on both the farm-themed side and the geometric shapes side, promoting fine motor skills and cognitive development.

Maintenance

- **Cleaning:** To clean the board, wipe it with a slightly damp cloth and a mild, non-toxic soap if necessary. Ensure the board is thoroughly dried immediately after cleaning to prevent moisture damage.
- **Storage:** Store the motor skills board in a dry environment, away from direct sunlight or extreme temperatures, which can cause warping or fading of the wood and colors.
- **Regular Inspection:** Periodically check the board for any signs of wear, splintering, or loose parts. If any damage is observed, discontinue use to ensure child safety.

Troubleshooting

- **Knobs are stiff to move:** Ensure the tracks are clean and free of any debris. Gentle, consistent pressure should allow the knobs to move smoothly. Avoid forcing the knobs, as this may cause damage.
- **Child loses interest:** Introduce the other side of the board to offer a new challenge. Demonstrate different ways to interact with the knobs and tracks, such as creating patterns or telling stories with the farm animals. Encourage open-ended play rather than strict adherence to rules.

Specifications

Product Dimensions	8.98 x 9.06 x 1.77 inches
Item Weight	7 ounces
Item Model Number	301696
Manufacturer Recommended Age	12 months - 8 years
Material	Plywood

Warranty and Support

Quality Assurance: HABA is committed to providing high-quality, safe, and durable products. The HABA Wooden Motor Skills Board is designed in Germany and manufactured with strict adherence to quality standards. All materials, engineering processes, mechanical endurance, and actual product use are rigorously tested and documented by independent, third-party testing institutes prior to market placement.
Customer Support: For any questions, concerns, or assistance regarding your HABA Wooden Motor Skills Board, please refer to the contact information provided on the product packaging or visit the official HABA website for customer service details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0169SGQ18

More documents and user manuals: **https://manuals.plus/**