

[Manuals.plus](#) /

> [Pure Garden](#) /

> Pure Garden Rolling Garden Cart with Seat (Model 75-MJ2011) Instruction Manual

## Pure Garden 75-MJ2011

# Pure Garden Rolling Garden Cart with Seat (Model 75-MJ2011) Instruction Manual

Model: 75-MJ2011

## 1. PRODUCT OVERVIEW

---

The Pure Garden Rolling Garden Cart with Seat is designed to provide comfort and convenience for various gardening and outdoor tasks. It features a sturdy seat, ample storage, and durable wheels for easy maneuverability.



Image: The Pure Garden Rolling Garden Cart with Seat, showcasing its green body, gray lid, and black wheels.

## 2. SETUP INSTRUCTIONS

The Pure Garden Rolling Garden Cart with Seat typically arrives pre-assembled. However, minor assembly may be required for the wheels or handle. Please follow these general steps:

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all parts are present: the main cart body, four wheels, and any necessary hardware (axles, washers, pins).
2. **Wheel Attachment:** Insert the axles through the designated holes on the cart body. Secure each wheel onto the axle using the provided washers and pins. Ensure wheels spin freely.
3. **Handle Attachment (if applicable):** If the handle is separate, align it with the attachment points on the cart and secure it with the provided fasteners.
4. **Lid Placement:** Place the lid securely on top of the cart body. Ensure the latches (if present) engage properly.



Image: A detailed view of the garden cart with key dimensions labeled, including length, width, and height.

### 3. OPERATING INSTRUCTIONS

---

The garden cart is designed for ease of use in various outdoor settings.

- **Using the Seat:** The lid of the cart serves as a sturdy bench seat. Sit comfortably on the lid to perform low-to-the-ground tasks such as weeding, planting, or trimming, reducing strain on your back and knees.
- **Maneuvering the Cart:** The four 6-inch diameter plastic wheels allow the cart to roll smoothly across various terrains, including tall grass and uneven ground. Use the built-in handles on each side to push or pull the cart as needed.
- **Accessing Storage:** The spacious interior of the cart and the removable tool tray are ideal for organizing and transporting gardening tools and supplies. Lift the lid to access the main storage compartment or remove the tool tray for smaller items.



Image: An individual comfortably seated on the garden cart, engaged in gardening activities, demonstrating its use as a mobile work seat.



Image: The garden cart with its lid open, revealing the removable tool tray and the spacious interior storage compartment, ideal for organizing gardening essentials.

## 4. MAINTENANCE

---

Proper maintenance ensures the longevity and optimal performance of your garden cart.

- **Cleaning:** Spot clean the cart as needed using a damp cloth and mild soap. Avoid harsh chemicals that may damage the plastic.
- **Storage:** Store the cart in a dry, covered area when not in use to protect it from prolonged exposure to direct sunlight, rain, or extreme temperatures, which can degrade plastic materials over time.
- **Wheel Inspection:** Periodically check the wheels for any debris or damage. Ensure they rotate freely and are securely attached.

## 5. TROUBLESHOOTING

---

If you encounter any issues with your garden cart, consider the following:

- **Wheels not rolling smoothly:** Check for debris (dirt, leaves, small stones) lodged in the wheel axles or around the wheels. Clean as necessary. Ensure the wheels are properly secured and not loose.

- **Lid not closing securely:** Verify that the lid is correctly aligned with the cart body. Check if any items in the storage compartment are obstructing the lid from closing completely.
- **Reduced stability:** Ensure the cart is on a relatively flat and stable surface. Avoid overloading the cart beyond its maximum weight capacity.

## 6. SPECIFICATIONS

<b>Product Dimensions</b>	10"D x 21.5"W x 11.5"H
<b>Brand</b>	Pure Garden
<b>Material</b>	Polypropylene (PP)
<b>Color</b>	Dark Green/Black/Grey
<b>Special Feature</b>	Durable, Removable Side, Sturdy
<b>Number of Shelves</b>	1
<b>Recommended Uses For Product</b>	Outdoor
<b>Target Audience</b>	Adults
<b>Handle Material</b>	Plastic
<b>Tire Type</b>	Tubeless
<b>Item Weight</b>	5.9 Pounds
<b>Number of Wheels</b>	4
<b>Weight Limit</b>	220 Pounds
<b>Assembly Required</b>	No
<b>Caster Type</b>	Pneumatic
<b>Frame Material</b>	Plastic
<b>UPC</b>	886511747166
<b>Item Model Number</b>	75-MJ2011
<b>Seat Height</b>	11.5 Inches
<b>Maximum Recommended Load</b>	220 Pounds
<b>Care Instructions</b>	Spot clean
<b>Number of Pieces</b>	1

## 7. WARRANTY AND SUPPORT

This Pure Garden product is covered by a **30-day warranty against manufacturer defects**. For warranty claims or product support, please refer to the contact information provided with your purchase or visit the official Pure Garden website.

