

[Manuals.plus](#) /

› [Acctim](#) /

› Acctim 14937 Astoria Smartlite Non-Ticking Alarm Clock - User Manual

Acctim 14937



Acctim Astoria Smartlite Alarm Clock

MODEL: 14937 - USER MANUAL

Introduction

Thank you for purchasing the Acctim Astoria Smartlite Alarm Clock. This manual provides detailed instructions for setting up, operating, and maintaining your new alarm clock. Please read it carefully to ensure optimal performance and longevity of your device.

The Acctim Astoria is designed for a peaceful night's rest, featuring a non-ticking sweep seconds hand for silent operation. Its innovative Smartlite technology automatically illuminates the display in low light conditions, providing clear visibility without disturbing your sleep.

Key Features:

- Smartlite technology that automatically illuminates the display for easy night time viewing.
- Non-ticking sweep second hand for silent operation.
- Clear, easy-to-read dial with automatic backlight.
- Alarm with snooze function.
- Compact dimensions: 59 x 95 x 105mm.

Setup

Battery Installation:

1. Locate the battery compartment cover on the back of the alarm clock.
2. Slide or lift the cover to open the compartment.
3. Insert 2 x AA batteries (not included), ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover securely.



Figure 1: Rear view of the alarm clock with battery compartment and controls.

Initial Time Setting:

1. On the back of the clock, locate the time setting knob (usually marked with a clock icon or 'TIME').
2. Rotate the knob clockwise or counter-clockwise to set the current time. Ensure you set the correct AM/PM if applicable (though this is an analogue clock, consider the 12-hour cycle for alarm setting).

Operating Instructions

Setting the Alarm:

1. Locate the alarm setting knob on the back of the clock (usually marked with an alarm bell icon or 'ALARM').
2. Rotate this knob to set the desired alarm time. The alarm hand on the clock face will move independently.
3. To activate the alarm, slide the ON/OFF switch (often near the alarm knob) to the 'ON' position. To deactivate, slide it to 'OFF'.

Using the Snooze Function:

When the alarm sounds, press the large button located on the top of the clock. This will temporarily silence the alarm, and it will sound again after approximately 5 minutes. To turn off the alarm completely, slide the alarm ON/OFF switch to the 'OFF' position.

Smartlite Technology:

The Acctim Astoria features Smartlite technology. A built-in light sensor on the clock monitors ambient light levels. When the room becomes dark, the backlight on the clock face will automatically illuminate, providing clear visibility of the time. As the room brightens, the backlight will turn off to conserve battery life. This feature is automatic and cannot be manually disabled or adjusted.





Figure 2: Front view of the alarm clock (left) and with Smartlite activated (right).

Maintenance

Cleaning:

To clean your alarm clock, gently wipe the surface with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying. Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the clock's finish or internal components.

Battery Replacement:

When the clock's display dims, the alarm weakens, or the clock stops functioning, it is time to replace the batteries. Follow

the battery installation steps outlined in the 'Setup' section.

Troubleshooting

Problem	Possible Cause	Solution
Clock not working / Display dim	Low or dead batteries; Incorrect battery installation.	Replace batteries with new AA batteries, ensuring correct polarity.
Alarm not sounding	Alarm switch is OFF; Alarm time not set correctly; Low batteries.	Ensure alarm switch is ON. Verify alarm time setting. Replace batteries.
Smartlite backlight is too bright at night	Automatic Smartlite feature is active.	The Smartlite feature is designed to automatically adjust to ambient light and cannot be manually turned off or dimmed. If the brightness is disruptive, consider placing the clock further away or turning it to face a wall.
Clock is ticking (despite being non-ticking)	While designed to be non-ticking, some internal mechanisms may produce a very faint sound.	This is generally normal for the mechanism. If the sound is significant, ensure the clock is on a stable, flat surface.

Specifications

- **Brand:** Acctim
- **Model Number:** 14937
- **Colour:** Silver
- **Product Dimensions:** 10.39 x 10.39 x 6.6 cm (approx. 9.5W x 10.5H centimetres)
- **Item Weight:** 154 g
- **Material:** Silver (finish)
- **Display Type:** Analogue
- **Power Source:** Battery Powered (2 x AA batteries, not included)
- **Special Feature:** Smartlite technology, Non-ticking sweep second hand, Snooze function




Figure 3: Product dimensions of the alarm clock.

Warranty and Support

Acctim products are manufactured to high standards and undergo rigorous quality control. For information regarding warranty coverage and terms, please refer to the packaging or contact Acctim customer support directly.

For further assistance, product registration, or to explore other Acctim products, please visit the official Acctim store:

[Visit the Acctim Store on Amazon](#)

Official Product Videos

No official product videos from the seller are available for embedding in this manual.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B016HVKPCI>

More documents and user manuals: <https://manuals.plus/>