

Neff T18PT16X0

NEFF T18PT16X0 Electric Hob User Manual

Model: T18PT16X0 | Brand: Neff

1. INTRODUCTION

This user manual provides essential information for the safe and efficient operation, installation, and maintenance of your NEFF T18PT16X0 Electric Hob. Please read these instructions carefully before using the appliance and keep them for future reference.



Figure 1.1: The NEFF T18PT16X0 Electric Hob seamlessly integrated into a kitchen countertop.

2. SAFETY INFORMATION

Always adhere to the following safety guidelines to prevent personal injury or damage to the appliance:

- Ensure the appliance is installed by a qualified professional.
- Do not operate the hob with wet hands.
- Keep children away from the hot cooking zones.
- Do not store flammable materials on or near the hob.
- After use, the glass ceramic surface may remain hot. Avoid touching it until it has cooled down.
- Never leave cooking unattended, especially when using high heat settings.
- In case of a fault, disconnect the appliance from the power supply immediately.

3. INSTALLATION

The NEFF T18PT16X0 Electric Hob is designed for flush-mounted installation. Proper installation is crucial for safety and performance. It is highly recommended that installation be carried out by a certified technician.

Key Installation Dimensions:

- Product Dimensions (W x D): 82.6 cm x 54.6 cm
- Niche Dimensions (H x W x D): 5.1 cm x 78.0 cm x 50.0 cm




Figure 3.1: Installation dimensions for the NEFF T18PT16X0 Electric Hob. All measurements are in millimeters.



Ohne Rahmen; zum flächenbündigen Einbau

Dieses Szenebild ist beispielhaft. Alle Informationen entnehmen Sie bitte der Artikelbeschreibung.

Figure 3.2: Detail showing the flush-mounted design of the hob, integrating seamlessly with the countertop.

4. OPERATING INSTRUCTIONS

Your NEFF T18PT16X0 Electric Hob features intuitive controls and versatile cooking zones to enhance your culinary experience.

4.1. The TwistPad Control

The unique **TwistPad** is a magnetic, removable control knob that allows for precise and comfortable regulation of all cooking zones. Simply place the TwistPad on the control panel and rotate it to select and adjust power levels.




Figure 4.1: The TwistPad control in detail, showing its central position and clear display.

Your browser does not support the video tag.

Video 4.1: Demonstration of the Neff TwistPad control in use, highlighting its ease of operation for adjusting heat settings.

4.2. Cooking Zones and Power Levels

The hob features four electric heating elements with 17 power levels for precise temperature control. These include:

- **Standard Cooking Zones:** For everyday cooking.
- **Switchable Roasting Zone (Bräterzone):** With a simple touch, two cooking zones can be combined into one large zone, ideal for larger roasting pans or griddles.
- **Power Level for Pots (Powerstufe für Töpfe):** Provides 50% more energy than level 9, allowing for extremely fast heating of pots without boiling over. The Powerstufe automatically switches off before overheating.
- **Power Level for Pans (Powerstufe für Pfannen):** Heats pans quickly for 30 seconds with high power, then automatically reduces heat to prevent burning.



Figure 4.2: A pot boiling rapidly on the Powerstufe for pots, demonstrating its high-speed heating capability.

POWERSTUFE FÜR TÖPFE

SCHNELLER ZUM GENUSS.

Mit der Powerstufe für Töpfe - mit 50% mehr Energie als auf Stufe 9 steht die maximale Hitze blitzschnell zur Verfügung. Ohne Überkochen. Die Powerstufe für Töpfe schaltet sich vor dem Überhitzen rechtzeitig wieder ab.

Figure 4.3: A pan with ingredients being cooked on the Powerstufe for pans, illustrating its quick heating feature for frying.

4.3. Child Lock

The hob is equipped with a child lock feature to prevent accidental activation. Refer to the detailed instructions in the full manual for activating and deactivating the child lock.

5. CARE AND MAINTENANCE

To maintain the appearance and functionality of your glass ceramic hob, follow these cleaning guidelines:

- Clean the hob after each use once it has cooled down.
- Use a soft cloth and a specialized ceramic hob cleaner.
- For stubborn stains, use a hob scraper, holding it at a shallow angle.
- Avoid abrasive cleaners, scouring pads, or harsh chemicals.

6. TROUBLESHOOTING

If you encounter issues with your hob, try the following before contacting customer service:

Problem	Possible Cause	Solution
Hob does not switch on.	No power supply; child lock activated.	Check circuit breaker; deactivate child lock.
Cooking zone not heating.	Incorrect pot placement; wrong power level selected.	Ensure pot is centered; adjust power level.
Error code displayed.	Specific fault detected.	Refer to the full manual's error code section or contact customer support.

7. TECHNICAL SPECIFICATIONS

Feature	Detail
Brand	Neff
Model Identifier	T18PT16X0
Product Dimensions (D x W x H)	5.1 x 78 x 5.1 cm
Installation Type	Built-in
Special Features	TwistPad, Switchable Roasting Zone, Flush-mounted
Burner Type	Built-in or Integrated
Number of Heating Elements	4
Color	Flush-mounted with Twistpad (Black)
Voltage	230 Volt
Wattage	12000 Watt

Feature	Detail
Operation Mode	Electric
Material	Glass Ceramic
Scope of Delivery	Hob only
First Available	January 1, 2016

Your browser does not support the video tag.

Video 7.1: A comparison video highlighting the differences between electric and induction hobs, providing context for the NEFF T18PT16X0's electric heating technology.

8. WARRANTY AND SUPPORT




For warranty information, technical support, or service requests, please refer to the warranty card included with your appliance or visit the official Neff website. Keep your purchase receipt as proof of purchase.




Online Resources:

- [Neff Official Store on Amazon.de](#)

© 2024 Neff. All rights reserved.

Related Documents - T18PT16X0

	<p>Neff T29RHS4S0A Built-in Gas Hob: User Manual & Installation Guide</p> <p>Comprehensive user manual and installation instructions for the Neff T29RHS4S0A built-in gas hob. Covers safety, installation, operation, cleaning, troubleshooting, and Home Connect features.</p>
	<p>NEFF T68..Y4.. Induction Hob: User Manual and Information for Use</p> <p>Discover how to safely and efficiently use your NEFF T68..Y4.. induction hob with this comprehensive user manual. Learn about its features, cooking recommendations, energy-saving tips, and maintenance.</p>
	<p>NEFF Collection: Premium Kitchen Appliances & Partner Program</p> <p>Discover the NEFF Collection, offering premium kitchen appliances with unique features like Slide & Hide and TwistPad Fire. Learn about the NEFF Collection Partner Program, its benefits, marketing support, and training opportunities for dealers.</p>

	<p>Neff T26BKP6N0 Gas Hob Installation Manual</p> <p>Detailed installation guide for the Neff T26BKP6N0 stainless steel gas hob, covering safety precautions, furniture preparation, gas and electrical connections, gas type conversion, and technical specifications.</p>
	<p>NEFF T16BT.6..., T16.T.6..., T17.T.6.. Hob User Manual and Installation Instructions</p> <p>Comprehensive guide for NEFF hobs, covering operation, safety, installation, and energy-saving tips. Learn about features like the Twist Pad, Powerboost, and timer functions.</p>
	<p>NEFF Induction Hob T6...Y4.. - Information for Use</p> <p>Comprehensive user manual for the NEFF T6...Y4.. induction hob, covering installation, operation, safety guidelines, features like Flex Zone and Home Connect, cleaning, and troubleshooting.</p>