

[Manuals.plus](#) /

› [Breville](#) /

› Breville BJE430SIL Juice Fountain Cold User Manual

Breville BJE430SILUSC

Breville Juice Fountain Cold Instruction Manual

Model: BJE430SILUSC

INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Breville Juice Fountain Cold. Please read all instructions before using the appliance and retain this manual for future reference.



The Breville BJE430SIL Juice Fountain Cold, featuring its main components: the juicer base, juice jug, and pulp container.

COMPONENTS

Familiarize yourself with the various parts of your Juice Fountain Cold:

- **Motor Base:** Houses the 850-watt motor and control dial.
- **Juicer Cover:** Transparent cover with a feed chute.
- **Pulp Container:** Collects discarded pulp. Capacity: 3.6 quarts.
- **Juice Jug:** 70 fl oz (2 Liter) capacity with an easy-seal lid and froth separator.
- **Filter Basket:** Italian-made precision mesh filter for juice extraction.
- **Food Pusher:** Used to guide fruits and vegetables into the feed chute.
- **Detachable Spout:** For direct juicing into a glass.
- **Cleaning Brush:** Included for easy cleaning of the mesh filter.



Powerful 850W motor with stainless steel and titanium reinforced extraction system

The Breville Juice Fountain Cold, designed for efficient juicing of various fruits and vegetables.

SETUP

Before first use, wash all removable parts in warm, soapy water. Rinse thoroughly and dry. Place the motor base on a dry, level surface.

1. Ensure the power cord is unplugged from the wall outlet.
2. Place the filter bowl surround onto the motor base.
3. Insert the stainless steel filter basket into the filter bowl surround, ensuring it is securely seated.
4. Position the juicer cover over the filter basket and filter bowl surround, aligning the chute with the juice outlet.
5. Lift the safety locking arm and lock it into the two grooves on either side of the juicer cover. The locking arm should be in a vertical and locked position.
6. Place the pulp container under the pulp chute at the back of the juicer.
7. Place the juice jug with its lid and froth separator under the juice spout. Alternatively, use the detachable spout for direct juicing into a glass.

OPERATING INSTRUCTIONS

The Breville Juice Fountain Cold features a powerful 850-watt motor and two-speed electronic control for optimal juicing.



2-speed electronic control: Low for soft and leafy, high for dense and hard

The two-speed electronic control allows selection between 'Low' for soft fruits and leafy greens, and 'High' for harder produce.

Juicing Process:

1. Wash fruits and vegetables thoroughly. Most fruits and vegetables, such as apples, carrots, and celery, can be processed whole due to the unique 3-inch extra-wide chute feed.
2. For fruits with hard skins (e.g., pineapple, melon, citrus fruits), peel them before juicing. Remove large seeds or pits from fruits like peaches, cherries, or mangoes.
3. Plug the power cord into a 110-120 Volt wall outlet.
4. Turn the control dial to the desired speed setting:
 - **LOW:** For soft fruits and leafy vegetables (e.g., berries, grapes, spinach).

- **HIGH:** For harder fruits and vegetables (e.g., apples, carrots, beets).

5. With the motor running, place prepared ingredients into the feed chute. Use the food pusher to gently guide the produce down. Do not apply excessive force, as this can affect juice yield and motor performance.
6. Juice will flow into the juice jug, and pulp will accumulate in the pulp container.
7. The LED display will illuminate if the motor stops due to overloading, indicating a preventative feature for secure use and motor longevity.
8. When finished juicing, turn the control dial to 'OFF' and unplug the appliance. Invert the juice nozzle to prevent drips.



Extra wide 3" chute feed to juice whole fruits and vegetables without pre-cutting

The extra-wide 3-inch feed chute allows for juicing whole fruits and vegetables, reducing prep time.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your juicer. Always unplug the juicer before cleaning.

Daily Cleaning:

1. Remove the pulp container, juice jug, food pusher, juicer cover, and filter basket.
2. Discard pulp from the pulp container.
3. Rinse all removable parts under running water. Use the included cleaning brush to remove pulp from the mesh filter.
4. All removable parts are dishwasher safe (top rack only).
5. Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
6. Dry all parts thoroughly before reassembling or storing.



Easy clean dishwasher safe 70 fl oz juice jug with froth separator

The 70 fl oz Seal & Store Jug allows for convenient storage of freshly made juice in the refrigerator for up to three days.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Juicer does not start.	Safety locking arm not correctly engaged. Power cord not plugged in.	Ensure locking arm is securely in place. Plug the power cord into a live outlet.
Motor stalls or stops during operation.	Overloading with too much produce or hard ingredients.	Turn off and unplug. Remove juicer cover and clear any blockage. Reduce amount of produce or use 'HIGH' speed for hard ingredients.
Excessive pulp in juice.	Filter basket is clogged or damaged.	Clean the filter basket thoroughly with the cleaning brush. Inspect for damage; replace if necessary.
Juice leaking from under the juicer cover.	Juicer cover not properly aligned or locking arm not engaged.	Ensure juicer cover is correctly positioned and the safety locking arm is fully engaged.

SPECIFICATIONS

- **Model Name:** Juice Fountain Cold
- **Model Number:** BJE430SILUSC
- **Power:** 850 Watts
- **Voltage:** 110 to 120 Volts
- **Capacity:** 70 fl oz (2 Liters) Juice Jug, 3.6 qt Pulp Container
- **Dimensions (D x W x H):** 7.99" x 13.62" x 16.65"
- **Blade Material:** Titanium
- **Control Type:** Button/Dial (2 Speeds)
- **Special Feature:** Cold Spin Technology, Whole Fruit Processing
- **Care Instructions:** Hand Wash Only (for certain parts), Dishwasher Safe (removable parts, top rack)



Product Dimensions

17" High x 14.5" Wide x 9" Deep

Product dimensions for placement and storage considerations.

WARRANTY AND SUPPORT

Your Breville Juice Fountain Cold is covered by a **1 Year Limited Product Warranty** from the date of purchase.

For warranty claims, technical support, or replacement parts, please contact Breville Customer Service. Refer to the official Breville website or your purchase documentation for contact details.

Important: Do not attempt to service the appliance yourself. Any servicing other than cleaning should be performed by an authorized Breville service center.

© 2024 Breville. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question