

Franke 65.131

Franke 65.131 Kitchen Spray Hose Instruction Manual

Model: 65.131

1. PRODUCT OVERVIEW

The Franke 65.131 Kitchen Spray Hose is a replacement component designed for specific Franke kitchen faucet models. This hose facilitates the pull-out spray function, providing flexibility and convenience for various kitchen tasks. It is constructed for durability and reliable performance within your Franke faucet system.

Compatibility

This replacement pull-out hose is compatible with the following Franke faucet applications:

- Franke FF200
- Franke FF-200
- Franke FF-300
- Franke FF-600
- Franke FF-700
- Franke FF-1200
- Franke FF3000
- Franke OE-300
- Franke OE-900

2. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in property damage or personal injury.

- Always turn off the main water supply to the faucet before beginning any installation or maintenance.
- Wear appropriate personal protective equipment, such as safety glasses and gloves, during installation.
- Ensure all connections are secure to prevent leaks.
- If you are unsure about any step, consult a qualified plumber.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation.

- 1 x Franke 65.131 Kitchen Spray Hose
- Washers (as supplied)



An image showing the Franke 65.131 kitchen spray hose, coiled, with a brass fitting on one end and a chrome fitting on the other. Two black rubber washers are also visible, indicating included components for installation.

4. INSTALLATION GUIDE

Follow these steps to replace your kitchen spray hose.

1. **Turn Off Water Supply:** Locate the hot and cold water supply valves under your sink and turn them off completely. Open the faucet to relieve any remaining water pressure.
2. **Disconnect Old Hose:** Place a bucket under the faucet connections to catch any residual water. Carefully disconnect the old spray hose from the faucet body and the spray head. Note the orientation of any washers or seals.
3. **Prepare New Hose:** Ensure the new Franke 65.131 spray hose has all necessary washers and seals in place. Refer to the included components.
4. **Connect to Faucet Body:** Attach one end of the new hose to the designated connection point on the faucet body under the sink. Hand-tighten first, then use a wrench to secure it, being careful not to overtighten.

- 5. **Connect to Spray Head:** Attach the other end of the hose to the spray head. Ensure a secure connection.
- 6. **Check for Obstructions:** Ensure the hose can move freely under the sink without kinking or rubbing against other plumbing components.
- 7. **Restore Water Supply:** Slowly turn on the hot and cold water supply valves.
- 8. **Test for Leaks:** Check all connections for leaks. If leaks are present, gently tighten the connections until they stop. Do not overtighten.
- 9. **Test Faucet Functionality:** Operate the faucet and spray head to ensure proper water flow and spray function.

5. OPERATION

The Franke 65.131 Kitchen Spray Hose functions as part of your pull-out or pull-down kitchen faucet system. To operate, simply pull the spray head from its docked position. Water will flow through the hose to the spray head. Push the spray head back into its docking position when finished. Ensure the hose retracts smoothly without obstruction.

6. MAINTENANCE AND CARE

Proper maintenance will extend the life of your spray hose.

- **Cleaning:** Clean the exterior of the hose with a soft cloth and mild soap and water. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Inspection:** Periodically inspect the hose for any signs of wear, kinks, or damage. Check connections for tightness and leaks.
- **Smooth Operation:** Ensure the hose moves freely within the faucet body and under the sink. Clear any obstructions that might impede its movement.

7. TROUBLESHOOTING

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Water leak at connections	Loose connection or damaged washer.	Ensure connections are tight. Replace worn or damaged washers.
Hose does not retract smoothly	Obstruction under the sink or hose is kinked.	Clear any items obstructing the hose's path. Straighten any kinks.
Reduced water flow from spray head	Aerator or spray head clogged, or hose kinked.	Clean the spray head/aerator. Check the hose for kinks.

8. TECHNICAL SPECIFICATIONS

- **Part Number:** 65.131
- **Item Model Number:** 65.131
- **Item Weight:** Approximately 11.2 ounces





- **Product Dimensions:** Approximately 10.08 x 7.32 x 2.4 inches (packaged)
- **Color:** Silver
- **Included Components:** Product Only (hose and necessary washers)
- **Manufacturer:** Franke



9. WARRANTY AND SUPPORT

For specific warranty information regarding your Franke 65.131 Kitchen Spray Hose, please refer to the documentation provided with your original Franke faucet or visit the official Franke website. For technical support or assistance with installation, please contact Franke customer service directly.

Online Resources: For additional information and support, visit the official Franke website.

Related Documents - 65.131

	<p>Franke EOS NEO Kitchen Faucet Installation and Service Manual</p> <p>Comprehensive guide for installing and servicing the Franke EOS NEO kitchen faucet, including model details, step-by-step instructions, technical specifications, and maintenance tips.</p>
	<p>Franke Sinks: Global Contacts and Installation Guide</p> <p>Find Franke kitchen sink contact information worldwide and access installation and maintenance guidance, including product details for the Franke Maris MRX 110-40.</p>
	<p>Franke EOS NEO Kitchen Faucet Installation and Service Manual</p> <p>Comprehensive installation and service manual for the Franke EOS NEO kitchen faucet, detailing installation steps, periodic checks, and operating data for Swivel Side and Pull Down Spray models.</p>
	<p>Franke Orbit Kitchen Faucet Installation and Service Manual</p> <p>This manual provides detailed installation and service instructions for the Franke Orbit kitchen faucet, covering various models and multilingual support.</p>

	<p>Franke EOS NEO Kitchen Faucet Installation and Service Manual</p> <p>Detailed installation and service guide for the Franke EOS NEO kitchen faucet, covering models A (Swivel Side) and B (Pull Down Spray), including dimensions, assembly steps, maintenance checks, operating data, and parts lists. Features multilingual support.</p>
	<p>Franke ATLAS NEO S Kitchen Faucet Installation and Service Manual</p> <p>Comprehensive installation and service guide for the Franke ATLAS NEO S kitchen faucet series, detailing product variants, technical specifications, operating data, and maintenance checks. Includes diagrams described textually.</p>

Documents - Franke – 65.131

no relevant documents