Beurer MP 70

Beurer MP 70 Paraffin Wax Bath: Instruction Manual

Model: MP 70

Introduction
Safety Warnings
Package Contents
Setup
Operation
Maintenance
Troubleshooting
Specifications
Warranty & Support

1. Introduction

The Beurer MP 70 Paraffin Wax Bath is designed to provide a soothing and hydrating treatment for your hands, feet, and elbows. This electric wax bath melts paraffin wax, creating a warm, moisture-retaining layer on the skin. The heat opens pores, enhancing the absorption of moisture and active skincare ingredients, while also promoting blood circulation. Regular use can help soften rough, dry, or damaged skin, leaving it supple and smooth.

2. Important Safety Warnings

Always consult the product packaging and the full instruction manual for complete safety information before use.

- Do not use if you have open wounds, skin infections, or severe circulatory problems.
- Ensure the device is placed on a stable, heat-resistant surface.
- Keep out of reach of children.
- Do not immerse the device in water or other liquids.
- Always unplug the device before cleaning or if not in use.
- Do not touch the melted wax directly with bare hands until you have tested its temperature.
- If the device or power cord is damaged, do not use it. Contact customer service.

3. Package Contents

Your Beurer MP 70 Paraffin Wax Bath package includes the following items:

- 1 x Beurer MP 70 Paraffin Wax Bath Unit
- 2 x Packs of Orange-Scented Paraffin Wax
- 30 x Plastic Sheets



The Beurer MP 70 Paraffin Wax Bath, shown with its included accessories: two packs of orange-scented paraffin wax and a supply of plastic sheets for treatment.

4. Setup Instructions

1. **Placement:** Place the paraffin wax bath unit on a flat, stable, and heat-resistant surface. Ensure there is adequate ventilation around the unit.
2. **Open Lid:** Open the lid of the paraffin wax bath.
3. **Insert Wax:** Place the paraffin wax blocks into the bath. It is recommended to use both included blocks for sufficient depth.
4. **Power Connection:** Plug the power cord into a suitable electrical outlet.
5. **Turn On and Melt:** Turn the temperature control dial to the 'hot' setting. The indicator light will illuminate. Allow approximately 2 hours for the paraffin wax to fully melt.
6. **Temperature Adjustment:** Once the wax is melted, turn the dial to the 'warm' setting or adjust to your preferred comfortable temperature. Always test the wax temperature on a small area of your skin (e.g., wrist) before full immersion to prevent burns.



A view inside the Beurer MP 70 Paraffin Wax Bath, illustrating the melted orange paraffin wax and the internal grid designed to prevent

direct contact with the heating element.



A detailed view of the temperature control dial on the Beurer MP 70, allowing users to adjust the wax temperature between 'warm' and 'hot' settings, with clear power indicators.

5. Operating Instructions

Follow these steps for an effective paraffin wax treatment:

1. **Prepare Skin:** Ensure your hands, feet, or elbows are clean and dry. For optimal results, apply a water-based moisturizer or cream to the area before treatment. This helps the skin absorb moisture more effectively once pores are opened by the warm wax.

2. **Test Temperature:** Before dipping, carefully test the wax temperature by briefly touching the surface with your wrist or a finger. The wax should feel comfortably warm, not unpleasantly hot.
3. **Dip Application:** Slowly dip your hand, foot, or elbow into the melted paraffin wax. Hold it submerged for a few seconds until a layer of wax forms. Carefully remove and allow the wax to solidify slightly. Repeat this dipping process 3-5 times to build up several layers of wax.
4. **Cover with Plastic:** Immediately after the final dip, place the treated hand or foot into one of the provided plastic sheets. This helps retain heat and moisture.
5. **Relaxation Time:** Allow the wax to remain on your skin for approximately 15-20 minutes. During this time, the warmth will open your pores and facilitate deep hydration.
6. **Remove Wax:** After the recommended time, gently peel off the solidified wax and the plastic sheet. The wax should come off easily, taking with it dead skin cells. Dispose of the used wax and plastic sheet.
7. **Post-Treatment:** Your skin should now feel soft and smooth. You may apply another layer of moisturizer if desired.



Illustration of applying a water-based moisturizer to the hands before paraffin treatment, which helps enhance skin hydration.



Demonstration of a hand being immersed into the warm, melted paraffin wax within the Beurer MP 70 unit, illustrating the application process.

6. Maintenance

Proper maintenance ensures the longevity and hygiene of your paraffin wax bath.

- **Cleaning the Unit:** After use, unplug the device and allow it to cool completely. Once the wax has solidified, it can be carefully removed in a block. Wipe the interior and exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Wax Replacement:** The paraffin wax should be replaced regularly, especially if it appears cloudy, discolored, or contains debris. Always use paraffin wax specifically designed for paraffin baths.
- **Storage:** Store the unit in a cool, dry place with the lid closed to prevent dust accumulation.

7. Troubleshooting

Problem	Possible Cause	Solution
Wax not melting or heating slowly	Not plugged in; temperature dial set too low; insufficient time.	Ensure unit is plugged in. Turn dial to 'hot' setting. Allow sufficient time (approx. 2 hours).
Wax too hot or too cold	Temperature dial set incorrectly.	Adjust the temperature dial to 'warm' or a comfortable setting. Always test before use.
Skin irritation after use	Allergic reaction; wax too hot; pre-existing skin condition.	Discontinue use immediately. Consult a healthcare professional. Ensure wax temperature is comfortable.
Unit not turning on	No power; faulty unit.	Check power outlet and cord connection. If still not working, contact customer support.

8. Technical Specifications

- **Product Name:** Paraffin Wax Bath for Hands and Feet
- **Brand:** Beurer
- **Model Number:** 589.32
- **Dimensions (L x W x H):** 18.5 x 33 x 23 cm
- **Weight:** 1.2 kg
- **Power:** 83 Watts
- **Country of Origin:** China

9. Warranty and Customer Support

For detailed warranty information, please refer to the warranty card included with your product or visit the official Beurer website. In case of technical issues, questions, or to claim warranty service, please contact Beurer customer support directly. Keep your proof of purchase for warranty claims.

© 2023 Beurer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question