

[Manuals.plus](#) /

› [Lorell](#) /

› Lorell LLR60997 12-Inch Round Radio Controlled Wall Clock Instruction Manual

Lorell LLR60997

Lorell LLR60997 12-Inch Round Radio Controlled Wall Clock Instruction Manual

Model: LLR60997

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Lorell LLR60997 12-Inch Round Radio Controlled Wall Clock. Please read this manual thoroughly before using the clock to ensure proper function and longevity.

PRODUCT OVERVIEW



Image: Front view of the Lorell LLR60997 12-Inch Round Radio Controlled Wall Clock. It features a black frame, a white face with large black numbers (1-12), and black hour, minute, and second hands. The Lorell logo is positioned below the 12, and "radio controlled" text with a signal icon is above the 6.

The Lorell LLR60997 is a 12-inch round wall clock that automatically synchronizes with the atomic clock signal for precise timekeeping. This radio-controlled feature ensures that the clock always displays the correct time, including automatic adjustments for Daylight Saving Time.

SETUP

1. **Unpacking:** Carefully remove the clock from its packaging. Inspect for any damage.
2. **Battery Installation:**
 - Locate the battery compartment on the back of the clock.
 - Insert one (1) AA alkaline battery (not included), ensuring the correct polarity (+/-).
 - Once the battery is inserted, the clock hands will automatically move to the 12 o'clock position and begin searching

for the radio signal. This process may take several minutes.

3. **Signal Reception:**

- Place the clock in an area with good reception. Walls, metal objects, and electronic devices can interfere with the signal.
- For best reception, position the clock near a window, away from large metal structures or other electronics.
- The clock will attempt to receive the atomic time signal daily, typically overnight, to maintain accuracy.

4. **Mounting:**

- Use a suitable screw or hook (not included) to hang the clock securely on a wall. Ensure the mounting point can support the clock's weight.

OPERATING INSTRUCTIONS

Once the battery is installed and the clock has successfully received the atomic time signal, it will automatically set itself to the correct time. No manual adjustment is typically required.

- **Automatic Time Synchronization:** The clock will automatically synchronize with the atomic time signal from Fort Collins, Colorado, ensuring accurate timekeeping.
- **Daylight Saving Time (DST) Adjustment:** The clock will automatically adjust for Daylight Saving Time changes in spring and autumn.

MAINTENANCE

- **Cleaning:** Wipe the clock's surface with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Battery Replacement:** Replace the battery annually or when the clock stops functioning. Always use a fresh AA alkaline battery.
- **Storage:** If storing the clock for an extended period, remove the battery to prevent leakage and damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock does not set to correct time.	• Weak or dead battery. • Poor radio signal reception. • Interference from electronics or metal objects.	• Replace with a fresh AA alkaline battery. • Relocate the clock to an area with better signal reception (e.g., near a window, away from electronics). • Allow up to 24 hours for the clock to receive the signal and set itself.
Clock hands are stuck or not moving.	• Battery issue. • Mechanical obstruction.	• Replace the battery. • Ensure hands are not bent or touching the clock face or each other.
Clock loses time or runs inaccurately.	• Weak battery. • Intermittent signal reception.	• Replace the battery. • Ensure the clock is in a location with consistent signal reception.

SPECIFICATIONS

- **Model:** Lorell LLR60997
- **Dimensions:** 12.4 x 12.4 x 2.25 inches (Diameter x Depth)
- **Weight:** Approximately 15.84 ounces
- **Power Source:** 1 x AA Alkaline Battery (not included)
- **Time Synchronization:** Radio Controlled (Atomic Clock Signal)
- **Automatic DST Adjustment:** Yes
- **Manufacturer:** Lorell

WARRANTY INFORMATION

Specific warranty details for the Lorell LLR60997 clock are typically provided with the product at the time of purchase or can be obtained directly from the manufacturer. Please refer to the documentation included in your product packaging or visit the official Lorell website for the most current warranty terms and conditions.

CUSTOMER SUPPORT

For technical assistance, troubleshooting beyond this manual, or inquiries regarding your Lorell LLR60997 clock, please contact Lorell customer support.

- **Manufacturer:** Lorell
- **Website:** www.lorellfurniture.com
- **Contact Information:** Refer to the manufacturer's website or product packaging for the most up-to-date contact details.

© 2023 Lorell. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question