

Progress Lighting P6085-3130K9

Progress Lighting Wish LED Collection Outdoor Wall Lantern

Model: P6085-3130K9

Brand: Progress Lighting

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Progress Lighting Wish LED Collection Outdoor Wall Lantern. This 1-light fixture features etched white linen glass and a textured black finish, designed for outdoor use. Please read this manual thoroughly before beginning installation or operation to ensure safe and proper use of the product.



Image Description: A close-up view of the Progress Lighting Wish LED Outdoor Wall Lantern, showcasing its textured black finish and etched white linen glass cylinder.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury to persons, please adhere to the following safety guidelines:

- Read all instructions carefully before installation.
- Disconnect power at the circuit breaker or fuse box before servicing or installing the fixture.

- All wiring must be in accordance with national and local electrical codes. If you are unsure about wiring, consult a qualified electrician.
- Use only UL/ETL listed components.
- This product is suitable for wet locations.
- **Proposition 65 Warning:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation:

- Progress Lighting Wish LED Outdoor Wall Lantern (1 unit)
- Installation Sheet
- Optional Dark Sky Shield (1 unit)

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Progress Lighting
Model Number	P6085-3130K9
Color	Black
Material	Aluminum (Fixture), Glass (Shade)
Style	Traditional/Casual
Fixture Form	Wall
Product Dimensions	9"L x 10.5"W x 12.5"H
Usage	Outdoor, Wet Location Listed
Power Source	AC
Light Source Type	Integrated LED (No bulbs required)
Number of Light Sources	1
Voltage	120 Volts
Light Color	Warm white
Wattage	17 watts
Brightness	1,211 lumens (71.2 lumens/watt)
Color Temperature	3000 Kelvin

Feature	Detail
CRI	90+
Energy Efficiency	Energy Star Certified
Item Weight	6.95 pounds
UPC	785247193387



Wet
Location
Listed

Image Description: The Progress Lighting Wish LED Outdoor Wall Lantern displayed alongside certification icons, including LED, Energy Star, T24, a 5-year warranty symbol, and a 'Wet Location Listed' icon.

SETUP AND INSTALLATION

This section provides general guidelines for installing your outdoor wall lantern. For detailed electrical wiring instructions, refer to the included installation sheet and consult local electrical codes. Professional installation is recommended if you are not familiar with electrical wiring.

General Sizing and Placement Guidelines

Proper sizing and placement are crucial for optimal illumination and aesthetic appeal. The following video offers general guidance on outdoor lighting selection:

Video playback is not supported by your browser. You can download the video [here](#).

Video Description: An instructional video from Progress Lighting titled "Outdoor Lighting - Sizing and Selection." It provides general guidance on selecting appropriate sizes and mounting heights for various outdoor lighting fixtures, including wall lanterns, for entryways and garages.

Wall Lantern Placement

- For entrances and garages, select fixtures that measure approximately 1/4 to 1/3 of the door's height.
- Mount them at eye level, typically about 5.5 to 6 feet from the ground to the center of the fixture.
- For entrance doors, mount lights on either side, approximately 8 to 10 feet apart.
- For a one-car garage, a single wall lantern is typically sufficient. For two or more car garages, mount lights on either side of the doors, or across the top for even illumination.



Image Description: Two Progress Lighting Wish LED outdoor wall lanterns illuminating the entryway of a house with light-colored brick and a dark wooden double door.



Image Description: Two Progress Lighting Wish LED outdoor wall lanterns flanking a dark blue front door on a white-sided house, demonstrating proper placement.

Dark Sky Shield Installation

Your lantern includes an optional dark sky shield. This component can be installed to direct light downwards, providing full cut-off illumination, or removed for a more traditional lighting effect. Refer to the installation sheet for specific instructions on attaching or removing this shield.




Image Description: A diagram illustrating the dimensions of the P6085-3130K9 wall lantern, showing a height of 12.5 inches and a width of 9 inches. An optional dark sky shield is also depicted separately, indicating its purpose to direct light downwards.

OPERATING INSTRUCTIONS

Powering On/Off

Once installed and wired correctly, the fixture can be operated via a standard wall switch connected to the

circuit.

Dimming Functionality

This fixture features integrated LED lighting and is dimmable when used with a compatible wall dimmer. Ensure your dimmer switch is rated for LED lighting to prevent damage and ensure proper operation. The LED module is integrated and does not require bulb replacement.



Image Description: A graphic illustrating the integrated LED feature (no bulbs required) and demonstrating the fixture's dimmable capability with a compatible wall dimmer switch.




Image Description: A graphic highlighting key LED specifications: LED light source, 90 CRI (Color Rendering Index), and 3000K (color temperature for warm white light).

CARE AND MAINTENANCE

- **Cleaning:** To clean the fixture, wipe it with a soft, damp cloth. Do not use abrasive cleaners, solvents, or polishes as these may damage the finish or electrical components.
- **LED Module:** The integrated LED module is designed for long-lasting performance. If replacement becomes necessary, consult a qualified electrician.
- **Glass Care:** Handle the etched white linen glass with care. Clean with a mild glass cleaner and a soft, lint-free cloth.

TROUBLESHOOTING

If you encounter issues with your fixture, refer to the following common troubleshooting steps:

- **Light does not illuminate:**
 - Check if the power is turned on at the wall switch and circuit breaker.
 - Ensure all wiring connections are secure according to the installation sheet.
- **Light flickers or dims improperly:**
 - Confirm that a compatible LED dimmer switch is being used.
 - Check for loose wiring connections.
 - Consult an electrician if the issue persists after checking connections and dimmer compatibility.
- **Fixture is loose:**
 - Carefully tighten mounting screws securely. Do not overtighten.

WARRANTY INFORMATION

This Progress Lighting product is covered by a **5-year Limited Warranty**. This warranty guarantees your complete satisfaction with your purchase and includes professional after-sales customer service support. For warranty claims or further details, please contact Progress Lighting customer service.

CUSTOMER SUPPORT

For technical assistance, replacement parts, or any questions regarding your Progress Lighting product, please visit the official Progress Lighting website or contact their customer service department. You can also visit the [Progress Lighting Store on Amazon](#) for more information and products.