

Nemco 8045W

Nemco 8045W Wide Hot Dog Roller Grill

45 HOT DOG CAPACITY (120V) INSTRUCTION MANUAL

1. Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and care of your Nemco 8045W Wide Hot Dog Roller Grill. Please read all instructions thoroughly before operating the appliance. Retain this manual for future reference.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- **Electrical Safety:** Ensure the unit is connected to a properly grounded 120V AC power supply. Do not operate with a damaged cord or plug. Keep the power cord away from heated surfaces.
- **Hot Surfaces:** The roller grill surfaces become extremely hot during operation. Use caution and wear protective gloves when handling hot dogs or cleaning. Avoid direct contact with skin.
- **Food Safety:** Maintain proper food temperatures to prevent bacterial growth. Cook hot dogs to an internal temperature of 160°F (71°C).
- **Cleaning:** Disconnect power before cleaning. Allow the unit to cool completely. Do not immerse the unit in water.
- **Ventilation:** Operate the grill in a well-ventilated area.
- **Supervision:** This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.

3. Setup

Follow these steps for initial setup:

1. **Unpacking:** Carefully remove the roller grill from its packaging. Inspect for any shipping damage. Report any damage to your supplier immediately.
2. **Placement:** Place the grill on a stable, level, heat-resistant surface. Ensure adequate clearance around the unit for ventilation and safe operation.
3. **Initial Cleaning:** Before first use, wipe down all surfaces, especially the rollers, with a damp cloth and mild detergent. Rinse thoroughly and dry completely.
4. **Power Connection:** Plug the unit into a dedicated 120V AC grounded electrical outlet.

Note: No relevant product images were found in the provided data for the Nemco 8045W Wide Hot Dog Roller Grill.

4. Operating Instructions

Operating the Nemco 8045W is straightforward:

1. **Preheating:** Turn the temperature control knob to the desired setting (e.g., medium-high). Allow the rollers to preheat for approximately 10-15 minutes until they reach the operating temperature.
2. **Loading Hot Dogs:** Place hot dogs evenly across the non-stick rollers. Avoid overcrowding to ensure even cooking. The grill has a capacity for 45 standard-sized hot dogs.
3. **Cooking:** The rollers will continuously rotate, cooking the hot dogs evenly. Monitor the hot dogs and adjust the temperature control as needed to maintain desired cooking speed and doneness.
4. **Holding:** Once hot dogs are cooked, reduce the temperature setting to a lower holding temperature to keep them warm without overcooking.
5. **Serving:** Use tongs or other appropriate utensils to remove hot dogs from the grill.
6. **Shut Down:** When finished, turn the temperature control knob to the 'OFF' position and unplug the unit from the power outlet.

Note: No relevant product videos were found in the provided data for the Nemco 8045W Wide Hot Dog Roller Grill.

5. Cleaning and Maintenance

Regular cleaning and maintenance ensure optimal performance and longevity of your roller grill.

- **Daily Cleaning:** After each use, ensure the unit is unplugged and completely cool. Wipe down the non-stick rollers and all exterior surfaces with a damp cloth and mild, non-abrasive detergent. Rinse with a clean damp cloth and dry thoroughly.
- **Grease Tray:** Remove and empty the grease drip tray regularly. Wash it with warm, soapy water, rinse, and dry before replacing.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or sharp objects on the non-stick rollers or aluminum surfaces, as this can damage the finish.
- **Inspection:** Periodically inspect the power cord for any signs of damage. Ensure all components are securely in place.

6. Troubleshooting

Refer to this section for common issues and their solutions:

- **Unit Not Heating:**
 - Check if the unit is properly plugged into a live 120V outlet.

- Ensure the temperature control knob is turned to an 'ON' position.
- Check the circuit breaker or fuse.

- **Hot Dogs Not Cooking Evenly:**

- Ensure hot dogs are evenly distributed and not overcrowded.
- Allow sufficient preheating time.
- Adjust the temperature setting.

- **Rollers Not Rotating:**

- Check for obstructions preventing roller movement.
- Ensure the unit is powered on.

7. Specifications

Model Number	8045W (Part Number: Hot-8045W)
Capacity	45 Hot Dogs
Voltage	120 Volts
Material	Aluminum
Special Feature	Non Stick Coating
UPC	749628423975
ASIN	B016SII324

8. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact Nemco customer service directly. Keep your purchase receipt for warranty claims.