

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Prestige](#) /

› [Prestige Audiovox 145SP Replacement Car Remote Transmitter User Manual](#)

## Prestige 145SP

# Prestige Audiovox 145SP Replacement Car Remote Transmitter User Manual

## INTRODUCTION

---

This manual provides comprehensive instructions for the proper setup, operation, and maintenance of your Prestige Audiovox 145SP Replacement Car Remote Transmitter. Please read these instructions carefully before attempting to program or use your new remote to ensure optimal performance and compatibility with your vehicle's security system, specifically APS997E and APS787E models.

## PRODUCT OVERVIEW

---

The Prestige Audiovox 145SP is a 1-way replacement remote transmitter designed for select Audiovox and Prestige vehicle security and remote start systems. It features a durable black casing and multiple buttons for controlling various functions of your vehicle's system. This remote operates on a single CR2032 battery.



## SETUP AND PROGRAMMING

---

Programming your new 145SP remote transmitter requires access to your vehicle's ignition and the system's valet/programming button. The valet button is typically a small push-button switch located under the dashboard, near the fuse box, or sometimes integrated into the system's antenna module (often found near the rearview mirror). Consult your vehicle's security system installation manual if you cannot locate the valet button.

### Programming Steps:

1. **Prepare the Vehicle:** Enter your vehicle and close all doors.
2. **Ignition ON:** Insert your vehicle key into the ignition and turn it to the 'ON' position. Do not start the engine.
3. **Activate Programming Mode:** Within 10 seconds of turning the ignition to 'ON', press and release the system's valet/programming button three (3) times. You should hear a confirmation sound (e.g., a honk, beep, or clicking from the instrument dash) indicating the system is in programming mode.
4. **Program the Remote:** Within 5 seconds of hearing the confirmation sound, press and hold the 'LOCK' button on your new 145SP remote transmitter. Continue holding until you hear another confirmation sound (e.g., a honk or beep), which signifies successful programming.
5. **Exit Programming Mode:** Turn the vehicle's ignition to the 'OFF' position and remove the key. The system will automatically exit programming mode.
6. **Test the Remote:** Test all functions of your new remote (Lock, Unlock, Start, Panic) to ensure it operates correctly.

*Note: If programming is unsuccessful, ensure you are performing the steps within the specified timeframes. The timing is critical for the system to enter and exit programming mode correctly.*

## OPERATING INSTRUCTIONS

---

Your Prestige Audiovox 145SP remote transmitter provides convenient control over your vehicle's security and remote start features. The typical button functions are as follows:

- **Lock Button:** Press once to arm the security system and lock the vehicle doors.
- **Unlock Button:** Press once to disarm the security system and unlock the vehicle doors.
- **Start Button:** Press and hold for approximately 2-3 seconds to remotely start your vehicle (if equipped and enabled).
- **Panic Button:** Press and hold for approximately 2-3 seconds to activate the vehicle's alarm system (horn and lights). Press again to deactivate.

## MAINTENANCE

---

### Battery Replacement:

The 145SP remote transmitter is powered by one CR2032 lithium coin cell battery. When the remote's range decreases significantly or it stops responding, it's time to replace the battery.

1. **Open the Casing:** Carefully pry open the remote's casing using a small flat-head screwdriver or a coin at the designated notch.

2. **Remove Old Battery:** Note the orientation (+/-) of the old battery and gently remove it.
3. **Insert New Battery:** Insert a new CR2032 battery with the positive (+) side facing up, matching the orientation of the old battery.
4. **Close Casing:** Snap the two halves of the remote casing back together until it is securely closed.

### General Care:

- Avoid exposing the remote to extreme temperatures, direct sunlight for extended periods, or moisture.
- Do not drop the remote or subject it to strong impacts.
- Clean the remote with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote does not program.	Incorrect programming steps or timing. Valet button not located or pressed correctly.	Review the 'Setup and Programming' section carefully. Ensure the valet button is pressed three times within 10 seconds of turning the ignition ON, and the remote's LOCK button is pressed within 5 seconds of the system's confirmation sound. Confirm the valet button's location.
No confirmation sound during programming.	Valet button not activated, or system not entering programming mode.	Ensure the ignition is in the 'ON' position. Verify the valet button is being pressed firmly and correctly. Listen for subtle clicks from the instrument panel if no honk/beep occurs.
Remote range is poor or inconsistent.	Low battery. Interference.	Replace the CR2032 battery. Avoid using the remote near strong radio frequency sources.
Remote functions are unresponsive.	Dead battery. Remote not programmed. System issue.	Replace the battery. Re-attempt programming the remote. If issues persist, consult a professional installer for your vehicle's security system.

## SPECIFICATIONS

- **Model Number:** 145SP
- **Brand:** Prestige
- **Compatibility:** Audiovox APS997E, APS787E (and other compatible Prestige/Audiovox systems)
- **Connectivity Technology:** Infrared (IR)
- **Power Source:** 1 x CR2032 Battery (included)
- **Item Weight:** Approximately 22.68 grams (0.8 ounces)
- **Dimensions (L x W x H):** Approximately 2" x 2" x 2"
- **Maximum Range:** Up to 12400 feet (line of sight, actual range may vary)
- **Color:** Black

## WARRANTY AND SUPPORT

---

This Prestige Audiovox 145SP Replacement Car Remote Transmitter is covered by a manufacturer's warranty against defects in materials and workmanship. For specific warranty details, including duration and terms, please refer to the documentation provided with your original vehicle security system or contact Prestige customer support directly. For technical assistance or further inquiries, please visit the official Prestige website or contact their customer service department.