

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Criacr](#) /

> [Criacr Phone Camera Lens Kit \(Model CP4\) Instruction Manual](#)

## Criacr CP4

# Criacr Phone Camera Lens Kit

MODEL: CP4 - INSTRUCTION MANUAL

## 1. Introduction

---

The Criacr 3-in-1 HD Camera Lens Kit is designed to enhance your mobile photography experience. This kit includes a 0.4X Wide Angle Lens, a 180° Fisheye Lens, and a 10X Macro Lens. These lenses are compatible with a wide range of smartphones, including iPhone and Samsung Galaxy models, as well as iPads and PCs. The professional-grade lenses are portable and easy to use, allowing you to explore new photographic perspectives directly from your mobile device.

## 2. Package Contents

---

Please verify that all items listed below are included in your package:

- 1 x 0.4X Super Wide Angle Lens
- 1 x 180° Fisheye Lens (attached to Macro Lens)
- 1 x 10X Macro Lens (attached to Fisheye Lens)
- 1 x Universal Lens Clip
- 2 x Lens Caps (for both ends of the assembled lens)
- 1 x Microfiber Lens Cleaning Cloth Bag



Image: All components of the Criacr 3-in-1 Phone Camera Lens Kit, including the wide-angle, fisheye, and macro lenses, universal clip, lens caps, and cleaning cloth bag.

### 3. Product Features

- **Upgraded 3-in-1 Phone Camera Lens Kit:** Includes a 180° fisheye lens, a 0.6X wide-angle lens, and a 15X macro lens. Designed for higher lens clarity, minimal vignetting, and reduced micro distortion.
- **High Clarity & Professional Design:** Crafted from high-class glass, these professional HD lenses reduce glass flare and ghosting. The lightweight and strong shell, along with a PVC-made clip, prevent scratching your cell phone.
- **Separate Lenses for Versatile Use:** Each lens can be used independently. The macro lens and fisheye lens are initially attached; unscrew the fisheye lens to use the macro lens alone. To use the fisheye lens, keep the macro lens attached.
- **Enhanced Photography Options:**
  - **180° Fisheye Lens:** Captures a unique, circular, and distorted image for a fun, wide perspective.
  - **10X Macro Lens:** Allows for capturing amazing close-up shots with crisp detail, focusing on objects as close as 10-15mm.

- **0.4X Wide Angle Lens:** Expands your field of view, enabling you to capture larger scenes and broader landscapes.
- **Wide Compatibility:** Compatible with most smartphones, including various iPhone models (e.g., 11, X, 8, 7, 6S, 5S, SE) and Samsung Galaxy models (e.g., S9, S8, S7, S6 Edge), HUAWEI, Xiaomi, Google Pixel, and iPads.

**criacr**

## HD 3 IN 1 PHONE CAMERA LENS KIT

NO distortion, NO color difference, NO vignetting  
EXTREMELY CLEARNESS-Shoot the most amazing pictures for your life!!!



Image: Visual representation of the 3-in-1 lens kit highlighting its features and components.

## 4. Setup

Follow these steps to properly set up your Criacr Phone Camera Lens Kit:

### 1. Prepare the Lenses:

- a. The 180° Fisheye Lens and 10X Macro Lens are attached together upon receipt.
- b. To use the **10X Macro Lens**: Gently unscrew the 180° Fisheye Lens from the Macro Lens. The Macro Lens is the smaller, inner lens.
- c. To use the **180° Fisheye Lens**: Keep the 10X Macro Lens attached to the Fisheye Lens. They function as a single unit for fisheye photography.
- d. The **0.4X Super Wide Angle Lens** is a separate unit.

### 2. Attach to the Universal Clip:

- a. Select the desired lens (Macro, Fisheye, or Wide Angle).
- b. Screw the chosen lens securely onto the threaded part of the universal lens clip.

### 3. Position on Your Phone:

- a. Carefully clip the assembled lens onto your smartphone, ensuring the lens is perfectly aligned with your phone's main camera.
- b. For optimal results, it is recommended to remove your phone case before attaching the lens. This ensures a snug fit and prevents potential vignetting or obstruction.
- c. Ensure the clip aims at the correct camera lens if your phone has multiple cameras.

4. **Remove Lens Caps:** Once the lens is securely attached and aligned, remove the protective lens caps from both ends of the lens.



## Steady Clip-On Design


The detachable and anti-slip clip securely fastens to your phone

Image: A smartphone with the Criacr lens attached using the universal clip, demonstrating the steady clip-on design.

## 5. Operating Instructions

Each lens offers a unique photographic effect:

- **Using the 10X Macro Lens:**
  - This lens is designed for extreme close-up photography.
  - Ensure the Fisheye Lens is unscrewed from the Macro Lens.
  - Position your phone very close to the subject (10-15mm distance) to achieve sharp focus and capture intricate details.




## 15X Macro Lens

Enables closeups of the miniature world for capturing sharp, vivid detail

Image: A detailed close-up of a butterfly on a flower, demonstrating the capabilities of the 15X Macro Lens.

- **Using the 0.4X Super Wide Angle Lens:**

- This lens expands your phone's field of view, allowing you to capture more of the scene.
- It is ideal for landscape photography, group photos, or capturing architectural shots.
- Ensure the lens is properly aligned to minimize any potential edge distortion.



## 0.4X-0.6X Wide Angle Lens

Provides wider angle of view to help you produce spectacular images



Image: A comparison showing a wider field of view achieved with the 0.4X Wide Angle Lens compared to a standard phone camera.

- **Using the 180° Fisheye Lens:**

- This lens creates a unique, spherical, or barrel-distorted effect, giving your photos a distinct artistic look.
- Remember to keep the Macro Lens attached to the Fisheye Lens when using this function.
- Experiment with different subjects and distances to achieve various creative fisheye effects.

## 180° Fisheye Lens

Delivers a unique perspective and creates a fun image with unusual feel



Image: A collage of images demonstrating the 180° fisheye effect, including architectural shots and a close-up of an animal.

## 6. Maintenance

To ensure the longevity and optimal performance of your Criacr Phone Camera Lenses:

- Always wipe clean all lenses with the provided microfiber cleaning cloth before and after each use to remove dust, fingerprints, and smudges.
- Store the lenses with their caps on in the cleaning cloth bag when not in use to protect them from scratches and dust.
- Avoid touching the lens glass directly with your fingers.
- Do not use harsh chemicals or abrasive materials to clean the lenses.

## 7. Troubleshooting

- **Vignetting (Dark corners in photos):**
  - Ensure the lens is perfectly centered over your phone's camera.
  - Remove your phone case if you are using one, as thicker cases can sometimes cause vignetting.

- **Blurry or unclear images:**
  - Clean the lens thoroughly with the microfiber cloth.
  - Ensure the lens is securely screwed onto the clip and properly aligned with your phone's camera.
  - For macro photography, ensure the lens is very close to the subject (10-15mm).
  - Note that these lenses enhance your phone's camera capabilities but cannot change the original pixel quality of your phone's camera.
- **Flashlight obstruction:** The design of these lenses is intended not to block the flashlight, even if the edge is close to it. If you experience issues, re-check alignment.

## 8. Specifications

Feature	Detail
Product Dimensions	6.24 x 1.17 x 4.29 inches
Item Weight	1.6 ounces
Model Number	CP4
Lens Type	Fisheye, Wide Angle, Macro
Fisheye Lens Angle	180°
Wide Angle Lens Magnification	0.4X (stated as 0.6X in feature bullets, using 0.4X from product description)
Macro Lens Magnification	10X (stated as 15X in feature bullets, using 10X from product description)
Macro Lens Min Object Distance	10-15mm
Compatible Mountings	iPhone (12 Pro Max, 12 Pro, 12, 11, XS MAX, XS, XR, X, 8Plus, 8, 7Plus, 7, 6Plus, 6, 5S, SE), Samsung Galaxy (A51, S9, S8, S7, S6 Edge), HUAWEI, Xiaomi, Google Pixel 5, iPad, and most other smartphones.
Manufacturer	Shenzhen Amier Technology Co.,Ltd.
Date First Available	October 28, 2015

## 9. Warranty and Support

Criacr is committed to providing high-quality products and excellent customer service. The following policies apply to your purchase:

- **45-Day Money Back Guarantee:** If you are not satisfied with your purchase, you may return it within

45 days for a full refund.

- **12-Month Replacement Warranty:** Your product is covered by a 12-month warranty for any manufacturing defects or malfunctions.
- **7/24 Online Customer Service:** Customer support is available 24 hours a day, 7 days a week for any inquiries or assistance.
- **Lifetime Support Guarantee:** Criacr offers lifetime support for its products.

For further assistance, please refer to the contact information provided with your product packaging or visit the official Criacr website.