

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [TIMBER RIDGE](#) /
- › Timber Ridge Zero Gravity Chair Instruction Manual

TIMBER RIDGE Zero Gravity

Timber Ridge Zero Gravity Chair Instruction Manual

Model: Zero Gravity

INTRODUCTION

Thank you for choosing the Timber Ridge Zero Gravity Chair. This oversized recliner is designed for ultimate comfort and durability, perfect for outdoor relaxation. Please read this manual carefully to ensure proper setup, operation, and maintenance of your chair.



Image: Two individuals enjoying the comfort of Timber Ridge Zero Gravity Chairs in a serene outdoor environment, highlighting the chair's suitability for relaxation.

PRODUCT FEATURES

- **Outstanding Loading Capacity:** Supports up to 350 lbs with a sturdy steel tube frame, premium elastic cord, and durable polyester fabric.
- **Adjustable Reclining Position:** Features a patented locking mechanism for easy adjustment from upright to fully laid-back.
- **Oversized Dimension:** Measures 43.5 x 22 x 21.3 inches (fully reclined length is 72 inches), providing ample space for relaxation.
- **Comfortable Design:** Full padded seating, removable head and lumbar support pillow, ergonomic design, and natural wood armrests for a weightless experience.
- **No Assembly Required:** Folds and unfolds in seconds for easy transportation and storage.
- **Included Cup Holder:** A convenient cup holder is included for your beverages.



Image: Detailed view of the chair's key features: the removable padded pillow, the durable bungee suspension system, natural wood armrests, the adjustable reclining mechanism, and a non-slip mat on the feet.

SETUP

Your Timber Ridge Zero Gravity Chair comes pre-assembled and is designed for quick setup. Simply unfold the chair to its desired position. No tools or additional assembly are required.

1. Remove the chair from its packaging.
2. Gently pull the frame apart to unfold the chair.
3. Ensure all legs are fully extended and stable on a flat surface.
4. Attach the removable headrest pillow to the desired height using its integrated straps.
5. Slide the cup holder onto the side frame until it clicks securely into place.



Image: The chair is displayed both folded for compact storage and fully extended, illustrating the ease of unfolding for use.

OPERATING INSTRUCTIONS

Reclining and Locking the Chair

The chair features an easy-to-use reclining and locking mechanism:

1. To recline, gently push back on the armrests while applying slight pressure with your feet on the footrest. The chair will smoothly glide into a reclined position.
2. Once you reach your desired recline angle, locate the locking levers on both sides beneath the armrests.
3. Push the levers downwards to engage the patented locking mechanism. This will secure the chair in your chosen position.

- To return to an upright position, lift the locking levers upwards to release the mechanism, then gently push forward with your feet and lean forward.



Image: A visual representation of the chair's adjustable reclining range, from 0 to 170 degrees, emphasizing the stability provided by its triangular frame design.

CARE AND MAINTENANCE

- **Cleaning:** Wipe clean with a damp cloth and mild soap. Avoid harsh chemicals that may damage the fabric or frame.
- **Storage:** When not in use, especially during inclement weather, fold the chair and store it in a dry, protected area to prolong its lifespan.
- **Armrests:** The natural wood armrests should be protected from prolonged exposure to strong sunlight and heavy rain to prevent weathering.
- **Inspection:** Periodically check all bolts, screws, and elastic cords to ensure they are secure and in good condition. Tighten any loose fasteners.




Image: A detailed shot of the chair's natural wood armrest, emphasizing its material and finish, which requires protection from harsh weather.

SPECIFICATIONS

Brand:	TIMBER RIDGE
Model Name:	Zero Gravity
Product Dimensions (Upright):	21.3"D x 22"W x 43.5"H
Fully Reclined Length:	72 inches
Maximum Weight Capacity:	350 Pounds
Item Weight:	24.3 pounds
Material:	Elastic and Polyester
Arm Style:	Natural Wood
Included Components:	Cup holder, Removable Headrest Pillow



Image: Technical drawing showing the key dimensions of the chair, including width, height, and reclined length, to help users understand its size.

WARRANTY INFORMATION

The Timber Ridge Zero Gravity Chair comes with a full 1-year manufacturer's warranty. Please retain your proof of purchase for any warranty claims. For support, please visit the [TIMBER RIDGE Store](#) or contact customer service.

VISUAL GUIDE & DEMONSTRATIONS

Product Overview and Features

Your browser does not support the video tag.

Video: A comprehensive overview of the Colegence XL Oversized Zero Gravity Chair, demonstrating its features, including the cup holder and reclining capabilities. Note: This video is from a seller and is relevant to the product type.

Reclining Mechanism Demonstration

Your browser does not support the video tag.

Video: A demonstration of the Timber Ridge Zero Gravity Patio Lounge Chair's reclining function, showcasing how easily it adjusts to different positions. Note: This video is from a merchant and is relevant to the product.

© 2024 TIMBER RIDGE. All rights reserved.