

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Westinghouse](#) /

› [Westinghouse 6343400 Iron Hill 3-Light Wall Fixture Instruction Manual](#)

## Westinghouse 6343400

# Westinghouse 6343400 Iron Hill 3-Light Wall Fixture Instruction Manual

Model: 6343400 | Brand: Westinghouse

## INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Westinghouse 6343400 Iron Hill 3-Light Wall Fixture. Please read all instructions carefully before beginning installation and retain this manual for future reference.

## SAFETY INFORMATION

**WARNING: RISK OF ELECTRIC SHOCK. Disconnect power at the circuit breaker or fuse box before installation or servicing. Improper installation can result in electric shock or fire.**

- All wiring must be in accordance with national and local electrical codes.
- If you are unsure about wiring, consult a qualified electrician.
- Do not exceed the maximum wattage specified for the light bulbs.
- Ensure all connections are secure and properly insulated.
- This fixture is designed for indoor use only.

## PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x Fixture Body (Oil Rubbed Bronze)
- 3 x White Metal Shades
- Mounting Hardware (screws, wire nuts, mounting plate)
- Instruction Manual

## TOOLS REQUIRED

The following tools are typically required for installation:

- Phillips Head Screwdriver

- Flathead Screwdriver
- Wire Strippers
- Pliers
- Electrical Tape
- Safety Glasses
- Ladder

## SETUP AND INSTALLATION

---

Follow these steps to install your wall fixture:

**1. Prepare for Installation:**

Turn off power at the circuit breaker or fuse box. Ensure the power is off before proceeding.

**2. Attach Mounting Plate:**

Secure the mounting plate to the junction box in the wall using the provided screws. Ensure the plate is level and firmly attached.

**3. Wire Connections:**

Connect the fixture's wires to the corresponding house wires. Connect the black wire (live) to the black house wire, the white wire (neutral) to the white house wire, and the green/bare copper wire (ground) to the house ground wire. Use wire nuts to secure connections and wrap with electrical tape for added safety.

**4. Mount the Fixture:**

Carefully align the fixture body with the mounting plate and secure it with the decorative nuts or screws provided.

**5. Install Shades:**

Attach the three white metal shades to the fixture. Ensure they are securely fastened.

**6. Insert Light Bulbs:**

Screw in three medium-base light bulbs (not included), up to 60-watt maximum each. For a vintage aesthetic, Westinghouse Timeless Vintage Inspired light bulbs are recommended.

**7. Restore Power:**

Turn the power back on at the circuit breaker or fuse box. Test the light fixture.



Image: The Westinghouse Iron Hill 3-Light Wall Fixture in Oil Rubbed Bronze with White Shades.



Image: A close-up view of the fixture's base, highlighting the oil rubbed bronze finish and mounting details.



Image: The Westinghouse Iron Hill 3-Light Wall Fixture installed above a mirror in a bathroom setting.

## OPERATING INSTRUCTIONS

This fixture operates with a standard wall switch (not included). Ensure appropriate light bulbs are installed

for desired illumination.

- **Bulb Replacement:** Always turn off power at the circuit breaker before replacing bulbs. Allow bulbs to cool completely before touching.
- **Dimmer Compatibility:** This fixture is compatible with most standard dimmer switches, provided the installed bulbs are also dimmable.

## MAINTENANCE

Regular cleaning and care will help maintain the appearance and functionality of your fixture.

- **Cleaning:** Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

## TROUBLESHOOTING

| Problem                | Possible Cause   | Solution  |
|------------------------|--|---|
| Light does not turn on | 1. Power is off<br>2. Loose wiring connection<br>3. Faulty bulb        | 1. Check circuit breaker/fuse<br>2. Verify all wire connections are secure (power off first)<br>3. Replace bulb |
| Flickering light       | 1. Loose bulb<br>2. Incompatible dimmer switch/bulb<br>3. Loose wiring | 1. Tighten bulb<br>2. Ensure dimmer and bulbs are compatible<br>3. Check wiring connections (power off first)   |

## SPECIFICATIONS

- **Brand:** Westinghouse
- **Model Name:** Iron Hill
- **Part Number:** 6343400
- **Color:** Oil Rubbed Bronze with White Shades
- **Material:** Metal
- **Style:** Wall Fixture
- **Light Fixture Form:** Vanity
- **Room Type:** Bathroom, Dining Room, Kitchen, Living Room
- **Product Dimensions:** 29.06" L x 9.63" W x 7.75" H
- **Power Source:** Corded Electric
- **Installation Type:** Wall Mount
- **Light Source Type:** LED (compatible)
- **Finish Type:** Oil Rubbed Bronze Finish with Highlights and Metal Shades
- **Shade Material:** Metal
- **Number of Light Sources:** 3
- **Voltage:** 120 Volts
- **Bulb Base:** E26 (Medium-base)

- **Wattage:** 60 watts maximum per bulb
- **Item Weight:** 5.3 Pounds
- **Water Resistance Level:** Not Water Resistant

## WARRANTY AND SUPPORT

---

This Westinghouse fixture comes with a **Five-year limited warranty** against defects in materials and workmanship.

For technical assistance, replacement parts, or warranty claims, please contact Westinghouse customer support. Refer to the product packaging or the official Westinghouse website for the most current contact information.

---