

Hampton Bay 16033KITV-BK

Hampton Bay Black Dimmable LED Track Kit User Manual

INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of your Hampton Bay Black Dimmable LED Track Kit. Please read this manual thoroughly before installation and retain it for future reference.

The Hampton Bay 3 Light Track Lighting Kit features a black finish, a 39.37 inch linear track, a floating power canopy, and three multi-directional track heads. It includes mounting hardware and 120-Volt LED lamps, providing warm light suitable for various indoor applications.

IMPORTANT SAFETY INFORMATION

WARNING: Risk of electric shock. Disconnect power at the circuit breaker before installation or servicing.

- Always follow local electrical codes and regulations.
- Ensure the power supply is turned off before handling any electrical components.
- If you are unsure about wiring or installation, consult a qualified electrician.
- Do not install this fixture in wet locations. This product is designed for indoor use only.
- Use only with 120 Volts AC.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x 39.37 inch Linear Track
- 1 x Floating Power Canopy
- 3 x Multi-directional Track Heads
- 3 x LED Bulbs
- Mounting Hardware



Image: Overview of the Hampton Bay Black Dimmable LED Track Kit, showing the black linear track with three adjustable track heads and included LED bulbs.

SETUP AND INSTALLATION

- 1. Prepare for Installation:** Turn off power at the main circuit breaker. Clear the installation area.
- 2. Mounting the Track:** This fixture is designed for ceiling mount installation. Secure the linear track to the ceiling using the provided mounting hardware. Ensure the track is firmly attached to a structural element or appropriate ceiling box.
- 3. Connecting Power:** Connect the floating power canopy to the electrical supply wires in the ceiling junction box. Follow standard wiring procedures: connect live to live, neutral to neutral, and ground to ground. Ensure all connections are secure.
- 4. Attaching Track Heads:** Insert the three multi-directional track heads into the linear track. Ensure they are properly seated and locked into place.
- 5. Installing Bulbs:** Insert the included LED bulbs into each track head.
- 6. Final Check:** Once all components are installed and secured, restore power at the circuit breaker.

Assembly is required for this product. Refer to the detailed diagrams in the full installation guide (not included in this summary) for specific steps.

OPERATING INSTRUCTIONS

- Power On/Off:** Use your wall switch to turn the track lighting system on or off.
- Dimmable Feature:** This track kit is dimmable. To utilize the dimming function, ensure you have a compatible LED dimmer switch installed (sold separately).
- Adjusting Light Direction:** The track heads are multi-directional and adjustable. Gently pivot and rotate each track head to direct light as desired.
- Control Method:** This fixture supports control via an app and remote control. Refer to the specific instructions for pairing and using these control methods (if applicable and provided with your purchase).

MAINTENANCE

- Cleaning:** Disconnect power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- Bulb Replacement:** Ensure power is off before replacing bulbs. Allow bulbs to cool completely before handling. Replace with compatible LED bulbs of the same wattage and base type.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture; loose wiring; faulty bulb.	Check circuit breaker. Verify all wire connections. Replace bulb.
Lights flicker.	Loose bulb; incompatible dimmer switch; unstable power supply.	Tighten bulbs. Ensure dimmer is LED compatible. Consult electrician for power issues.
Dimming not working.	Non-dimmable bulbs; incompatible dimmer switch.	Ensure bulbs are dimmable. Use an LED compatible dimmer switch.

SPECIFICATIONS

- **Brand:** Hampton Bay
- **Model Number:** 16033KITV-BK
- **Color:** Black
- **Material:** Metal (Shade Material: Plastic)
- **Style:** Modern
- **Light Fixture Form:** Track Light Head
- **Product Dimensions:** 40.25"L x 4.5"W x 4.75"H
- **Indoor/Outdoor Usage:** Indoor
- **Power Source:** Corded Electric
- **Installation Type:** Ceiling Mount
- **Special Feature:** Dimmable
- **Control Method:** App, Remote Control
- **Light Source Type:** LED
- **Finish Type:** Painted
- **Number of Light Sources:** 3
- **Voltage:** 120 Volts
- **Light Color:** Warm White
- **Included Components:** Bulb
- **Lighting Method:** Adjustable
- **Specification Met:** Energy Star
- **Item Weight:** 5.2 Pounds
- **Wattage:** 14.21 watts
- **Brightness:** 802 Lumen
- **Assembly Required:** Yes

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Hampton Bay customer service. Keep your proof of purchase for warranty claims.
For additional assistance, visit the [Hampton Bay brand page on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question