

[manuals.plus](#) /› [Armitron](#) /› [Armitron Women's 75/5338 Leather Strap Watch User Manual](#)**Armitron 75/5338**

Armitron Women's 75/5338 Leather Strap Watch User Manual

Model: 75/5338

1. INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Armitron Women's 75/5338 Leather Strap Watch. Please read this manual carefully to ensure proper use and care of your timepiece.

The Armitron 75/5338 is a women's watch featuring a gold-tone case, a black dial with dauphine hands and alternating Arabic/stick markers, and a black leather strap. It is powered by a Japanese quartz movement.

2. SETUP

2.1 Unboxing and Initial Inspection

Upon receiving your watch, carefully remove it from its packaging. Inspect the watch for any visible damage or missing components.



Image: The Armitron watch box, typically black with the brand logo. This is how your watch will be packaged.

2.2 Setting the Time

- 1. Locate the Crown:** The crown is the small knob located on the right side of the watch case.
- 2. Pull Out the Crown:** Gently pull the crown outwards to the time-setting position. You may feel a slight click.
- 3. Adjust the Time:** Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time.
- 4. Push In the Crown:** Once the correct time is set, push the crown back into its original position against the watch case. This will start the watch movement.





Image: Close-up of the Armitron 75/5338 watch, showing the dial, hands, and the crown on the right side of the case.

2.3 Wearing the Watch and Strap Adjustment

Place the watch on your wrist and fasten the leather strap using the buckle. Ensure the strap is snug but comfortable, allowing for proper blood circulation. The leather strap will naturally conform to your wrist over time.



Image: The Armitron 75/5338 watch worn on a wrist, demonstrating how the leather strap fits.

3. OPERATING YOUR WATCH

3.1 Basic Timekeeping

Your Armitron 75/5338 watch is designed for reliable timekeeping. Once the time is set, the watch will continuously display the current time using its hour, minute, and second hands.

3.2 Water Resistance

This watch is water resistant. This generally means it is suitable for everyday use and can withstand splashes or brief immersion in water, such as washing hands or light rain. It is **not** recommended for swimming, showering, or diving, as prolonged water exposure or high water pressure can damage the watch. Always ensure the crown is fully pushed in to maintain water resistance.

4. MAINTENANCE AND CARE

4.1 Cleaning Your Watch

- Case and Crystal:** Wipe the watch case and crystal (glass) with a soft, dry, lint-free cloth. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying.
- Leather Strap:** Avoid exposing the leather strap to excessive moisture, direct sunlight, or harsh chemicals, as these can cause damage or discoloration. Wipe the strap with a dry cloth to remove surface dirt.

4.2 Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. The original watch box is ideal for storage.

4.3 Battery Replacement

Your watch is powered by one LR44 battery (included). When the watch stops running, it indicates the battery needs replacement. It is recommended to have the battery replaced by a qualified watch technician

to ensure proper sealing and maintain water resistance.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch is not running.	<ul style="list-style-type: none">Battery is depleted.Crown is not fully pushed in.	<ul style="list-style-type: none">Replace the battery (professional service recommended).Push the crown firmly back into the case.
Time is incorrect.	<ul style="list-style-type: none">Time was not set correctly.Crown was accidentally pulled out.	<ul style="list-style-type: none">Refer to Section 2.2 "Setting the Time" to reset.Ensure the crown is fully pushed in after setting.
Moisture under the crystal.	<ul style="list-style-type: none">Water resistance compromised.Exposure to extreme temperature changes.	<ul style="list-style-type: none">Seek professional service immediately to prevent further damage.

6. SPECIFICATIONS

Model Number	75/5338BKGPBK
Movement Type	Japanese Quartz
Case Diameter	30 Millimetres
Band Material	Leather
Band Color	Black
Battery Type	1 LR44 battery (included)
Item Weight	136 g
Product Dimensions	17.78 x 68.58 x 27.94 cm
Manufacturer	Armitron

7. WARRANTY AND SUPPORT

7.1 Warranty Information

The warranty type for this product is "Contact seller of record". Please refer to your purchase documentation or contact the seller directly for specific warranty terms and conditions.

7.2 Customer Support

For any questions, concerns, or technical assistance not covered in this manual, please contact Armitron customer support or the retailer from whom you purchased the watch.

Related Documents - 75/5338

 MB33	<p><u>Armitron M833 Watch: Instructions Manual & Limited Lifetime Warranty</u></p> <p>Detailed instructions manual and limited lifetime warranty information for the Armitron M833 watch. Learn how to operate features like the chronograph, alarms, countdown timer, and second time zone, plus find information on battery replacement, water resistance, and service.</p>
	<p><u>Armitron Watch Instructions: Setting Time, Adjusting & Changing Straps</u></p> <p>Comprehensive guide to setting the time, adjusting the size of steel and mesh bands, and changing straps for Armitron watches. Includes step-by-step instructions for operation and maintenance.</p>
 MB33	<p><u>Armitron M833 Digital Sports Watch: Complete Instructions Manual</u></p> <p>Get detailed instructions for your Armitron M833 digital sports watch. Learn how to set time, use the chronograph, alarms, countdown timer, and understand water resistance and service options.</p>
 MD16388	<p><u>Armitron Adventure MD16388 Digital Watch: Features, Instructions, and Limited Lifetime Warranty</u></p> <p>Detailed instructions and warranty information for the Armitron Adventure MD16388 digital watch. Learn about its features including time telling, alarms, chronograph, world time, pedometer, and countdown timer. Includes setup, operation, water resistance, battery replacement, and service center details.</p>
 AD1159	<p><u>Armitron AD1159 Pro-Sport Watch Instructions Manual</u></p> <p>Detailed instructions manual for the Armitron AD1159 Pro-Sport watch, covering features, operation, battery replacement, water resistance, and service information.</p>

ARMITRON

INSTRUCTIONS AND
LIMITED LIFETIME WARRANTY

ANALOG
VISIT US AT OUR WEBSITE
www.armitron.com

[Armitron Analog Watch Instructions and Limited Lifetime Warranty](#)

Comprehensive guide to setting, maintaining, and understanding the warranty for Armitron analog watches, including solar and automatic models, water resistance, and bracelet adjustment.