

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [IKEA](#) /
- › [IKEA HOPPVALS Insulating Blind, White \(60290624\) Instruction Manual](#)

IKEA 602.906.24

IKEA HOPPVALS Insulating Blind Instruction Manual

Model: 602.906.24

1. INTRODUCTION

Thank you for choosing the IKEA HOPPVALS insulating blind. This manual provides comprehensive instructions for the safe and effective assembly, installation, operation, and maintenance of your new blind. Please read this manual carefully before beginning installation and keep it for future reference.

The HOPPVALS blind is designed to help regulate indoor temperature by providing insulation, while also softening incoming sunlight and offering privacy by blocking outside views. Its cellular structure traps air, contributing to energy efficiency.

2. SAFETY INFORMATION

Always follow basic safety precautions when installing and operating this product.

- Ensure all mounting hardware is securely fastened to a suitable wall or ceiling material. Use appropriate anchors for your wall type.
- Keep small children and pets away from the blind during installation to prevent accidents.
- Do not attempt to modify the blind or its components, as this may void the warranty and create safety hazards.
- If any parts are missing or damaged, contact IKEA customer service immediately.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

Item	Description	Quantity
Hoppvals Blind Unit	Pre-assembled cellular blind	1
Mounting Brackets	For wall or ceiling installation	2-3 (depending on width)
Screws and Wall Plugs	Hardware for mounting	Varies
Handle/Pull Cord	For operating the blind	1

4. SETUP AND INSTALLATION

The HOPPVALS blind can be mounted either on the wall or the ceiling. Choose the appropriate location and ensure the surface is suitable for drilling.

4.1 Tools Required

- Pencil
- Measuring Tape
- Drill
- Spirit Level
- Screwdriver (Phillips head)

4.2 Mounting Instructions

1. **Measure and Mark:** Hold the blind in the desired position and use a pencil to mark the locations for the mounting brackets. Ensure the marks are level using a spirit level. For wall mounting, position brackets above the window frame. For ceiling mounting, position them inside the window recess or on the ceiling directly.
2. **Drill Holes:** Drill pilot holes at the marked locations. Use a drill bit appropriate for your wall or ceiling material and the provided wall plugs.
3. **Attach Brackets:** Insert the wall plugs (if necessary) and then screw the mounting brackets securely into place.
4. **Install Blind:** Carefully lift the HOPPVALS blind and snap its top rail into the installed mounting brackets. Ensure it clicks firmly into place.
5. **Attach Handle:** Slide the provided handle onto the bottom rail of the blind.



Image Description: This image shows a close-up view of the top section of the IKEA HOPPVALS insulating blind, highlighting the white top rail and the pleated cellular fabric. The mounting clip is visible, indicating how the blind attaches to the brackets. The blind is shown against a light-colored wall, suggesting a typical installation scenario.



Image Description: This image provides a side profile view of the IKEA HOPPVALS blind, clearly illustrating its unique cellular (honeycomb) structure. This design is key to its insulating properties. The white fabric is neatly folded, and the top rail is visible, showing the clean, minimalist design.

5. OPERATING INSTRUCTIONS

The HOPPVALS blind is designed for simple manual operation.

1. **To Lower the Blind:** Gently pull down on the handle located at the bottom rail of the blind. The blind will smoothly extend downwards. Release the handle at the desired height.
2. **To Raise the Blind:** Gently push up on the handle. The blind will retract upwards. Release the handle when the blind reaches the desired position.

The blind features a cordless design for enhanced safety and ease of use, allowing it to stay in place at any height.



Image Description: This image shows a person's hand demonstrating the operation of the IKEA HOPPVALS blind. The hand is gently pushing upwards on the handle attached to the bottom rail of the blind, indicating the action to raise the blind. The blind is partially open, revealing a window with outdoor greenery in the background.

6. MAINTENANCE AND CARE

To ensure the longevity and appearance of your HOPPVALS blind, follow these simple care instructions:

- **Cleaning:** Dust the blind regularly with a feather duster or a soft cloth. For deeper cleaning, gently vacuum with a brush attachment on low suction. Do not wet the fabric or use harsh cleaning agents.
- **Spot Cleaning:** For small spots, gently dab with a damp cloth and mild soap. Blot dry immediately. Test on an inconspicuous area first.
- **Avoid Direct Sunlight:** While the blind is designed to soften sunlight, prolonged exposure to intense direct sunlight can cause fading over time.
- **Mechanism:** The operating mechanism is designed to be maintenance-free. Do not lubricate or disassemble.

7. TROUBLESHOOTING

If you encounter any issues with your HOPPVALS blind, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blind does not stay up/down	Mechanism not engaging properly.	Ensure the blind is fully extended and then fully retracted a few times to reset the mechanism. Check that the handle is securely attached.
Blind is crooked	Improper installation or uneven tension.	Check that the mounting brackets are level and securely fastened. If the issue persists, re-install the blind ensuring it is properly seated in the brackets.
Difficulty moving blind	Obstruction or dirt in the mechanism.	Inspect the top and bottom rails for any obstructions. Clean any visible dust or debris. Do not force the blind.

If troubleshooting steps do not resolve the issue, please contact IKEA customer support.

8. SPECIFICATIONS

- **Model Name:** HOPPVALS Insulating Blind
- **Model Number:** 602.906.24
- **Brand:** IKEA
- **Color:** White
- **Dimensions (as per product description):** Length: 155 cm, Width: 100 cm
- **Material:** 100% Polyester (fabric), Aluminum (top/bottom rail)
- **Operation:** Manual, Cordless
- **Mounting:** Wall or Ceiling
- **Key Feature:** Thermal insulation, light filtering, privacy

9. WARRANTY INFORMATION

IKEA products are designed with quality and durability in mind. For specific warranty details regarding your HOPPVALS blind, please refer to the warranty card included with your purchase or visit the official IKEA website. Keep your proof of purchase for any warranty claims.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or need to report a defect, please contact IKEA customer service. You can find contact information on the IKEA website or in your purchase documentation.

IKEA Official Website: www.ikea.com