

[Manuals.plus](#) /

> [Ikea](#) /

> Ikea LILLHULT USB Type C to USB Cable User Manual

Ikea 40250855

Ikea LILLHULT USB Type C to USB Cable User Manual

Model: 40250855

INTRODUCTION

This user manual provides essential information for the safe and efficient use of your Ikea LILLHULT USB Type C to USB cable. Please read this manual carefully before using the product and retain it for future reference.

SETUP INSTRUCTIONS

The Ikea LILLHULT cable is designed for connecting devices with a USB Type C port to a power source or another device with a standard USB-A port for charging and data transfer.

- 1. Identify Connectors:** Locate the USB Type C connector (smaller, reversible) and the standard USB-A connector (larger, rectangular).
- 2. Connect to Device:** Insert the USB Type C connector into the compatible port on your smartphone, tablet, or other USB-C enabled device. Ensure it is fully seated.
- 3. Connect to Power/Data Source:** Insert the USB-A connector into a compatible USB wall adapter, power bank, computer USB port, or other USB-A enabled charging/data port.
- 4. Verify Connection:** Confirm that your device indicates it is charging or connected for data transfer.



Image: A person connecting the USB Type C end of the cable to a smartphone. This illustrates the initial connection step.

OPERATING INSTRUCTIONS

Charging Devices

Once properly connected to a power source, the cable will facilitate charging of your USB Type C device. Charging speed may vary depending on the power adapter and the device's charging capabilities.

Data Transfer

This cable supports data transfer at speeds up to 0.48 Gigabits Per Second. To transfer data, connect the USB-A end to a computer's USB port and the USB Type C end to your device. Your device may prompt you to select a connection mode (e.g., "File Transfer" or "MTP").



Image: The Ikea LILLHULT cable in use, connecting a smartphone to a charging base, with a laptop in the background. This demonstrates the cable's function in a typical setup.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the cable with a dry, soft cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, coil the cable loosely. Avoid sharp bends or kinks, especially near the connectors, to prevent internal wire damage. The integrated cable tie can be used for neat storage.
- **Handling:** Always grasp the connector housing when plugging or unplugging the cable, rather than pulling on the cable itself.
- **Environment:** Keep the cable away from extreme temperatures, direct sunlight, and moisture.



Image: A close-up view of the coiled Ikea LILLHULT cable, secured with its integrated cable tie, showing the durable braided design and the USB-A connector with the Ikea logo. This highlights the cable's design for easy storage and durability.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging.	Loose connection, faulty power adapter, incompatible device.	Ensure both ends of the cable are securely connected. Try a different power adapter or USB port. Verify device compatibility.
Slow charging.	Low-power USB port, power adapter not sufficient, background apps on device.	Use a higher-wattage power adapter. Close unnecessary applications on your device. Ensure the USB port provides adequate power.
Data transfer not working.	Incorrect device settings, driver issues on computer, loose connection.	Check your device's USB connection settings (e.g., select "File Transfer"). Ensure computer drivers are up to date. Reconnect the cable firmly.

SPECIFICATIONS

Brand:	Ikea
Model:	40250855
Connector Type:	USB Type C to USB-A
Cable Type:	USB
Length:	1.5 meters (4 feet 11 inches)
Compatible Devices:	Charging Adapter, USB Type C enabled devices
Special Feature:	Durable braided design
Data Transfer Rate:	Up to 0.48 Gigabits Per Second

Color: Black
Item Shape: Round
Manufacturer: Ikea

WARRANTY AND SUPPORT

For information regarding warranty, returns, or customer support, please refer to the purchase documentation or visit the official Ikea website. Keep your proof of purchase for any warranty claims.

Online Resources:

- Official Ikea Website: www.ikea.com
- Product Support Page (if available): Refer to the Ikea website for specific product support pages.