

Baby Einstein 12807

Baby Einstein Sea Floor Explorers 2-in-1 Water Mat Instruction Manual

Brand: Baby Einstein | **Model:** 12807

INTRODUCTION

The Baby Einstein Sea Floor Explorers 2-in-1 Water Mat Play Gym is designed to engage infants through sensory development and exploration. This versatile product offers four distinct modes of play, suitable for various developmental stages from newborn onwards. It features a comfortable play surface, five detachable sensory toys, and a unique water mat for mess-free aquatic play.

The water mat is removable, allowing for use on the floor or attached to a highchair. The play gym's design incorporates vibrant colors and high-contrast patterns to stimulate visual development, featuring familiar characters like Opus the Octopus and Neptune the Turtle.

PRODUCT FEATURES

- **Four Play Modes:** Adaptable for tummy time, lay and play, seated activities, and highchair use.
- **Detachable Water Mat:** Provides mess-free sensory exploration with floating ocean-themed elements. Can be used independently.
- **Five Removable Sensory Toys:** Includes a bead chaser, baby-safe mirror, sensory disc, plush chime fish, and a colorful ring to encourage interaction and development.
- **Soft & Comfortable Play Surface:** Ensures a cozy environment for your baby.
- **Visual Stimulation:** Features vibrant colors and high-contrast patterns to support visual development.
- **Portable Design:** The water mat folds easily for convenient storage and travel.



Figure 1: The Baby Einstein Sea Floor Explorers 2-in-1 Water Mat Play Gym.

SETUP

1. **Assemble Play Arches:** Connect the two flexible arches by inserting their ends into the designated slots on the play mat. Ensure they are securely fastened to form a stable archway over the mat.
2. **Attach Toys:** Clip the five included sensory toys onto the loops along the play arches. Toys can be repositioned as desired to suit your baby's reach and engagement.
3. **Prepare Water Mat:** Locate the fill valve on the back of the water mat. Open the valve and carefully fill the mat with clean tap water. Close the valve securely to prevent leaks.
4. **Attach Water Mat to Play Mat:** The water mat features Velcro fasteners on its underside. Align these fasteners with the corresponding areas on the main play mat and press firmly to secure. The water mat can also be used independently.



Figure 2: Filling the detachable water mat with water.



Figure 3: Detachable sensory toys and the water mat.

OPERATING MODES

The Sea Floor Explorers Play Gym offers versatile play options to support your baby's development:

- **Lay and Play:** Position your baby on their back under the arches. The hanging toys encourage reaching, batting, and visual tracking.
- **Tummy Time:** Place your baby on their stomach on the mat, with the water mat positioned in front of them. This encourages head lifting and strengthens neck and shoulder muscles while engaging with the floating elements.
- **Seated Activities:** As your baby grows and can sit independently, they can interact with the toys from a seated position, developing fine motor skills.
- **Highchair Play:** Detach the water mat and secure it to a highchair tray for sensory play during meal times or other seated activities.



Figure 4: Baby engaged in tummy time with the water mat.



Figure 5: Detached water mat used for highchair play.

Your browser does not support the video tag.

Video 1: Demonstration of the Baby Einstein Sea Floor Explorers Water Mat in various play scenarios.

MAINTENANCE AND CARE

- **Play Mat:** Remove the toy bar, all toys, and the plush toy before washing. Machine wash the mat with cold water on a gentle cycle. Do not use bleach. Air dry thoroughly.
- **Toy Bar Assembly and Toys:** Clean these components before use with a damp cloth and mild soap. Air dry completely. Do not immerse in water.
- **Water Mat:** Empty water from the mat after each use. Clean with a damp cloth and mild soap. Ensure it is completely dry before storing.
- **Storage:** The play mat and water mat can be folded for compact storage.



Figure 6: Folding the play mat for easy storage.

TROUBLESHOOTING

- **Toys not staying attached:** Ensure the plastic clips are fully closed and securely fastened to the fabric loops on the arches.
- **Water mat not inflating/leaking:** Check that the fill valve is tightly closed. If a leak is suspected, inspect the seams for any damage.
- **Water mat elements sticking:** Gently press on the water mat to dislodge any floating elements that may have stuck together.
- **Play mat unstable:** Verify that both arches are fully inserted into their respective base connectors on the mat.

SPECIFICATIONS




Feature	Detail
Product Dimensions	32 x 32 x 18 inches
Item Model Number	12807
Material Type	Plastic
Material Composition	50% fabric, 50% plastic
Item Weight	1.25 pounds
Power Source	No Power Source Required
Batteries Required	No

WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please refer to the contact information provided with your product packaging or visit the official Baby Einstein website.

You may also visit the [Baby Einstein Store on Amazon](#) for additional product details and customer service options.

Related Documents - 12807

	<p>Baby Einstein Sensory Splash Water Mat Instructions and Safety</p> <p>Comprehensive guide for the Baby Einstein Sensory Splash Water Mat, including setup, safety warnings, and maintenance instructions in multiple languages.</p>
	<p>Baby Einstein Ocean Explorers Curiosity Cove 2-in-1 Activity Jumper User Manual</p> <p>User manual for the Baby Einstein Ocean Explorers Curiosity Cove 2-in-1 Activity Jumper, providing safety instructions, assembly guide, care tips, battery information, and product features. Includes multilingual safety warnings and detailed parts list.</p>
	<p>Baby Einstein 4-in-1 Kickin' Tunes Jellyfish Jamboree Activity Gym - Instructions and Safety</p> <p>This document provides essential safety warnings, care instructions, battery information, assembly guidance, operating modes, and a parts list for the Baby Einstein 4-in-1 Kickin' Tunes Jellyfish Jamboree Music & Language Discovery Gym. Designed for infants up to 36 months.</p>



[Baby Einstein 4-in-1 Kickin' Tunes Musical Meadow Gym - User Manual & Assembly Guide](#)

Comprehensive user manual and assembly guide for the Baby Einstein 4-in-1 Kickin' Tunes Musical Meadow Music & Language Discovery Gym (Model 17447-BBWS). Includes safety warnings, care instructions, parts list, and battery information.



[Baby Einstein 4-in-1 Kickin' Tunes Musical Meadow Activity Gym - User Manual](#)

Comprehensive user manual for the Baby Einstein 4-in-1 Kickin' Tunes Musical Meadow Music & Language Discovery Gym. Includes safety warnings, assembly instructions, care and cleaning, battery information, and parts list.



[Baby Einstein 4-in-1 Kickin' Tunes Music and Language Discovery Gym Manual](#)

Comprehensive guide for the Baby Einstein 4-in-1 Kickin' Tunes Music and Language Discovery Gym, covering safety, assembly, care, and battery information. Features multiple languages.