

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MVMT](#) /

› [MVMT Hive Lightweight Aluminum Portable Wireless Bluetooth Speaker User Manual](#)

### MVMT SP2854-SIA

# MVMT Hive Lightweight Aluminum Portable Wireless Bluetooth Speaker

Model: SP2854-SIA

## INTRODUCTION

Thank you for purchasing the MVMT Hive Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it thoroughly before use to ensure optimal performance and longevity of your device.

## PACKAGE CONTENTS

Ensure all items are present in the package:

- 1 x MVMT Hive Bluetooth Speaker
- 1 x Auxiliary Cable
- 1 x Micro USB Charging Cable
- 1 x User Manual (this document)



*Image: A silver MVMT Hive portable Bluetooth speaker, showcasing its compact, cylindrical design and aluminum body, alongside its included auxiliary and micro USB cables.*

## CHARGING THE SPEAKER

1. Locate the Micro USB charging port on the speaker.
2. Connect the Micro USB end of the provided charging cable to the speaker's charging port.
3. Connect the standard USB end of the cable to a USB power adapter (not included) or a computer's USB port.
4. The charging indicator light will illuminate, typically red, to show that the speaker is charging.
5. A full charge takes approximately 3-4 hours. The indicator light will change or turn off once charging is complete.
6. A fully charged speaker provides up to 6 hours of playtime in Bluetooth wireless mode.

## BLUETOOTH PAIRING

Follow these steps to connect your MVMT Hive speaker to a Bluetooth-enabled device:

1. Ensure the speaker is fully charged.
2. Power on the speaker by pressing and holding the power button. The speaker will enter Bluetooth pairing mode, indicated by a flashing LED light.

3. On your mobile device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "MVMT Hive" from the list of found devices.
5. Once paired, the speaker will emit an audible confirmation tone, and the LED indicator will typically stop flashing and remain solid.
6. You can now play audio from your device through the MVMT Hive speaker.

*Note: The speaker will automatically attempt to reconnect to the last paired device when powered on, if that device's Bluetooth is active and within range.*

## AUX Mode Operation

To use the speaker with devices that do not support Bluetooth, use the auxiliary (AUX) input:

1. Connect one end of the provided 3.5mm auxiliary cable to the AUX input port on the MVMT Hive speaker.
2. Connect the other end of the 3.5mm auxiliary cable to the headphone jack or AUX output of your audio device.
3. The speaker should automatically switch to AUX mode. If not, ensure no Bluetooth connection is active.
4. Adjust the volume on both your audio device and the speaker for optimal sound.

## Troubleshooting

Problem	Solution
Speaker does not power on.	Ensure the speaker is fully charged. Connect it to a power source using the Micro USB cable and allow it to charge for 3-4 hours.
Cannot pair via Bluetooth.	<ol style="list-style-type: none"> <li>1. Ensure the speaker is in pairing mode (flashing LED).</li> <li>2. Make sure Bluetooth is enabled on your device and it is within 10 meters (33 feet) of the speaker.</li> <li>3. Forget "MVMT Hive" from your device's Bluetooth list and try pairing again.</li> <li>4. Turn both the speaker and your device off and on again.</li> </ol>
No sound or low volume.	<ol style="list-style-type: none"> <li>1. Increase the volume on both the speaker and your connected device.</li> <li>2. Ensure the speaker is correctly paired via Bluetooth or the AUX cable is securely connected.</li> <li>3. Check if the audio source is playing.</li> </ol>
Sound distortion.	<ol style="list-style-type: none"> <li>1. Reduce the volume on both the speaker and your device.</li> <li>2. Move the speaker closer to your Bluetooth device to avoid interference.</li> <li>3. Ensure the speaker is not placed near other electronic devices that may cause interference.</li> </ol>

## Maintenance and Care

- Keep the speaker away from water, moisture, and extreme temperatures.
- Do not expose the speaker to direct sunlight for extended periods.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid dropping or subjecting the speaker to strong impacts.
- When not in use for a long time, charge the speaker at least once every three months to maintain battery

health.

## SPECIFICATIONS

<b>Model Number</b>	SP2854-SIA
<b>Brand</b>	MVMT
<b>Connectivity Technology</b>	Bluetooth, Auxiliary, USB
<b>Power Source</b>	Battery Powered
<b>Battery Playtime</b>	Up to 6 hours (Bluetooth mode)
<b>Charge Time</b>	3-4 hours
<b>Speaker Output Power</b>	2 x 2W (4W total)
<b>Product Dimensions</b>	16.69 x 3.4 x 5.89 cm
<b>Weight</b>	317.51 g
<b>Material</b>	Lightweight Aluminum Body
<b>Special Feature</b>	Portable

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for warranty claims.