

Fossil Nate Analog Digital Men's Watch JR1507 Instruction Manual

Model: JR1507

1. INTRODUCTION

This manual provides essential instructions for the proper use, setup, and maintenance of your Fossil Nate Analog Digital Men's Watch, model JR1507. Please read this manual thoroughly before operating your watch to ensure optimal performance and longevity.

The Fossil Nate watch combines classic analog timekeeping with a functional digital display, offering features such as an alarm and stopwatch, all protected by a durable mineral crystal and water resistance up to 100 meters.

2. SAFETY INFORMATION

- Avoid exposing the watch to extreme temperatures (hot or cold) for prolonged periods.
- Do not operate the crown or pushers while the watch is submerged in water to maintain water resistance.
- Keep the watch away from strong magnetic fields, as they can affect timekeeping accuracy.
- Clean the watch regularly with a soft, dry cloth. For water-resistant models, a slightly damp cloth can be used, followed by drying.
- Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and water resistance.

3. PACKAGE CONTENTS

Your Fossil Nate Analog Digital Men's Watch package should contain the following items:

- Fossil Nate Analog Digital Men's Watch (Model JR1507)
- Instruction Manual (this document)
- Warranty Information (if applicable)

4. WATCH COMPONENTS OVERVIEW

Familiarize yourself with the main components of your watch:



Figure 1: Front view of the Fossil Nate Analog Digital Men's Watch JR1507. This image displays the watch face with both analog hands and the digital display, along with the various pushers and crown on the side.

- **Crown:** Used for setting analog time.

- **Pushers (Buttons):** Used for operating digital functions (Mode, Light, Start, Reset).
- **Analog Hands:** Hour, minute, and second hands for traditional timekeeping.
- **Digital Display:** Shows digital time, date, alarm, and stopwatch functions.
- **Watch Band:** Stainless steel band for securing the watch to your wrist.

5. SETUP AND INITIAL CONFIGURATION

5.1 Setting the Analog Time

1. Pull the crown out to the furthest position.
2. Rotate the crown to move the hour and minute hands to the correct time.
3. Push the crown back in to its normal position to start the analog timekeeping.

5.2 Setting the Digital Time and Date

The digital display typically has multiple modes. Use the "MODE" pusher (usually bottom left) to cycle through them.

1. Press the "MODE" pusher repeatedly until the digital time display starts flashing or enters setting mode.
2. Use the "RESET" pusher (usually bottom right) to select the digit or setting you wish to adjust (e.g., hours, minutes, month, day).
3. Use the "START" pusher (usually top right) to increase the value of the selected digit.
4. Once all settings are correct, press the "MODE" pusher again to exit the setting mode.

5.3 Setting the Alarm

1. Press the "MODE" pusher until the alarm mode is displayed (often indicated by "AL" or an alarm icon).
2. Press the "RESET" pusher to select the hour or minute digit for the alarm.
3. Use the "START" pusher to adjust the alarm time.
4. Press the "MODE" pusher to confirm and exit. To activate/deactivate the alarm, there is usually a dedicated button or a combination of buttons (refer to specific watch module instructions if available).

6. OPERATING THE WATCH

6.1 Using the Stopwatch Function

1. Press the "MODE" pusher until the stopwatch mode is displayed (often indicated by "ST" or "STOP").
2. Press the "START" pusher to begin timing.
3. Press the "START" pusher again to pause timing.
4. Press the "RESET" pusher to reset the stopwatch to zero.

6.2 Using the Backlight

Press the "LIGHT" pusher (usually top left) to illuminate the digital display for a few seconds, aiding visibility in low-light conditions.

6.3 Water Resistance

Your Fossil Nate watch is water-resistant to 100 meters (330 feet / 10 ATM). This means it is suitable for showering, swimming, and snorkeling. However, it is **not** suitable for high-impact water sports or scuba diving. Ensure the crown and pushers are fully pushed in before any water exposure.



Figure 2: The Fossil Nate watch displayed on a wrist, illustrating its size and fit. The watch features a black stainless steel band and a prominent black dial.

7. MAINTENANCE AND CARE

- **Cleaning:** Wipe the watch case and band regularly with a soft, dry cloth. For stainless steel bands, a slightly damp cloth can be used, ensuring it is dried thoroughly afterward.
- **Battery:** The watch is powered by a product-specific battery (included). When the battery runs low, the digital display may dim or the watch may stop. It is recommended to have the battery replaced by an authorized service center to maintain water resistance and ensure proper function.
- **Storage:** When not in use for extended periods, store the watch in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Impact:** While durable, avoid dropping the watch or subjecting it to strong impacts, which can damage the internal movement or crystal.

8. TROUBLESHOOTING

- **Watch Not Running:**
 - Check if the crown is fully pushed in.
 - The battery may need replacement.
- **Digital Display Dim or Blank:**
 - The battery may be low and require replacement.
 - Ensure the watch is not in a power-saving mode (if applicable).
- **Analog and Digital Times Do Not Match:**
 - Re-set both the analog and digital times as per Section 5.1 and 5.2.
- **Water Inside Watch:**
 - Immediately take the watch to an authorized service center. Do not attempt to open it yourself.

9. SPECIFICATIONS

Feature	Specification
---------	---------------

Model Number	JR1507
Movement	Quartz
Case Diameter	49mm (as per description) / 50 Millimetres (as per specifications)
Case Thickness	15MM (as per description) / 12 Millimetres (as per specifications)
Band Width	24 Millimetres
Case Material	Stainless Steel
Band Material	Stainless Steel
Crystal Type	Mineral Crystal
Water Resistance	100 Meters / 330 Feet / 10 ATM
Functions	Analog Time, Digital Time, Alarm, Stopwatch, Light
Battery	1 Product Specific battery (included)
Item Weight	249 g




Figure 3: A visual guide illustrating different watch case diameters, ranging from 14-16mm up to 50-54mm, to help understand the relative size of the 49-50mm Fossil Nate watch.

10. WARRANTY AND SUPPORT

For warranty information, please refer to the separate warranty card or documentation included with your purchase. Fossil watches typically come with a limited warranty covering manufacturing defects. For technical support, service, or to locate an authorized service center, please visit the official Fossil website or contact their customer service department. Keep your proof of purchase for warranty claims. You can visit the official Fossil Store for more information:[Fossil Store on Amazon.in](https://www.amazon.in)

