

[Manuals.plus](#) /

› [INJUSA](#) /

› INJUSA The Beast 12V Electric Quad Instruction Manual

INJUSA 761

INJUSA The Beast 12V Electric Quad

Instruction Manual - Model 761

INTRODUCTION

Thank you for choosing the INJUSA The Beast 12V Electric Quad. This electric ride-on toy is designed for children aged 2 to 4 years, offering a fun and realistic driving experience. Please read this manual carefully before assembly and use to ensure safe operation and proper maintenance of your product.



Image: The INJUSA The Beast 12V Electric Quad, showcasing its red and black design with large wheels.

SAFETY INFORMATION

WARNING: To prevent serious injury, adult supervision is required at all times. This product is a toy and is not intended for use on public roads or heavy traffic areas. Always ensure the child wears appropriate safety gear, including a helmet.

- **Age Range:** Suitable for children aged 24 months to 4 years.
- **Maximum Weight Capacity:** Do not exceed 30 kg (66 lbs).
- **Operating Environment:** Use only on flat, dry surfaces away from swimming pools, stairs, hills, and other hazards.
- **Battery Safety:** Keep the battery away from children. Do not short-circuit the battery terminals.
- **Assembly:** Adult assembly is required. Ensure all parts are securely fastened before use.
- **Braking:** The quad features an electric brake that activates when the accelerator pedal is released.

PACKAGE CONTENTS

Please check that all components are present before beginning assembly:

- INJUSA The Beast 12V Electric Quad (main body and unassembled parts)
- 12V Rechargeable Battery
- Battery Charger

- Instruction Manual (this document)
- Assembly Hardware (screws, washers, etc.)

SETUP AND ASSEMBLY

Adult assembly is required. Follow these steps carefully. Refer to the diagrams for visual guidance.

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Attach Wheels:** Securely attach the front and rear wheels. Ensure the rear wheels with rubber bands are correctly positioned for enhanced grip.



Image: Detail of the quad's wheel, showing the rubber band for improved traction.

3. **Install Steering Column/Handlebars:** Connect the handlebars to the steering mechanism.
4. **Connect Battery:** Locate the battery compartment, typically under the seat or chassis. Connect the battery terminals as indicated in the diagram.



Image: View of the quad's underside, highlighting the battery compartment for installation.

5. **Secure All Fasteners:** Double-check that all screws, nuts, and bolts are tightened.

CHARGING THE BATTERY

For optimal performance, fully charge the battery before first use and after each play session.

- **Initial Charge:** Charge the battery for 8-12 hours before the first use. Do not exceed 18 hours.
- **Regular Charging:** After each use, charge the battery for 8-12 hours.
- **Charging Procedure:**
 - a. Ensure the quad is turned off.
 - b. Locate the charging port (refer to the product diagram if needed).
 - c. Plug the charger into a standard wall outlet.
 - d. Connect the charger's plug to the quad's charging port.
 - e. The charger indicator light will show the charging status (refer to charger manual for specific light indications).
 - f. Once charging is complete, disconnect the charger from the quad and then from the wall outlet.
- **Battery Life:** The average battery life per charge is approximately 60 minutes, depending on usage and terrain.

OPERATING INSTRUCTIONS

Familiarize your child with the controls in a safe, open area under constant adult supervision.

1. **Power On/Off:** Locate the power switch (usually a button or lever) and turn the quad ON.
2. **Accelerator Pedal:** The quad is equipped with an accelerator pedal. Press the pedal to move forward.



Image: Detailed view of the accelerator pedal, located on the footrest of the quad.

3. **Braking:** Release the accelerator pedal to activate the electric brake and stop the quad.
4. **Reverse Gear:** A switch allows selection of forward or reverse motion. Ensure the quad is stationary before changing direction.
5. **Steering:** Use the handlebars to steer the quad left or right.
6. **Speed:** The quad can reach speeds up to 6 km/h.



Image: A child seated on the INJUSA The Beast 12V Electric Quad, demonstrating its use.

MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your electric quad.

- **Cleaning:** Wipe the quad with a damp cloth. Do not use abrasive cleaners or solvents. Do not hose down or immerse in water.
- **Storage:** Store the quad in a dry, cool place away from direct sunlight. If storing for extended periods, charge the battery fully before storage and recharge every 3 months to prolong battery life.
- **Battery Care:** Do not allow the battery to fully discharge. Always recharge after use.
- **Inspections:** Periodically check all fasteners, wheels, and electrical connections for wear or damage. Replace worn parts immediately.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Quad does not move	Battery is low or discharged; Loose battery connection; Power switch is off; Faulty accelerator pedal.	Charge the battery; Check battery terminals; Turn power switch ON; Contact customer support.
Quad moves slowly	Battery is low; Overloaded (exceeds 30 kg); Operating on uneven or soft terrain.	Recharge battery; Ensure child's weight is within limits; Use on flat, hard surfaces.
Charger light not indicating charge	Charger not properly plugged in; Faulty charger or battery.	Check connections; Test wall outlet; Contact customer support.
Unusual noises during operation	Loose parts; Debris in wheels/motor; Worn gears.	Inspect for loose parts and tighten; Clear any debris; Contact customer support.

SPECIFICATIONS

- **Model:** 761 (The Beast)
- **Brand:** INJUSA
- **Battery:** 1 x 12V (included)
- **Recommended Age:** 24 months - 4 years
- **Maximum Speed:** Up to 6 km/h
- **Maximum Weight Capacity:** 30 kg (66 lbs)
- **Product Dimensions (L x W x H):** 81 x 60 x 58 cm
- **Item Weight:** 10 kg
- **Material:** Plastic
- **Average Battery Life per Charge:** Approximately 60 minutes
- **Assembly Required:** Yes
- **Safety Standards:** Complies with European safety standards EN71 and 62115
- **Origin:** Made in Spain

WARRANTY INFORMATION

INJUSA offers the following warranty for this product:

- **Product Warranty:** 3 years against manufacturing defects.
- **Battery and Charger Warranty:** 1 year against manufacturing defects.
- **Spare Parts Availability:** Spare parts are available for up to 10 years after purchase.

Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to make a warranty claim, please contact INJUSA customer support:

- **Email:** info@injusa.com, service@injusa.com

- **Phone:** +34 96 555 08 62
- **Address:** Industrial Juguetera S.A., Avenida Azorin 20, 03440 Ibi, Alicante, España

For more information, visit the official INJUSA website or your local retailer.

© 2024 INJUSA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question