

[Manuals.plus](#) /

› [Seneca River Trading](#) /

› Seneca River Trading Dryer Motor Model 33002795 Instruction Manual

Seneca River Trading 33002795

Seneca River Trading Dryer Motor Model 33002795 Instruction Manual

Brand: Seneca River Trading | Model: 33002795

1. INTRODUCTION

This manual provides essential information for the safe and correct installation and maintenance of the Seneca River Trading Dryer Motor, model 33002795. This motor is designed as a replacement part for specific dryer models manufactured by Whirlpool, Maytag, Magic Chef, Amana, Jenn Air, and Kenmore. Please read these instructions thoroughly before attempting any installation or repair.

2. SAFETY INFORMATION

Improper installation or repair can result in electric shock, fire, or personal injury. Always adhere to the following safety precautions:

- **Disconnect Power:** Always unplug the dryer from the electrical outlet or turn off the circuit breaker before beginning any service or repair.
- **Professional Installation Recommended:** Due to the complexity of dryer repairs, installation by a qualified technician is highly recommended.
- **Wear Protective Gear:** Use appropriate personal protective equipment, such as gloves and safety glasses, to prevent injury.
- **Handle with Care:** The motor contains electrical components and moving parts. Handle it carefully to avoid damage or injury.
- **Warning Label:** Observe all warning labels present on the motor itself. An example of such a label is visible in the product images.




Figure 1: Seneca River Trading Dryer Motor, model 33002795. This view highlights the motor's robust construction, copper windings, and the important warning label affixed to its surface. The threaded shaft for the blower belt pulley is also visible.

3. PRODUCT OVERVIEW

The Seneca River Trading Dryer Motor, model 33002795, is a non-OEM replacement part designed to restore functionality to compatible dryers. It features a 2-3/4 inch long threaded shaft for the blower belt pulley. The package includes the motor unit as the primary component.

This motor replaces several part numbers, including AP4043081, 1002859, AH2036417, EA2036417, PS2036417, AP6007997, PS11741125, PS2036417, and WP33002795.




Figure 2: Side view of the Seneca River Trading Dryer Motor. This perspective clearly shows the motor's main housing, the extended shaft with orange and blue components, and the electrical terminal block for wiring connections.

4. COMPATIBILITY

This replacement dryer motor is designed to fit specific dryer models from the following manufacturers:

- Whirlpool
- Maytag
- Magic Chef
- Amana
- Jenn Air
- Kenmore

Always verify the original part number of your dryer motor against the replacement numbers provided (AP4043081, 1002859, AH2036417, EA2036417, PS2036417, AP6007997, PS11741125, PS2036417, WP33002795) to ensure proper fitment before purchase and installation.

5. INSTALLATION INSTRUCTIONS

Warning: Ensure the dryer is completely disconnected from power before proceeding. If you are not comfortable performing this repair, consult a qualified appliance technician.

1. **Disconnect Power:** Unplug the dryer from the wall outlet or turn off the corresponding circuit breaker at your

home's electrical panel.

2. **Access the Motor:** Depending on your dryer model (especially stackable units), this may involve significant disassembly of the dryer cabinet. Refer to your specific dryer's service manual for detailed instructions on how to access the motor compartment.
3. **Document Wiring:** Before disconnecting any wires from the old motor, take clear photographs or make a detailed diagram of the wiring connections. This will be crucial for correctly connecting the new motor.
4. **Remove Old Motor:** Carefully disconnect all wiring, belts, and mounting hardware securing the old motor. Note the orientation and position of all components.
5. **Install New Motor:** Position the new Seneca River Trading motor in the dryer. Secure it using the appropriate mounting hardware. Ensure the motor is seated correctly and all mounting points are aligned.
6. **Connect Wiring:** Using your documented wiring diagram, carefully connect all electrical wires to the new motor's terminals. Double-check each connection for security and correctness.
7. **Attach Belt and Blower:** Reattach the drive belt to the motor pulley and the blower fan to the motor shaft.
Note: Some users have reported that the shaft may not be an exact fit for all plastic squirrel cage fans, potentially requiring a new fan or modification. Verify compatibility before final assembly.
8. **Reassemble Dryer:** Carefully reassemble the dryer cabinet, ensuring all panels and covers are securely fastened.
9. **Test Operation:** Plug the dryer back into the electrical outlet or restore power at the circuit breaker. Run a short cycle to verify the motor operates correctly and quietly. Listen for any unusual noises.

6. POST-INSTALLATION CHECK

After installation, perform the following checks:

- Confirm the dryer starts and stops normally.
- Listen for any abnormal sounds, such as grinding, squealing, or excessive vibration. A slight increase in noise during initial startup compared to the original motor has been noted by some users, which may quiet down as the motor heats up.
- Ensure the drum rotates smoothly and the blower fan is moving air effectively.
- Check for any burning smells, which could indicate an electrical issue. Immediately disconnect power if detected.

7. MAINTENANCE

To ensure the longevity of your dryer and its components, including the motor, consider the following general maintenance tips:

- **Clean Lint Filter:** Clean the lint filter before or after every load to maintain proper airflow and prevent motor strain.
- **Inspect Venting:** Periodically inspect and clean the dryer's exhaust vent to prevent blockages, which can cause the motor to overheat.
- **Avoid Overloading:** Do not overload the dryer, as this puts excessive strain on the motor and other moving parts.
- **Regular Inspections:** If comfortable, periodically inspect internal components for signs of wear, loose connections, or lint buildup.

8. TROUBLESHOOTING

If you encounter issues after installing the new motor, consider the following:

- **Motor Not Starting / No Operation:**
 - Verify all electrical connections are secure and correctly matched to the wiring diagram.
 - Check for any bent or faulty pins on the motor's electrical terminals, as this can prevent proper contact.
 - Ensure the dryer door switch is functioning correctly and the door is fully closed.
 - Confirm power supply to the dryer.
- **Unusual Noise:**
 - Check for any obstructions in the blower fan or drum area.
 - Ensure the motor is securely mounted and not vibrating against other components.
 - Verify the drive belt is properly tensioned and aligned.
- **Shaft Incompatibility with Blower Fan:**
 - Some users have reported that the motor shaft may not be perfectly compatible with existing plastic squirrel cage fans. If this occurs, you may need to source a compatible blower fan or consult a technician for modification options.

If troubleshooting steps do not resolve the issue, contact a qualified appliance repair technician.

9. SPECIFICATIONS

Feature	Detail
Brand Name	Seneca River Trading
Model Number	33002795
Item Weight	9.31 pounds
Product Dimensions	12 x 7 x 8 inches
Part Number	33002795
Color	Multicolor
Included Components	Motor
Replaces Part Numbers	AP4043081, 1002859, AH2036417, EA2036417, PS2036417, AP6007997, PS11741125, PS2036417, WP33002795

10. WARRANTY INFORMATION

Specific warranty details for the Seneca River Trading Dryer Motor Model 33002795 were not provided in the product information. For warranty inquiries, please contact the seller directly or refer to any documentation included with your purchase.

11. SUPPORT

If you require further assistance with installation, troubleshooting, or have questions regarding the Seneca River Trading Dryer Motor, please contact the retailer from whom you purchased the product or consult a certified

appliance repair technician.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B017UQE7P0>

More documents and user manuals: <https://manuals.plus/>