

[Manuals.plus](#) /

› [BARNETT](#) /

› Barnett Crank Cocking Device Replacement Handle Manual

## BARNETT BAR730175

# Barnett Crank Cocking Device Replacement Handle Manual

Model: BAR730175

## 1. INTRODUCTION

This manual provides essential information for the proper use, installation, and maintenance of your Barnett Crank Cocking Device Replacement Handle (Model BAR730175). This handle is an OEM replacement part designed to restore the functionality of your compatible Barnett crank cocking device. Please read these instructions thoroughly before attempting any installation or operation to ensure safe and effective use.

## 2. PRODUCT OVERVIEW

The Barnett Crank Cocking Device Replacement Handle is constructed from durable aluminum with a black powder-coated finish, ensuring longevity and resistance to wear. It is designed for easy, threaded attachment to your existing crank cocking device.





Figure 2.1: Angled view of the Barnett Crank Cocking Device Replacement Handle, showing its overall shape and textured grip.



Figure 2.2: Side view of the replacement handle, highlighting the ergonomic curve and the attachment point.



Figure 2.3: Top view of the handle, showing the textured grip and the threaded connection point.



Figure 2.4: Detailed view of the threaded attachment mechanism, indicating how the handle connects to the crank cocking device.

### 3. COMPATIBILITY

This replacement handle is specifically designed for use with certain Barnett Crank Cocking Devices. Please verify your device model against the lists below to ensure proper fit and function.

### 3.1 Compatible Models:

- Vengeance CCD (Item 17450)
- Standard CCD of 16" power stroke or less (Item 17455)
- Tactical CCD (Item BAR20011)
- Standard CCD Hook Style (Item BAR20020)
- Standard CCD Sled Style (Item BAR20030)
- Explorer CCD (Item BAR20021)
- Barnett Stalker 410 w/CCD
- Quad 400 Crank Handle

### 3.2 Non-Compatible Models:

- HyperGhost CCD
- HyperTac Pro 430
- Predator/Revolution CCD
- Hyper Raptor

If your device is not listed under compatible models, or is listed under non-compatible models, this handle will not function correctly with your device.

## 4. SETUP AND INSTALLATION

The replacement handle is designed for straightforward installation. Ensure your crank cocking device is unloaded and safe before proceeding.

1. **Identify the Attachment Point:** Locate the threaded shaft on your Barnett Crank Cocking Device where the original handle was attached.
2. **Align the Handle:** Position the replacement handle over the threaded shaft.
3. **Thread On:** Carefully turn the handle clockwise onto the shaft until it is securely fastened. Ensure it is tight enough to prevent wobbling during use, but do not overtighten.
4. **Test Functionality:** Once installed, gently operate the crank cocking device to ensure the handle is properly seated and functions smoothly.

If you encounter resistance or difficulty, do not force the handle. Re-check alignment and ensure no debris is obstructing the threads.

## 5. OPERATING INSTRUCTIONS

Once the replacement handle is securely installed, operate your crank cocking device as per its original manufacturer's instructions. The handle provides the necessary leverage to safely and efficiently cock your crossbow.

- **Grip:** Hold the handle firmly.
- **Crank:** Turn the handle in the direction specified by your crank cocking device's manual to draw the crossbow string.
- **Smooth Operation:** Apply steady, even pressure. Avoid jerky movements.

Always refer to your specific crossbow and crank cocking device manual for detailed operating procedures and safety

warnings.

## 6. MAINTENANCE

Regular maintenance will extend the life of your replacement handle and ensure reliable performance.

- **Cleaning:** Wipe the handle with a clean, dry cloth after each use to remove dirt, dust, and moisture. For stubborn grime, a slightly damp cloth can be used, followed by thorough drying.
- **Inspection:** Periodically inspect the handle for any signs of damage, such as cracks, bends, or loose connections. Ensure the threaded attachment remains secure.
- **Storage:** Store the handle in a dry environment, away from extreme temperatures and corrosive substances.

Do not use harsh chemicals or abrasive cleaners, as these may damage the finish or material of the handle.

## 7. TROUBLESHOOTING

This section addresses common issues you might encounter with the replacement handle.

### 7.1 Handle Does Not Attach Securely:

- **Check Compatibility:** Verify that your crank cocking device model is listed as compatible in Section 3.
- **Inspect Threads:** Ensure both the handle's internal threads and the device's external shaft threads are clean and undamaged. Remove any debris.
- **Alignment:** Make sure the handle is aligned straight before attempting to thread it on.

### 7.2 Handle Feels Loose After Installation:

- **Retighten:** Gently retighten the handle. If it continues to loosen during use, inspect the threads for wear.
- **Compatibility:** Reconfirm compatibility. An incorrect handle may not seat properly.

If issues persist after following these steps, contact Barnett customer support or a qualified technician.

## 8. SPECIFICATIONS

|                             |                       |
|-----------------------------|-----------------------|
| Model Number                | BAR730175             |
| Brand                       | BARNETT               |
| Material                    | Aluminum              |
| Color                       | Black                 |
| Exterior Finish             | Black Powder-coated   |
| Item Weight                 | 8 ounces (0.5 Pounds) |
| Package Dimensions          | 10 x 3 x 3 inches     |
| Handle Attachment Mechanism | Threaded              |
| Included Components         | Handle (1 piece)      |
| Specific Uses               | Archery, Hunting      |

## 9. WARRANTY INFORMATION

Specific warranty details for this replacement handle are not provided in this document. For information regarding warranty coverage, terms, and conditions, please refer to the official Barnett Outdoors website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

## 10. CUSTOMER SUPPORT

For technical assistance, questions about compatibility, or other product-related inquiries, please contact Barnett Outdoors customer support. Contact information can typically be found on the manufacturer's official website.

**Manufacturer:** Barnett Outdoors

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**