

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Lorell](#) /
- › [Lorell Modern Chair Mid-back Leather Guest Chair Instruction Manual LLR59539](#)

Lorell LLR59539

Lorell Modern Chair Mid-back Leather Guest Chair Instruction Manual

Model: LLR59539

INTRODUCTION

This manual provides essential information for the proper setup, use, and maintenance of your Lorell Modern Mid-back Leather Guest Chair, Model LLR59539. Please read these instructions carefully before assembly and use to ensure safe and optimal performance.



Image 1: Front view of the Lorell Modern Mid-back Leather Guest Chair. The chair features a black bonded leather seat and back with

horizontal stitching, chromed metal arms with leather pads, and a polished aluminum cantilever base.

SETUP AND ASSEMBLY

The Lorell Modern Guest Chair is designed for minimal assembly. Typically, the chair arrives largely pre-assembled. Follow these general steps:

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging materials until assembly is complete and you are satisfied with the product.
2. **Component Check:** Verify all parts are present and undamaged. Refer to the included parts list (if provided in physical packaging).
3. **Base Attachment (if separate):** If the cantilever base is separate, align it with the chair's seat frame and secure it using the provided hardware (screws, washers) and tools (e.g., Allen wrench). Ensure all connections are tightened securely.
4. **Armrest Attachment (if separate):** If armrests are separate, attach them to the chair frame using the provided hardware. Ensure they are firmly secured.
5. **Final Inspection:** After assembly, gently test the chair for stability and ensure all connections are tight. Do not use the chair if any part feels loose or unstable.

For detailed assembly instructions, please refer to the specific guide included in your product packaging.

OPERATING INSTRUCTIONS

This guest chair is designed for stationary seating. It does not feature adjustable components such as height or recline mechanisms. To use the chair:

- **Placement:** Position the chair on a stable, level surface. The polished aluminum cantilever base is suitable for hard floor surfaces.
- **Seating:** Sit centrally on the seat cushion. The chair is designed to support a maximum weight of 275 pounds.
- **Armrests:** Utilize the padded armrests for comfort and support.

Avoid standing on the chair or using it for purposes other than seating to prevent damage or injury.

CARE AND MAINTENANCE

Proper care ensures the longevity and appearance of your Lorell guest chair.

- **Cleaning Leather Surfaces:** Wipe clean with a soft, damp cloth. For more stubborn marks, use a mild leather cleaner specifically designed for bonded leather, following the product's instructions. Avoid abrasive cleaners or solvents.
- **Cleaning Metal Surfaces:** The polished aluminum base and chromed metal arms can be cleaned with a soft, dry cloth. For smudges, a slightly damp cloth followed by a dry buff can restore shine. Avoid harsh chemicals that may damage the finish.
- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the leather to fade or crack. Position the chair away from direct sunlight when possible.
- **Spill Management:** Blot spills immediately with a clean, dry cloth. Do not rub, as this can spread the stain.

TROUBLESHOOTING

If you encounter any issues with your Lorell guest chair, refer to the following common solutions:

- **Chair is Unstable/Wobbly:**
 - Ensure the chair is placed on a flat, even surface.
 - Check all assembly screws and bolts. Tighten any loose connections.
- **Squeaking Noises:**
 - Inspect the connections between the seat, back, and base. Tighten any loose hardware.
 - Apply a small amount of silicone lubricant to metal-on-metal contact points if tightening does not resolve the issue.
- **Leather Surface Damage:**
 - For minor scuffs, a leather conditioner or repair kit designed for bonded leather may help.
 - For significant damage, contact Lorell customer support for advice or professional repair options.

If problems persist, please contact Lorell customer support.

PRODUCT SPECIFICATIONS



Image 2: Diagram showing the dimensions of the Lorell Modern Mid-back Leather Guest Chair. The chair is approximately 21 inches deep, 27.3 inches wide, and 31 inches high.

Model Number	LLR59539
Brand	Lorell

Product Dimensions	21"D x 27.3"W x 31"H
Seat Height	18 Inches
Seat Depth	18.75 Inches
Item Weight	54 pounds
Maximum Weight Capacity	275 pounds
Material	Bonded Leather (Seat/Back), Polished Aluminum (Base), Chromed Metal (Arms)
Color	Black
Special Features	Padded Armrest
Care Instructions	Wipe Clean
UPC	035255595391

WARRANTY INFORMATION

Specific warranty details for the Lorell Modern Mid-back Leather Guest Chair are typically provided with your purchase documentation. Please refer to the warranty card or information sheet included in the product packaging for terms, conditions, and duration of coverage.

In general, Lorell products are manufactured to high standards and are covered against defects in materials and workmanship under normal use. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For further assistance, parts replacement, or to report any issues not covered in this manual, please contact Lorell customer support.

Please have your model number (LLR59539) and proof of purchase available when contacting support. Contact information can typically be found on the Lorell official website or on your product packaging.

